



**HIRSCHMANN**

A **BELDEN** BRAND

# Reference Manual

## Command Line Interface

### Industrial ETHERNET (Gigabit) Switch

RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30,  
MACH100, MACH 1000, PowerMICE, MACH 4000, OCTOPUS

L2P Rel. 7.1

The screenshot shows the Command Line Interface (CLI) for a Hirschmann switch. The title bar at the top left says "Command Line" and the top right features the Hirschmann logo and "HIRSCHMANN A Belden Company". The main content area displays a list of commands and their descriptions:

```
(Hirschmann PowerMICE) (Config)#?  
  
access-list          Configure Access List parameters.  
address-conflict    Configure the device's address conflict detection  
                    mode or enable or disable the ongoing detection.  
arp                 Configure a static ARP entry.  
authentication      Configure an Authentication List.  
auto-negotiate      Enables/Disables automatic negotiation on a port. The  
                    cable-crossing settings have no effect if auto-  
                    negotiation is enabled. In this case cable-crossing  
                    is always set to auto. Cable-crossing is set to the  
                    value chosen by the user if auto-negotiation is  
                    disabled.  
  
bridge              Configure forwarding database parameters.  
classofservice      Configure Class of Service parameters.  
config-watchdog     Configure the Auto Configuration Undo settings.  
cos-queue           Configure the Cos Queue Parameters.  
deleteport          Delete all ports from a link-aggregation.  
device-status       Configure which events are to be included in the  
                    device status as well as the trap setting.  
  
dhcp-relay          Configure the DHCP Relay's server addresses and the  
                    Option 82 settings.  
  
dhcp-server         Configure the DHCP-Server  
disable             Disables/Enables parameters for various protocols.  
--More-- or (q)uit
```

The naming of copyrighted trademarks in this manual, even when not specially indicated, should not be taken to mean that these names may be considered as free in the sense of the trademark and tradename protection law and hence that they may be freely used by anyone.

© 2011 Hirschmann Automation and Control GmbH

Manuals and software are protected by copyright. All rights reserved. The copying, reproduction, translation, conversion into any electronic medium or machine scannable form is not permitted, either in whole or in part. An exception is the preparation of a backup copy of the software for your own use. For devices with embedded software, the end-user license agreement on the enclosed CD applies

The performance features described here are binding only if they have been expressly guaranteed in the contract. This publication has been created by Hirschmann Automation and Control GmbH according to the best of our knowledge. Hirschmann reserves the right to change the contents of this manual without prior notice. Hirschmann can give no guarantee in respect of the correctness or accuracy of the details in this publication.

Hirschmann can accept no responsibility for damages, resulting from the use of the network components or the associated operating software. In addition, we refer to the conditions of use specified in the license contract.

Printed in Germany 12/6/11

Hirschmann Automation and Control GmbH  
Stuttgarter Str. 45-51  
72654 Neckartenzlingen  
Germany  
Tel.: +49 1805 141538

12/2011

# Content

	About this Manual	21
1	Command Structure	23
1.1	Format	24
	1.1.1 Command	24
	1.1.2 Parameters	25
	1.1.3 Values	25
	1.1.4 Conventions	27
	1.1.5 Annotations	28
	1.1.6 Special keys	29
	1.1.7 Special characters in scripts	30
	1.1.8 Secrets in scripts	32
2	Quick Start up	35
2.1	Quick Starting the Switch	36
2.2	System Info and System Setup	37
3	Mode-based CLI	43
3.1	Mode-based Topology	44
3.2	Mode-based Command Hierarchy	45
3.3	Flow of Operation	47
3.4	“No” Form of a Command	49
	3.4.1 Support for “No” Form	49
	3.4.2 Behavior of Command Help (“?”)	49
4	CLI Commands: Base	51
4.1	System Information and Statistics Commands	52
	4.1.1 show address-conflict	52
	4.1.2 show arp switch	52
	4.1.3 show bridge address-learning	53
	4.1.4 show bridge address-relearn-detect	53
	4.1.5 show bridge aging-time	54
	4.1.6 show bridge duplex-mismatch-detect	54

4.1.7	show bridge fast-link-detection	54
4.1.8	show bridge framesize	55
4.1.9	show bridge vlan-learning	55
4.1.10	bridge framesize	56
4.1.11	show config-watchdog	56
4.1.12	show device-status	57
4.1.13	show authentication	58
4.1.14	show eventlog	59
4.1.15	show interface	60
4.1.16	show interface ethernet	62
4.1.17	show interface switchport	70
4.1.18	show logging	70
4.1.19	show mac-addr-table	71
4.1.20	show signal-contact	72
4.1.21	show slot	73
4.1.22	show running-config	74
4.1.23	show sysinfo	75
4.1.24	show temperature	78
4.2	Debug Commands	79
4.2.1	debug tcpdump help	79
4.2.2	debug tcpdump start cpu	79
4.2.3	debug tcpdump start cpu filter	80
4.2.4	debug tcpdump stop	80
4.2.5	debug tcpdump filter show	81
4.2.6	debug tcpdump filter list	81
4.2.7	debug tcpdump filter delete	82
4.3	Management VLAN Commands	83
4.3.1	network mgmt_vlan	83
4.4	Class of Service (CoS) Commands	84
4.4.1	classofservice dot1p-mapping	85
4.4.2	classofservice ip-dscp-mapping	86
4.4.3	classofservice trust	87
4.4.4	show classofservice dot1p-mapping	88
4.4.5	show classofservice ip-dscp-mapping	89
4.4.6	show classofservice trust	90
4.4.7	vlan port priority all	91
4.4.8	vlan priority	91
4.4.9	dvlan-tunnel ethertype	92
4.4.10	mode dvlan-tunnel	93

4.4.11	show dvlan-tunnel	94
4.5	Link Aggregation(802.3ad) Commands	95
4.5.1	link-aggregation staticcapability	95
4.5.2	show link-aggregation brief	96
4.6	Management Commands	97
4.6.1	telnet	97
4.6.2	transport input telnet	98
4.6.3	transport output telnet	99
4.6.4	session-limit	100
4.6.5	session-timeout	101
4.6.6	bridge address-learning	101
4.6.7	bridge address-relearn detect operation	102
4.6.8	bridge address-relearn detect threshold	102
4.6.9	bridge aging-time	103
4.6.10	bridge fast-link-detection	104
4.6.11	bridge duplex-mismatch-detect operation	104
4.6.12	bridge vlan-learning	105
4.6.13	digital-input	105
4.6.14	digital-output	107
4.6.15	show digital-input	110
4.6.16	show digital-input config	111
4.6.17	show digital-input all	112
4.6.18	show digital-input <slot/input>	113
4.6.19	show digital-output	114
4.6.20	show digital-output config	115
4.6.21	show digital-output all	116
4.6.22	show digital-output <slot/output>	117
4.6.23	ethernet-ip	118
4.6.24	network javascriptmode	118
4.6.25	network mgmt-access add	119
4.6.26	network mgmt-access delete	120
4.6.27	network mgmt-access modify	121
4.6.28	network mgmt-access operation	122
4.6.29	network mgmt-access status	122
4.6.30	network parms	123
4.6.31	network protocol	123
4.6.32	network priority	124
4.6.33	profinetio	125
4.6.34	serial timeout	126
4.6.35	set prompt	127

4.6.36	show ethernet-ip	127
4.6.37	show network	128
4.6.38	show network mgmt-access	129
4.6.39	show profinetio	130
4.6.40	show serial	131
4.6.41	show snmp-access	131
4.6.42	show snmpcommunity	132
4.6.43	show snmptrap	133
4.6.44	show telnet	134
4.6.45	show telnetcon	135
4.6.46	show trapflags	136
4.6.47	snmp-access global	137
4.6.48	snmp-access version	138
4.6.49	snmp-access version v3-encryption	138
4.6.50	snmp-server	139
4.6.51	snmp-server community	140
4.6.52	snmp-server contact	141
4.6.53	snmp-server community ipaddr	142
4.6.54	snmp-server community ipmask	143
4.6.55	snmp-server community mode	144
4.6.56	snmp-server community ro	145
4.6.57	snmp-server community rw	145
4.6.58	snmp-server location	145
4.6.59	snmp-server sysname	146
4.6.60	snmp-server enable traps	146
4.6.61	snmp-server enable traps chassis	147
4.6.62	snmp-server enable traps l2redundancy	148
4.6.63	snmp-server enable traps linkmode	149
4.6.64	snmp-server enable traps multiusers	150
4.6.65	snmp-server enable traps port-sec	151
4.6.66	snmp-server enable traps stpmode	152
4.6.67	snmptrap	153
4.6.68	snmptrap ipaddr	154
4.6.69	snmptrap mode	155
4.6.70	snmptrap snmpversion	156
4.6.71	telnetcon maxsessions	157
4.6.72	telnetcon timeout	158
4.7	Syslog Commands	159
4.7.1	logging buffered	159
4.7.2	logging buffered wrap	160

4.7.3	logging cli-command	161
4.7.4	logging console	162
4.7.5	logging host	163
4.7.6	logging host reconfigure	164
4.7.7	logging host remove	164
4.7.8	logging snmp-requests get operation	164
4.7.9	logging snmp-requests set operation	165
4.7.10	logging snmp-requests get severity	165
4.7.11	logging snmp-requests set severity	166
4.7.12	logging syslog	167
4.7.13	logging syslog port	167
4.8	Scripting Commands	168
4.8.1	script apply	168
4.8.2	script delete	169
4.8.3	script list	169
4.8.4	script show	170
4.8.5	script validate	170
4.9	Device Configuration Commands	171
4.9.1	addport	171
4.9.2	adminmode	172
4.9.3	auto-negotiate	173
4.9.4	cable-crossing	174
4.9.5	auto-negotiate all	175
4.9.6	media-module remove	175
4.9.7	deleteport	176
4.9.8	deleteport all	176
4.9.9	macfilter	177
4.9.10	macfilter adddest	178
4.9.11	macfilter adddest all	179
4.9.12	monitor session <session-id>	180
4.9.13	monitor session <session-id> mode	181
4.9.14	monitor session <session-id> source/destination	182
4.9.15	link-aggregation	183
4.9.16	link-aggregation adminmode	184
4.9.17	link-aggregation linktrap	185
4.9.18	link-aggregation name	186
4.9.19	rmon-alarm add	186
4.9.20	rmon-alarm delete	187
4.9.21	rmon-alarm enable	187
4.9.22	rmon-alarm disable	188

4.9.23rmon-alarm modify mib-variable	188
4.9.24rmon-alarm modify thresholds	189
4.9.25rmon-alarm modify interval	189
4.9.26rmon-alarm modify sample-type	190
4.9.27rmon-alarm modify startup-alarm	190
4.9.28rmon-alarm modify rising-event	191
4.9.29rmon-alarm modify falling-event	191
4.9.30set garp timer join	192
4.9.31set garp timer leave	193
4.9.32set garp timer leaveall	194
4.9.33set gmrp adminmode	195
4.9.34set gmrp interfacemode	196
4.9.35set gmrp interfacemode	197
4.9.36set gmrp forward-all-groups	198
4.9.37set igmp	199
4.9.38set igmp	200
4.9.39set igmp aging-time-unknown	201
4.9.40set igmp automatic-mode	201
4.9.41set igmp forward-all	202
4.9.42set igmp forward-unknown	203
4.9.43set igmp static-query-port	204
4.9.44set igmp groupmembershipinterval	205
4.9.45set igmp interfacemode	206
4.9.46set igmp lookup-interval-unknown	207
4.9.47set igmp lookup-resp-time-unknown	207
4.9.48set igmp maxresponse	208
4.9.49set igmp querier max-response-time	209
4.9.50set igmp querier protocol-version	209
4.9.51set igmp querier status	210
4.9.52set igmp querier tx-interval	210
4.9.53set igmp query-ports-to-filter	211
4.9.54selftest ramtest	211
4.9.55selftest reboot-on-error	212
4.9.56show garp	212
4.9.57show gmrp configuration	213
4.9.58show igmpsnooping	214
4.9.59show mac-filter-table gmrp	216
4.9.60show mac-filter-table igmpsnooping	217
4.9.61show mac-filter-table multicast	218
4.9.62show mac-filter-table static	219
4.9.63show mac-filter-table staticfiltering	220



4.9.64	show mac-filter-table stats	221
4.9.65	show monitor session	222
4.9.66	show port	223
4.9.67	show link-aggregation	224
4.9.68	show rmon-alarm	226
4.9.69	show selftest	226
4.9.70	show storm-control	227
4.9.71	show storm-control limiters port	228
4.9.72	show vlan	228
4.9.73	show vlan brief	230
4.9.74	show vlan port	231
4.9.75	show voice vlan	232
4.9.76	show voice vlan interface	233
4.9.77	shutdown	234
4.9.78	shutdown all	235
4.9.79	snmp trap link-status	236
4.9.80	snmp trap link-status all	237
4.9.81	spanning-tree bpdumigrationcheck	238
4.9.82	speed	239
4.9.83	storm-control broadcast	240
4.9.84	storm-control egress-limiting	240
4.9.85	storm-control ingress-limiting	241
4.9.86	storm-control ingress-mode	241
4.9.87	storm-control broadcast (port-related)	241
4.9.88	storm-control egress-limit	242
4.9.89	storm-control ingress-limit	242
4.9.90	storm-control ingress-mode	242
4.9.91	storm-control flowcontrol	243
4.9.92	storm-control flowcontrol per port	244
4.9.93	vlan	245
4.9.94	vlan0-transparent-mode	246
4.9.95	vlan acceptframe	247
4.9.96	vlan database	248
4.9.97	vlan ingressfilter	248
4.9.98	vlan name	249
4.9.99	vlan participation	250
4.9.100	vlan participation all	251
4.9.101	vlan port acceptframe all	252
4.9.102	vlan port ingressfilter all	253
4.9.103	vlan port pvid all	254
4.9.104	vlan port tagging all	255

4.9.105	vlan pvid	256
4.9.106	vlan tagging	257
4.9.107	voice vlan (Global Config Mode)	258
4.9.108	voice vlan <id>	259
4.9.109	voice vlan dot1p	260
4.9.110	voice vlan none	260
4.9.111	voice vlan untagged	261
4.9.112	voice vlan auth	261
4.10	User Account Management Commands	263
4.10.1	disconnect	263
4.10.2	show loginsession	264
4.10.3	show users	265
4.10.4	users defaultlogin	266
4.10.5	users login <user>	267
4.10.6	users access	268
4.10.7	users name	269
4.10.8	users passwd	270
4.10.9	users snmpv3 accessmode	271
4.10.10	users snmpv3 authentication	272
4.10.11	users snmpv3 encryption	273
4.11	System Utilities	275
4.11.1	address-conflict	275
4.11.2	boot skip-aca-on-boot	276
4.11.3	show boot skip-aca-on-boot	276
4.11.4	cablestatus	277
4.11.5	clear eventlog	277
4.11.6	traceroute	278
4.11.7	clear arp-table-switch	278
4.11.8	clear config	279
4.11.9	clear config factory	279
4.11.10	clear counters	279
4.11.11	clear hiper-ring	280
4.11.12	clear igmpsnooping	280
4.11.13	clear mac-addr-table	281
4.11.14	clear pass	281
4.11.15	clear link-aggregation	282
4.11.16	clear signal-contact	282
4.11.17	clear traplog	283
4.11.18	clear ring-coupling	283
4.11.19	clear vlan	284

4.11.20	config-watchdog	284
4.11.21	copy	285
4.11.22	device-status connection-error	292
4.11.23	device-status monitor	293
4.11.24	logout	294
4.11.25	ping	294
4.11.26	signal-contact connection-error	295
4.11.27	signal-contact	295
4.11.28	temperature	297
4.11.29	reboot	298
4.11.30	show reboot	298
4.11.31	reload	299
4.11.32	show reload	300
4.12	LLDP - Link Layer Discovery Protocol	301
4.12.1	show lldp	301
4.12.2	show lldp config	301
4.12.3	show lldp config chassis	302
4.12.4	show lldp config chassis admin-state	302
4.12.5	show lldp config chassis notification-interval	303
4.12.6	show lldp config chassis re-init-delay	303
4.12.7	show lldp config chassis tx-delay	304
4.12.8	show lldp config chassis tx-hold-mult	304
4.12.9	show lldp config chassis tx-interval	304
4.12.10	show lldp config port	305
4.12.11	show lldp config port tlv	306
4.12.12	show lldp med	307
4.12.13	show lldp med interface	308
4.12.14	show lldp med local-device detail	309
4.12.15	show lldp med remote-device	309
4.12.16	show lldp med remote-device detail	310
4.12.17	show lldp remote-data	310
4.12.18	lldp	312
4.12.19	lldp config chassis admin-state	313
4.12.20	lldp config chassis notification-interval	314
4.12.21	lldp config chassis re-init-delay	314
4.12.22	lldp config chassis tx-delay	315
4.12.23	lldp config chassis tx-hold-mult	315
4.12.24	lldp chassis tx-interval	316
4.12.25	clear lldp config all	316
4.12.26	lldp admin-state	317

4.12.27	lldp fdb-mode	317
4.12.28	lldp hm-mode	318
4.12.29	lldp max-neighbors	318
4.12.30	lldp med	318
4.12.31	lldp med all	319
4.12.32	lldp med confignotification	320
4.12.33	lldp med confignotification all	320
4.12.34	lldp med faststartrepeatcount	321
4.12.35	lldp med transmit-tlv	322
4.12.36	lldp med transmit-tlv all	323
4.12.37	lldp notification	324
4.12.38	lldp tlv link-aggregation	324
4.12.39	lldp tlv mac-phy-config-state	324
4.12.40	lldp tlv max-frame-size	325
4.12.41	lldp tlv mgmt-addr	325
4.12.42	lldp tlv pnio	325
4.12.43	lldp tlv pnio-alias	326
4.12.44	lldp tlv pnio-mrp	326
4.12.45	lldp tlv port-desc	326
4.12.46	lldp tlv port-vlan	327
4.12.47	lldp tlv gmrp	327
4.12.48	lldp tlv igmp	327
4.12.49	lldp tlv portsec	328
4.12.50	lldp tlv ptp	328
4.12.51	lldp tlv protocol	328
4.12.52	lldp tlv sys-cap	329
4.12.53	lldp tlv sys-desc	329
4.12.54	lldp tlv sys-name	329
4.12.55	lldp tlv vlan-name	330
4.12.56	name	330
4.13	SNTP - Simple Network Time Protocol	331
4.13.1	show sntp	331
4.13.2	show sntp anycast	332
4.13.3	show sntp client	333
4.13.4	show sntp operation	334
4.13.5	show sntp server	334
4.13.6	show sntp status	335
4.13.7	show sntp time	336
4.13.8	no sntp	336
4.13.9	sntp anycast address	337

4.13.10	sntp anycast transmit-interval	337
4.13.11	sntp anycast vlan	338
4.13.12	sntp client accept-broadcast	338
4.13.13	sntp client disable-after-sync	339
4.13.14	sntp client offset	339
4.13.15	sntp client request-interval	340
4.13.16	no sntp client server	340
4.13.17	sntp client server primary	340
4.13.18	sntp client server secondary	341
4.13.19	sntp client threshold	342
4.13.20	sntp operation	343
4.13.21	sntp server disable-if-local	344
4.13.22	sntp time system	344
4.14	PTP - Precision Time Protocol	345
4.14.1	show ptp	345
4.14.2	show ptp configuration	346
4.14.3	show ptp operation	346
4.14.4	show ptp port	347
4.14.5	show ptp status	348
4.14.6	ptp clock-mode	349
4.14.7	ptp operation	350
4.14.8	ptp sync-lower-bound	351
4.14.9	ptp sync-upper-bound	351
4.14.10	ptp v1 preferred-master	352
4.14.11	ptp v1 re-initialize	352
4.14.12	ptp v1 subdomain-name	353
4.14.13	ptp v1 sync-interval	354
4.14.14	ptp v2bc priority1	355
4.14.15	ptp v2bc priority2	355
4.14.16	ptp v2bc domain	356
4.14.17	ptp v2bc utc-offset	356
4.14.18	ptp v2bc utc-offset-valid	356
4.14.19	ptp v2bc vlan	357
4.14.20	ptp v2bc vlan-priority	357
4.14.21	ptp v1 burst	357
4.14.22	ptp v1 operation	358
4.14.23	ptp v2bc operation	359
4.14.24	ptp v2bc announce-interval	359
4.14.25	ptp v2bc announce-timeout	360
4.14.26	ptp v2bc sync-interval	360

4.14.27	ptp v2bc delay-mechanism	360
4.14.28	ptp v2bc pdelay-interval	361
4.14.29	ptp v2bc network-protocol	361
4.14.30	ptp v2bc v1-compatibility-mode	361
4.14.31	ptp v2bc asymmetry	362
4.14.32	ptp v2tc asymmetry	362
4.14.33	ptp v2tc delay-mechanism	362
4.14.34	ptp v2tc management	363
4.14.35	ptp v2tc multi-domain-mode	363
4.14.36	ptp v2tc network-protocol	364
4.14.37	ptp v2tc operation	364
4.14.38	ptp v2tc pdelay-interval	365
4.14.39	ptp v2tc primary-domain	365
4.14.40	ptp v2tc syntonization	365
4.14.41	ptp v2tc vlan	366
4.14.42	ptp v2tc vlan-priority	366
4.14.43	ptp v2tc sync-local-clock	367
4.15	PoE - Power over Ethernet	369
4.15.1	show inlinepower	369
4.15.2	show inlinepower port	369
4.15.3	inlinepower (Global Config)	370
4.15.4	inlinepower (Interface Config)	371
4.15.5	clear inlinepower	371
4.16	PoE+ - Power over Ethernet Plus	373
4.16.1	show inlinepower slot	373
4.16.2	inlinepower budget slot	374
4.16.3	inlinepower threshold slot	375
4.16.4	inlinepower trap slot	375
4.17	Port monitor	377
4.17.1	show port-monitor	378
4.17.2	show port-monitor <slot/port>	379
4.17.3	show port-monitor brief	380
4.17.4	show port-monitor crc-fragment	381
4.17.5	show port-monitor link-flap	381
4.17.6	port-monitor (Global Config)	382
4.17.7	port-monitor (Interface Config)	382
4.17.8	port-monitor condition link-flap (Global Config)	383
4.17.9	port-monitor condition link-flap (Interface Config)	383
4.17.10	port-monitor condition crc-fragment (Global Config)	384

4.17.11	port-monitor condition crc-fragment (Interface Config)	385
4.17.12	port-monitor action	385
5	CLI Commands: Switching	387
5.1	Spanning Tree Commands	389
5.1.1	show spanning-tree	389
5.1.2	show spanning-tree interface	391
5.1.3	show spanning-tree mst detailed	392
5.1.4	show spanning-tree mst port detailed	394
5.1.5	show spanning-tree mst port summary	397
5.1.6	show spanning-tree mst summary	398
5.1.7	show spanning-tree summary	399
5.1.8	show spanning-tree vlan	400
5.1.9	spanning-tree	401
5.1.10	spanning-tree auto-edgeport	402
5.1.11	spanning-tree bpduguard	403
5.1.12	spanning-tree configuration name	404
5.1.13	spanning-tree configuration revision	405
5.1.14	spanning-tree edgeport	406
5.1.15	spanning-tree forceversion	407
5.1.16	spanning-tree forward-time	408
5.1.17	spanning-tree guard loop	409
5.1.18	spanning-tree guard none	410
5.1.19	spanning-tree guard root	411
5.1.20	spanning-tree hello-time	412
5.1.21	spanning-tree hold-count	413
5.1.22	spanning-tree max-age	414
5.1.23	spanning-tree max-hops	415
5.1.24	spanning-tree mst	416
5.1.25	spanning-tree mst priority	418
5.1.26	spanning-tree mst vlan	419
5.1.27	spanning-tree mst instance	420
5.1.28	spanning-tree port mode	421
5.1.29	spanning-tree port mode all	422
5.1.30	spanning-tree stp-mrp-mode	423
5.1.31	spanning-tree tcnguard	424
5.2	MRP	425
5.2.1	show mrp	425
5.2.2	show mrp current-domain	426
5.2.3	mrp current-domain	428

5.2.4	mrp delete-domain	429
5.2.5	mrp new-domain	430
5.2.6	arc	431
5.2.7	show arc	432
5.3	HIPER-Ring	435
5.3.1	show hiper-ring	436
5.3.2	hiper-ring	437
5.3.3	hiper-ring mode	438
5.3.4	hiper-ring port primary	438
5.3.5	hiper-ring port secondary	439
5.3.6	hiper-ring recovery-delay	439
5.4	Fast-HIPER-Ring	441
5.4.1	show fast-hiper-ring (MACH 1000, RSR20/RSR30)	442
5.4.2	show fast-hiper-ring current-id (MACH 1000, RSR20/RSR30)	443
5.4.3	fast-hiper-ring	444
5.5	Redundant Coupling	447
5.5.1	show ring-coupling	448
5.5.2	ring-coupling	450
5.5.3	ring-coupling config	451
5.5.4	ring-coupling net-coupling	452
5.5.5	ring-coupling operation	452
5.5.6	ring-coupling port	453
5.5.7	ring-coupling redundancy-mode	453
5.6	Port Security	455
5.6.1	show port-sec mode	455
5.6.2	show port-sec port	455
5.6.3	port-sec mode	456
5.6.4	port-sec action	456
5.6.5	port-sec allowed-ip	457
5.6.6	port-sec allowed-ip add	457
5.6.7	port-sec allowed-ip remove	458
5.6.8	port-sec allowed-mac	458
5.6.9	port-sec allowed-mac add	459
5.6.10	port-sec allowed-mac remove	459
5.6.11	clear port-sec	460
5.7	DHCP Relay Commands	461
5.7.1	show dhcp-relay	461
5.7.2	dhcp-relay	462



5.7.3	dhcp-relay	463
5.8	DHCP Server Commands	465
5.8.1	DHCP server configuration example	466
5.8.2	show dhcp-server	467
5.8.3	show dhcp-server operation	467
5.8.4	show dhcp-server port	468
5.8.5	show dhcp-server pool	468
5.8.6	dhcp-server operation	469
5.8.7	dhcp-server pool add <id>	469
5.8.8	dhcp-server pool modify <id> mode	470
5.8.9	dhcp-server pool modify <id> option	472
5.8.10	dhcp-server pool modify leasetime	473
5.8.11	dhcp-server pool modify <id> hirschmann-device	473
5.8.12	dhcp-server pool enable	474
5.8.13	dhcp-server pool disable	474
5.8.14	dhcp-server pool delete	474
5.9	Sub-Ring Commands	475
5.9.1	show sub-ring	475
5.9.2	sub-ring <id> mode	477
5.9.3	sub-ring <id> operation	478
5.9.4	sub-ring <id> protocol	478
5.9.5	sub-ring <id> port	479
5.9.6	sub-ring <id> ring-name	479
5.9.7	sub-ring <id> vlan	480
5.9.8	sub-ring <id> mrp-domainID	481
5.9.9	sub-ring delete-ring	482
5.9.10	sub-ring new-ring	482
6	CLI Commands: Security	483
6.1	Security Commands	485
6.1.1	authentication login	485
6.1.2	authorization network radius	487
6.1.3	clear dot1x statistics	487
6.1.4	clear radius statistics	488
6.1.5	dot1x defaultlogin	488
6.1.6	dot1x dynamic-vlan enable	489
6.1.7	dot1x guest-vlan	490
6.1.8	dot1x initialize	491
6.1.9	dot1x login	491

6.1.10	dot1x mac-auth-bypass	492
6.1.11	dot1x max-req	493
6.1.12	dot1x max-users	494
6.1.13	dot1x port-control	495
6.1.14	dot1x port-control all	496
6.1.15	dot1x re-authenticate	497
6.1.16	dot1x re-authentication	497
6.1.17	dot1x safe-vlan	498
6.1.18	dot1x system-auth-control	499
6.1.19	dot1x timeout	500
6.1.20	dot1x timeout guest-vlan-period	502
6.1.21	dot1x unauthenticated-vlan	503
6.1.22	dot1x user	504
6.1.23	radius accounting mode	505
6.1.24	radius server host	506
6.1.25	radius server key	507
6.1.26	radius server msgauth	507
6.1.27	radius server primary	508
6.1.28	radius server retransmit	509
6.1.29	radius server timeout	510
6.1.30	show radius accounting	511
6.1.31	show authentication	513
6.1.32	show authentication users	514
6.1.33	show dot1x	515
6.1.34	show dot1x users	520
6.1.35	show dot1x clients	521
6.1.36	show radius	522
6.1.37	show radius statistics	523
6.1.38	show users authentication	525
6.1.39	users login	526
6.2	HTTP Commands	527
6.2.1	ip http secure-port	527
6.2.2	ip http secure-protocol	528
6.2.3	ip http server	529
6.2.4	show ip http	530
6.2.5	ip https server	531
6.2.6	ip https port	532
6.2.7	ip https certgen	533
6.2.8	show ip https	533

7	Appendix- VLAN Example	535
7.1	SOLUTION 1	537
7.2	SOLUTION 2	539
8	Glossary	541
9	Index	559
10	Further support	567



# About this Manual

The "GUI" reference manual contains detailed information on using the graphical user interface (web-based interface) to operate the individual functions of the device.

The "Command Line Interface" reference manual contains detailed information on using the Command Line Interface to operate the individual functions of the device.

The "Installation" user manual contains a device description, safety instructions, a description of the display, and the other information that you need to install the device.

The "Basic Configuration" user manual contains the information you need to start operating the device. It takes you step by step from the first startup operation through to the basic settings for operation in your environment.

The "Redundancy Configuration" user manual contains the information you need to select a suitable redundancy procedure and configure that procedure.

The "Industry Protocols" user manual describes how the device is connected by means of a communication protocol commonly used in the industry, such as EtherNet/IP or PROFINET IO.

The HiVision Network Management Software provides you with additional options for smooth configuration and monitoring:

- D Simultaneous configuration of multiple devices
- D Graphic interface with network layout
- D Auto-topology recognition
- D Event log
- D Event handling
- D Client/server structure
- D Browser interface
- D ActiveX control for SCADA integration
- D SNMP/OPC gateway.

## Maintenace

Hirschmann are continually working on improving and developing their software. You should regularly check whether there is a new version of the software that provides you with additional benefits. You will find software information and downloads on the product pages of the Hirschmann website.

# 1 Command Structure

The Command Line Interface (CLI) syntax, conventions and terminology are described in this section. Each CLI command is illustrated using the structure outlined below.

## 1.1 Format

Commands are followed by values, parameters, or both.

### U Example 1

```
network parms <ipaddr> <netmask> [gateway]
```

D network parms  
is the command name.

D <ipaddr> <netmask>  
are the required values for the command.

D [gateway]  
is the optional value for the command.

### U Example 2

```
snmp-server location <loc>
```

D snmp-server location  
is the command name.

D <loc>  
is the required parameter for the command.

### U Example 3

```
clear vlan
```

D clear vlan  
is the command name.

### 1.1.1 Command

The text in courier font is to be typed exactly as shown.



## 1.1.2 Parameters

Parameters are order dependent.

Parameters may be mandatory values, optional values, choices, or a combination.

- D `<parameter>`. The `<>` angle brackets indicate that a mandatory parameter is to be entered in place of the brackets and text inside them.
- D `[parameter]`. The `[]` square brackets indicate that an optional parameter may be entered in place of the brackets and text inside them.
- D `choice1 | choice2`. The `|` indicates that only one of the parameters should be entered.
- D The `{}` curly braces indicate that a parameter must be chosen from the list of choices.

## 1.1.3 Values

### **macaddr**

The MAC address format is six hexadecimal numbers separated by colons, for example 00:06:29:32:81:40.

### **areaid**

Area IDs may be entered in dotted-decimal notation (for example, 0.0.0.1). An area ID of 0.0.0.0 is reserved for the backbone. Area IDs have the same form as IP addresses, but are distinct from IP addresses. The IP network address of the sub-netted network may be used for the area ID.

### **slot/port**

Valid slot and port number separated by forward slashes. For example, 1/1 represents slot number 1 and port number 1.

**logical slot/port**

Logical slot and port number. This is applicable in the case of a link-aggregation (LAG) and vlan router interfaces (9/x). The operator can use the logical slot/port to configure the link-aggregation.

### 1.1.4 Conventions

Network addresses are used to define a link to a remote host, workstation or network. Network addresses are shown using the following syntax:

Address Type	Format	Range
ipaddr	192.168.11.110	0.0.0.0 to 255.255.255.255 (decimal)
macaddr	A7:C9:89:DD:A9:B3	hexadecimal digit pairs

*Table 1: Network Address Syntax*

Double quotation marks such as "System Name with Spaces" set off user defined strings. If the operator wishes to use spaces as part of a name parameter then it must be enclosed in double quotation marks.

Empty strings ("" ) are not valid user defined strings.

Command completion finishes spelling the command when enough letters of a command are typed to uniquely identify the command word. The command may be executed by typing <enter> (command abbreviation) or the command word may be completed by typing the <tab> or <space bar> (command completion).

The value 'Err' designates that the requested value was not internally accessible.

The value of '-----' designates that the value is unknown.

### 1.1.5 Annotations

The CLI allows the user to type single-line annotations at the command prompt for use when writing test or configuration scripts and for better readability. The exclamation point (!) character flags the beginning of a comment. The comment flag character can begin a word anywhere on the command line and all input following this character is ignored. Any command line that begins with the character '!' is recognized as a comment line and ignored by the parser.

Some examples are provided below:

```
! Script file for setting the CLI prompt
set prompt example-switch
! End of the script file
```

## 1.1.6 Special keys

The following list of special keys may be helpful to enter command lines.

BS	delete previous character
Ctrl-A	go to beginning of line
Ctrl-E	go to end of line
Ctrl-F	go forward one character
Ctrl-B	go backward one character
Ctrl-D	delete current character
Ctrl-H	display command history or retrieve a command
Ctrl-U, X	delete to beginning of line
Ctrl-K	delete to end of line
Ctrl-W	delete previous word
Ctrl-T	transpose previous character
Ctrl-P	go to previous line in history buffer
Ctrl-R	rewrites or pastes the line
Ctrl-N	go to next line in history buffer
Ctrl-Y	print last deleted character
Ctrl-Q	enables serial flow
Ctrl-S	disables serial flow
Ctrl-Z	return to root command prompt
Tab, <SPACE>	command-line completion
Exit	go to next lower command prompt
?	list choices

### 1.1.7 Special characters in scripts

Some of the configuration parameters are strings that can contain special characters. When the switch creates a script from the running configuration (by use of the command `#show running-config <scriptname.cli>`), these special characters are written to the script with a so-called escape character preceding them. This ensures that when applying the script, these characters are regarded as a normal part of the configuration parameter, not having the special meaning they usually have.

Character (plain)	Meaning, when entered in the CLI
!	Begin of a comment, ! and the rest of the line will be ignored
"	Begin or end of a string that may contain space characters
'	Begin or end of a string that may contain space characters
?	Shows possible command keywords or parameters
\	The backslash is used as an escape character to mask characters that normally have a special meaning

*Tab. 2: Special characters*

Character (escaped)	Meaning, when entered in the CLI
\!	! becomes part of the string
\"	" becomes part of the string
\'	' becomes part of the string
\?	? becomes part of the string
\\	\ becomes part of the string

*Tab. 3: Special characters escaped*

The commands with strings that may contain these special characters are listed below.

**Note:** Not every string is allowed to contain special characters. The string that is output with the escape characters (if necessary) is shown as "...".

Command	Note
!System Description "..."	"At the beginning of the script
!System Version "..."	"At the beginning of the script

*Tab. 4: Commands in Privileged Exec mode*

Command	Note
snmp-server location "..."	
snmp-server contact "..."	
snmp-server community "..."	
snmp-server community ipaddr <ip> "..."	
snmp-server community ipmask <ip> "..."	
snmp-server community ro "..."	
snmp-server community rw "..."	
no snmp-server community mode "..."	
no snmp-server community "..."	
link-aggregation "..."	
spanning-tree configuration name "..."	
ptp subdomain-name "..."	

*Tab. 5: Commands in Global Config mode*

Command	Note
name "..."	

*Tab. 6: Commands in Interface Config mode*

Command	Note
vlan name <n> "..."	

*Tab. 7: Commands in VLAN Database mode*

When a device creates a script, a human-readable header is included that lists the special characters and the escape characters:

```
!Parameter string escape handling \, 1
!Characters to be preceded with escape char (\): \, !, ", ', ?
```

### 1.1.8 Secrets in scripts

A configuration may include secrets (e. g., passwords). When creating a script, these secrets are written to it in a scrambled form, not in clear text. These secrets may be up to 31 characters long. The format for a scrambled secret is: ":v1:<scrambled secret>:" (without the quotes ("), they were added for readability). v1 denotes the scrambling method (v1 in this case), the value of the scrambled secret is a 64-digit hex string.

The following commands produce scrambled secrets (if necessary):

Command	Note
radius server key acct <ip> <password>	
radius server key auth <ip> <password>	
users passwd <username> <password>	
users snmpv3 encryption <username> des <password>	

*Tab. 8: Commands in Global Config mode*

Applying or validating a script requires the following conditions for a scrambled secret, else it will be considered invalid (usually only relevant if a script is edited manually):



- D string must not be longer than 64 hex digits
- D string must only contain the digits 0-9 and the characters A-F (or a-f)
- D string length must be even



## 2 Quick Start up

The CLI Quick Start up details procedures to quickly become acquainted with the software.

## 2.1 Quick Starting the Switch

- D Read the device Installation Guide for the connectivity procedure. In-band connectivity allows access to the software locally or from a remote workstation. The device must be configured with IP information (IP address, subnet mask, and default gateway).
- D Turn the Power on.
- D Allow the device to load the software until the login prompt appears. The device's initial state is called the default mode.
- D When the prompt asks for operator login, execute the following steps:
  - D Type the word `admin` in the login area. Since a number of the Quick Setup commands require administrator account rights, we recommend logging into an administrator account. Press the enter key.
  - D Enter the state on delivery password `private`.
  - D Press the enter key
  - D The CLI User EXEC prompt will be displayed.  
User EXEC prompt:  
`(Hirschmann Product) >`
  - D Use "enable" to switch to the Privileged EXEC mode from User EXEC.  
Privileged EXEC prompt:  
`(Hirschmann Product) #`
  - D Use "configure" to switch to the Global Config mode from Privileged EXEC.  
Global Config prompt:  
`(Hirschmann Product) (Config)#`
  - D Use "exit" to return to the previous mode.

## 2.2 System Info and System Setup

This chapter informs you about:

- D Quick Start up Software Version Information
- D Quick Start up Physical Port Data
- D Quick Start up User Account Management
- D Quick Start up IP Address
- D Quick Start up Uploading from Switch to Out-of-Band PC (Only XMODEM)
- D Quick Start up Downloading from Out-of-Band PC to Switch (Only XMODEM)
- D Quick Start up Downloading from TFTP Server
- D Quick Start up Factory Defaults

## U Quick Start up Physical Port Data

Command	Details
<code>show port all</code> (in Privileged EXEC)	<p>Displays the Ports</p> <p>slot/port</p> <p>Type - Indicates if the port is a special type of port</p> <p>Admin Mode - Selects the Port Control Administration State</p> <p>Physical Mode - Selects the desired port speed and duplex mode</p> <p>Physical Status - Indicates the port speed and duplex mode</p> <p>Link Status - Indicates whether the link is up or down</p> <p>Link Trap - Determines whether or not to send a trap when link status changes</p> <p>LACP Mode - Displays whether LACP is enabled or disabled on this port.</p>

*Table 9: Quick Start up Physical Port Data*

## U Quick Start up User Account Management

Command	Details
<code>show users</code> (in Privileged EXEC)	<p>Displays all of the users that are allowed to access the switch</p> <p>Access Mode - Shows whether the user is able to change parameters on the switch(Read/Write) or is only able to view them (Read Only).</p> <p>As a factory default, the 'admin' user has Read/Write access and the 'user' user has Read Only access. There can only be one Read/Write user and up to five Read Only users.</p>
<code>show login session</code> (in User EXEC)	Displays all of the login session information

*Table 10: Quick Start up User Account Management*

Command	Details
<pre>users passwd &lt;user- name&gt;</pre> (in Global Config)	<p>Allows the user to set passwords or change passwords needed to login</p> <p>A prompt will appear after the command is entered requesting the users old password. In the absence of an old password leave the area blank. The operator must press enter to execute the command.</p> <p>The system then prompts the user for a new password then a prompt to confirm the new password. If the new password and the confirmed password match a message will be displayed.</p> <p>User password should not be more than eight characters in length.</p> <p>Make sure, that the passwords of the users differ from each other. If two or more users try to choose the same password, the CLI will display an error message.</p>
<pre>copy system:running- config nvram:startup-config</pre> (in Privileged EXEC)	<p>This will save passwords and all other changes to the device.</p> <p>If you do not save the configuration by doing this command, all configurations will be lost when a power cycle is performed on the switch or when the switch is reset.</p>
<pre>logout</pre> (in User EXEC and Privileged EXEC)	<p>Logs the user out of the switch</p>

*Table 10: Quick Start up User Account Management*

## U Quick Start up IP Address

To view the network parameters the operator can access the device by the following three methods.

- D Simple Network Management Protocol - SNMP
- D Telnet
- D Web Browser

**Note:** After configuring the network parameters it is advisable to execute the command `'copy system:running-config nvram:startup-config'` to ensure that the configurations are not lost.

Command	Details
<pre>show network (in User EXEC)</pre>	<p>Displays the Network Configurations</p> <p>IP Address - IP Address of the switch Default IP is 0.0.0.0</p> <p>Subnet Mask - IP Subnet Mask for the switch Default is 0.0.0.0</p> <p>Default Gateway - The default Gateway for this switch Default value is 0.0.0.0</p> <p>Burned in MAC Address - The Burned in MAC Address used for in-band connectivity</p> <p>Network Configurations Protocol (BOOTP/DHCP) - Indicates which network protocol is being used Default is DHCP</p> <p>Network Configurations Protocol HiDiscovery - Indicates the status of the HiDiscovery protocol. Default is read-write</p> <p>Management VLAN Id - Specifies VLAN id</p> <p>Web Mode - Indicates whether HTTP/Web is enabled.</p> <p>JavaScript Mode - Indicates whether java mode is enabled. When the user accesses the switch's graphical user interface (web interface) and JavaScript Mode is enabled, the switch's web server will deliver a HTML page that contains JavaScript. Some browsers do not support JavaScript. In this case, a HTML page without JavaScript is necessary. In this case, set JavaScript Mode to disabled. Default: enabled.</p>
<pre>network parms &lt;ipaddr&gt; &lt;net- mask&gt; [gateway] (in Privileged EXEC)</pre>	<p>Sets the IP Address, subnet mask and gateway of the router. The IP Address and the gateway must be on the same subnet.</p> <p>IP Address range from 0.0.0.0 to 255.255.255.255</p>

*Table 11: Quick Start up IP Address*



Command	Details
	Subnet Mask range from 0.0.0.0 to 255.255.255.255
	Gateway Address range from 0.0.0.0 to 255.255.255.255

*Table 11: Quick Start up IP Address*

## U Quick Start up Downloading from TFTP Server

Before starting a TFTP server download, the operator must complete the Quick Start up for the IP Address.

Command	Details
<code>copy &lt;url&gt; {nvram:startup-config   system:image}</code>	Sets the destination (download) datatype to be an image (system:image) or a configuration file (nvram:startup-config). The URL must be specified as: <code>ftp://ipAddr/filepath/fileName</code> . The nvram:startup-config option downloads the configuration file using tftp and system:image option downloads the code file.

*Table 12: Quick Start up Downloading from TFTP Server*

## U Quick Start up Factory Defaults

Command	Details
<code>clear config</code> (in Privileged EXEC Mode)	Enter yes when the prompt pops up to clear all the configurations made to the switch.
<code>copy system:running-config nvram:startup-config</code>	Enter yes when the prompt pops up that asks if you want to save the configurations made to the switch.
<code>reboot</code> (or cold boot the switch) (in Privileged EXEC Mode)	Enter yes when the prompt pops up that asks if you want to reset the system. This is the users choice either reset the switch or cold boot the switch, both work effectively.

*Table 13: Quick Start up Factory Defaults*



## 3 Mode-based CLI

The CLI groups all the commands in appropriate modes according to the nature of the command. A sample of the CLI command modes are described below. Each of the command modes support specific software commands.

- D User Exec Mode
- D Privileged Exec Mode
- D Global Config Mode
- D Vlan Mode
- D Interface Config Mode
- D Line Config Mode

The Command Mode table captures the command modes, the prompts visible in that mode and the exit method from that mode.

Command Mode	Access Method	Prompt	Exit or Access Next Mode
User Exec Mode	This is the first level of access. Perform basic tasks and list system information	(Hirschmann Product)>	Enter Logout command
Privileged Exec Mode	From the User Exec Mode, enter the enable command	(Hirschmann Product)#	To exit to the User Exec mode, enter exit or press Ctrl-Z.
VLAN Mode	From the Privileged User Exec mode, enter the vlan database command	(Hirschmann Product) (Vlan) #	To exit to the Privileged Exec mode, enter the exit command, or press Ctrl-Z to switch to User Exec mode.
Global Config Mode	From the Privileged Exec mode, enter the configure command	(Hirschmann Product) (Config)#	To exit to the Privileged Exec mode, enter the exit command, or press Ctrl-Z to switch to user exec mode.
Interface Config Mode	From the Global Configuration mode, enter the interface <slot/port> command	(Hirschmann Product) (Interface- "if number")#	To exit to the Global Config mode enter exit. To return to user EXEC mode enter ctrl-Z.
Line Config Mode	From the Global Configuration mode, enter the lineconfig command	(Hirschmann Product) (line) #	To exit to the Global Config mode enter exit. To return to User Exec mode enter ctrl-Z.

*Table 14: Command Mode*

## 3.1 Mode-based Topology

The CLI tree is built on a mode concept where the commands are available according to the interface. Some of the modes are depicted in the following figure.




Fig. 1: Mode-based CLI

## 3.2 Mode-based Command Hierarchy

The CLI is divided into various modes. The Commands in one mode are not available until the operator switches to that particular mode, with the exception of the User Exec mode commands. The User Exec mode commands may also be executed in the Privileged Exec mode.

The commands available to the operator at any point in time depend upon the mode. Entering a question mark (?) at the CLI prompt, displays a list of the available commands and descriptions of the commands.

The CLI provides the following modes:

### User Exec Mode

When the operator logs into the CLI, the User Exec mode is the initial mode. The User Exec mode contains a limited set of commands. The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product)>
```

### Privileged Exec Mode

To have access to the full suite of commands, the operator must enter the Privileged Exec mode. Privileged users authenticated by login are able to enter the Privileged EXEC mode. From Privileged Exec mode, the operator can issue any Exec command, enter the VLAN mode or enter the Global Configuration mode . The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product)#
```

### VLAN Mode

This mode groups all the commands pertaining to VLANs. The command prompt shown at this level is:

```
Command Prompt: (Hirschmann Product)(VLAN)#
```

### Global Config Mode

This mode permits the operator to make modifications to the running configuration. General setup commands are grouped in this mode. From the Global Configuration mode, the operator can enter the System Configuration mode, the Physical Port Configuration mode, the

Interface Configuration mode, or the Protocol Specific modes specified below. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product)(Config)#
```

From the Global Config mode, the operator may enter the following configuration modes:

### Interface Config Mode

Many features are enabled for a particular interface. The Interface commands enable or modify the operation of an interface.

In this mode, a physical port is set up for a specific logical connection operation. The Interface Config mode provides access to the router interface configuration commands. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product)(Interface  
<slot/port>)#
```

The resulting prompt for the interface configuration command entered in the Global Configuration mode is shown below:

```
(Hirschmann Product)(Config)# interface 2/1  
(Hirschmann Product)(Interface 2/1)#
```

### Line Config Mode

This mode allows the operator to configure the console interface. The operator may configure the interface from the directly connected console or the virtual terminal used with Telnet. The command prompt at this level is:

```
Command Prompt: (Hirschmann Product)(Line)#
```

### MAC Access-List Config Mode

Use the MAC Access-List Config mode to create a MAC Access-List and to enter the mode containing Mac Access-List configuration commands.

```
(Hirschmann Product)(Config)# mac-access-list  
extended <name>
```

```
Command Prompt: (Hirschmann Product)(Config mac-  
access-list)#
```

## 3.3 Flow of Operation

This section captures the flow of operation for the CLI:

- D The operator logs into the CLI session and enters the User Exec mode. In the User Exec mode the `(Hirschmann Product)(exec)>` prompt is displayed on the screen.

The parsing process is initiated whenever the operator types a command and presses <ENTER>. The command tree is searched for the command of interest. If the command is not found, the output message indicates where the offending entry begins. For instance, command node A has the command "show spanning-tree" but the operator attempts to execute the command "show arpp brief" then the output message would be  
`(Hirschmann Product)(exec)> show sspanning-tree^.`  
`(Hirschmann Product)%Invalid input detected at '^' marker.` If the operator has given an invalid input parameter in the command, then the message conveys to the operator an invalid input was detected. The layout of the output is depicted below:

```
(Hirschmann Product)(exec) #show sspanning-tree
                               ^
(Hirschmann Product)Invalid input detected at '^' marker.
```

*Fig. 2: Syntax Error Message*

After all the mandatory parameters are entered, any additional parameters entered are treated as optional parameters. If any of the parameters are not recognized a syntax error message will be displayed.

- D After the command is successfully parsed and validated, the control of execution goes to the corresponding CLI callback function.

- D For mandatory parameters, the command tree extends till the mandatory parameters make the leaf of the branch. The callback function is only invoked when all the mandatory parameters are provided. For optional parameters, the command tree extends till the mandatory parameters and the optional parameters make the leaf of the branch. However, the call back function is associated with the node where the mandatory parameters are fetched. The call back function then takes care of the optional parameters.
- D Once the control has reached the callback function, the callback function has complete information about the parameters entered by the operator.



## 3.4 “No” Form of a Command

“No” is a specific form of an existing command and does not represent a new or distinct command. Only the configuration commands are available in the “no” form. The behavior and the support details of the “no” form is captured as part of the mapping sheets.

### 3.4.1 Support for “No” Form

Almost every configuration command has a “no” form. In general, use the no form to reverse the action of a command or reset a value back to the default. For example, the `no shutdown interface` configuration command reverses the shutdown of an interface. Use the command without the keyword “no” to re-enable a disabled feature or to enable a feature that is disabled by default.

### 3.4.2 Behavior of Command Help (“?”)

The “no” form is treated as a specific form of an existing command and does not represent a new or distinct command. However, the behavior of the “?” and help text differ for the “no” form (the help message shows only options that apply to the “no” form).

- D The help message is the same for all forms of the command. The help string may be augmented with details about the “no” form behavior.
- D For the `(no interface?)` and `(no inte?)` cases of the “?”, the options displayed are identical to the case when the “no” token is not specified as in `(interface)` and `(inte?)`.



## 4 CLI Commands: Base

This chapter provides detailed explanation of the Switching commands. The commands are divided into five functional groups:

- D Show commands display switch settings, statistics, and other information.
- D Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.
- D Copy commands transfer or save configuration and informational files to and from the switch.
- D Clear commands clear
  - some  
(e.g. the "clear arp-table-switch" command which clears the agent's ARP table) or
  - all  
(e.g. the "clear config" command which resets the whole configuration to the factory defaults)

This chapter includes the following configuration types:

- D System information and statistics commands
- D Management commands
- D Device configuration commands
- D User account management commands
- D Security commands
- D System utilities
- D Link Layer Discovery Protocol Commands
- D Simple Network Time Protocol Commands
- D Precision Time Protocol Commands
- D Power over Ethernet Commands

## 4.1 System Information and Statistics Commands

### 4.1.1 show address-conflict

This command displays address-conflict settings.

**Format**

```
show address-conflict
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.2 show arp switch

This command displays the Address Resolution Protocol cache of the switch.

**Format**

```
show arp switch
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.3 show bridge address-learning

This command displays the address-learning setting. The setting can be enable or disable.

**Format**

```
show bridge address-learning
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.4 show bridge address-relearn-detect

This command displays the Bridge Address Relearn Detection setting and the Bridge Address Relearn Threshold.

**Format**

```
show bridge address-relearn-detect
```

**Mode**

```
Privileged EXEC and User EXEC
```

**Bridge Address Relearn Detection**

Setting can be enable or disable.

**Bridge Address Relearn Threshold**

The threshold can be 1 to 1024.

### 4.1.5 show bridge aging-time

This command displays the timeout for address aging.

**Format**

```
show bridge aging-time
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.6 show bridge duplex-mismatch-detect

This command displays the Bridge Duplex Mismatch Detection setting (Enabled or Disabled).

**Format**

```
show bridge duplex-mismatch-detect
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.7 show bridge fast-link-detection

This command displays the Bridge Fast Link Detection setting.

**Format**

```
show bridge fast-link-detection
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.8 show bridge framesize

This command displays the maximum size of frame (packet size) setting.

**Format**

```
show bridge framesize
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.9 show bridge vlan-learning

This command displays the bridge vlan-learning mode.

**Format**

```
show bridge vlan-learning
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.1.10 bridge framesize

Activation of long frames. Configure 1522 or 1632<sup>1)</sup> as maximum size of frame (packet size). Default: 1522.

**Format**

```
bridge framesize {1522|16321)}
```

**Mode**

```
Global Config
```

**bridge framesize 1522**

Configure 1522 as maximum size of frame.

**bridge framesize 1632** <sup>1)</sup>

Configure 1632 <sup>1)</sup> as maximum size of frame.

<sup>1)</sup> On MACH 4000, MACH100, MACH 1000 and PowerMICE: 1552

### 4.1.11 show config-watchdog

Activating the watchdog enables you to return automatically to the last configuration after a set time period has elapsed. This gives you back your access to the Switch.

**Format**

```
show config-watchdog
```

**Mode**

```
Privileged EXEC and User EXEC
```



## 4.1.12 show device-status

The signal device status is for displaying

- D the monitoring functions of the switch,
- D the device status trap setting.

### Format

```
show device-status  
[monitor|state|trap]
```

### Mode

Privileged EXEC and User EXEC

### Device status monitor

Displays the possible monitored events and which of them are monitored:

- the detected failure of at least one of the supply voltages.
- the removal of the ACA
- the removal of a media module
- the temperature limits
- the defective link status of at least one port. With the switch, the indication of link status can be masked by the management for each port. Link status is not monitored in the delivery condition.
- the loss of Redundancy guarantee.

Ring/network coupling:

- The following conditions are reported in Stand-by mode:
- interrupted control line
- partner device running in Stand-by mode.

HIPER-Ring:

- The following condition is reported in RM mode additionally:
- Ring redundancy guaranteed. Ring redundancy is not monitored in the delivery condition.

### Device status state

Error The current device status is error.

No Error The current device status is no error.

### Device status trap

enabled A trap is sent if the device status changes.

disabled No trap is sent if the device status changes.

### 4.1.13 show authentication

This command displays users assigned to authentication login lists.

**Format**

```
show authentication [users <listname>]
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.14 show eventlog

This command displays the event log, which contains error messages from the system. The event log is not cleared on a system reset.

**Format**

```
show eventlog
```

**Mode**

```
Privileged EXEC and User EXEC
```

**File**

The file in which the event originated.

**Line**

The line number of the event

**Task Id**

The task ID of the event.

**Code**

The event code.

**Time**

The time this event occurred.

**Note:** Event log information is retained across a switch reset.

### 4.1.15 show interface

This command displays a summary of statistics for a specific port or a count of all CPU traffic based upon the argument.

#### Format

```
show interface {<slot/port> |  
                ethernet{<slot/port>|switchport} |  
                switchport}
```

#### Mode

Privileged EXEC and User EXEC

The display parameters, when the argument is '`<slot/port>`', is as follows :

#### Packets Received Without Error

The total number of packets (including broadcast packets and multi-cast packets) received by the processor.

#### Packets Received With Error

The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

#### Broadcast Packets Received

The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

#### Packets Transmitted Without Error

The total number of packets transmitted out of the interface.

#### Transmit Packets Errors

The number of outbound packets that could not be transmitted because of errors.

#### Collisions Frames

The best estimate of the total number of collisions on this Ethernet segment.

#### Time Since Counters Last Cleared

The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters, when the argument is 'switchport', is as follows :

**Packets Received Without Error**

The total number of packets (including broadcast packets and multi-cast packets) received by the processor.

**Broadcast Packets Received**

The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

**Packets Received With Error**

The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

**Packets Transmitted Without Error**

The total number of packets transmitted out of the interface.

**Broadcast Packets Transmitted**

The total number of packets that higher-level protocols requested to be transmitted to the Broadcast address, including those that were discarded or not sent.

**Transmit Packet Errors**

The number of outbound packets that could not be transmitted because of errors.

**Address Entries Currently In Use**

The total number of Forwarding Database Address Table entries now active on the switch, including learned and static entries.

**VLAN Entries Currently In Use**

The number of VLAN entries presently occupying the VLAN table.

**Time Since Counters Last Cleared**

The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

## 4.1.16 show interface ethernet

This command displays detailed statistics for a specific port or for all CPU traffic based upon the argument.

### Format

```
show interface ethernet {<slot/port> | switchport}
```

### Mode

Privileged EXEC and User EXEC

The display parameters, when the argument is '<slot/port>', are as follows :

### Packets Received

**Octets Received** - The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including Frame Check Sequence (FCS) octets). This object can be used as a reasonable estimate of ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. ----- The result of this equation is the value Utilization which is the percent utilization of the ethernet segment on a scale of 0 to 100 percent.

**Packets Received < 64 Octets** - The total number of packets (including bad packets) received that were < 64 octets in length (excluding framing bits but including FCS octets).

**Packets Received 64 Octets** - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

**Packets Received 65-127 Octets** - The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 128-255 Octets** - The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 256-511 Octets** - The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 512-1023 Octets** - The total number of packets (including bad packets) received that were between 512 and 1023

octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 1024-1518 Octets** - The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received 1519-1522 Octets** - The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Received > 1522 Octets** - The total number of packets received that were longer than 1522 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.

### **Packets Received Successfully**

**Total** - The total number of packets received that were without errors.

**Unicast Packets Received** - The number of subnetwork-unicast packets delivered to a higher-layer protocol.

**Multicast Packets Received** - The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

**Broadcast Packets Received** - The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.

### **Packets Received with MAC Errors**

**Total** - The total number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.

**Jabbers Received** - The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.

**Fragments/Undersize Received** - The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets).

**Alignment Errors** - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with a non-integral number of octets.

**Rx FCS Errors** - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets

**Overruns** - The total number of frames discarded as this port was overloaded with incoming packets, and could not keep up with the inflow.

### Received Packets not forwarded

**Total** - A count of valid frames received which were discarded (i.e. filtered) by the forwarding process.

**Local Traffic Frames** - The total number of frames dropped in the forwarding process because the destination address was located off of this port.

**802.3x Pause Frames Received** - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.

**Unacceptable Frame Type** - The number of frames discarded from this port due to being an unacceptable frame type.

**VLAN Membership Mismatch** - The number of frames discarded on this port due to ingress filtering.

**VLAN Viable Discards** - The number of frames discarded on this port when a lookup on a particular VLAN occurs while that entry in the VLAN table is being modified, or if the VLAN has not been configured.

**Multicast Tree Viable Discards** - The number of frames discarded when a lookup in the multicast tree for a VLAN occurs while that tree is being modified.

**Reserved Address Discards** - The number of frames discarded that are destined to an IEEE 802.1 reserved address and are not supported by the system.

**Broadcast Storm Recovery** - The number of frames discarded that are destined for FF:FF:FF:FF:FF:FF when Broadcast Storm Recovery is enabled.

**CFI Discards** - The number of frames discarded that have CFI bit set and the addresses in RIF are in non-canonical format.



**Upstream Threshold** - The number of frames discarded due to lack of cell descriptors available for that packet's priority level.

### **Packets Transmitted Octets**

**Total Bytes** - The total number of octets of data (including those in bad packets) transmitted into the network (excluding framing bits but including FCS octets). This object can be used as a reasonable estimate of ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval. -----

**Packets Transmitted 64 Octets** - The total number of packets (including bad packets) transmitted that were 64 octets in length (excluding framing bits but including FCS octets).

**Packets Transmitted 65-127 Octets** - The total number of packets (including bad packets) transmitted that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 128-255 Octets** - The total number of packets (including bad packets) transmitted that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 256-511 Octets** - The total number of packets (including bad packets) transmitted that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 512-1023 Octets** - The total number of packets (including bad packets) transmitted that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 1024-1518 Octets** - The total number of packets (including bad packets) transmitted that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

**Packets Transmitted 1519-1522 Octets** - The total number of packets (including bad packets) transmitted that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

**Max Info** - The maximum size of the Info (non-MAC) field that this port will receive or transmit.

## Packets Transmitted Successfully

**Total** - The number of frames that have been transmitted by this port to its segment.

**Unicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

**Multicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

**Broadcast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

## Transmit Errors

**Total Errors** - The sum of Single, Multiple, and Excessive Collisions.

**Tx FCS Errors** - The total number of packets transmitted that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets

**Oversized** - The total number of frames that exceeded the max permitted frame size. This counter has a max increment rate of 815 counts per sec. at 10 Mb/s.

**Underrun Errors** - The total number of frames discarded because the transmit FIFO buffer became empty during frame transmission.

## Transmit Discards

**Total Discards** - The sum of single collision frames discarded, multiple collision frames discarded, and excessive frames discarded.

**Single Collision Frames** - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.

**Multiple Collision Frames** - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.

**Excessive Collisions** - A count of frames for which transmission on a particular interface is discontinued due to excessive collisions.

**Port Membership** - The number of frames discarded on egress for this port due to egress filtering being enabled.

**VLAN Viable Discards** - The number of frames discarded on this port when a lookup on a particular VLAN occurs while that entry in the VLAN table is being modified, or if the VLAN has not been configured.

## Protocol Statistics

**BPDUs received** - The count of BPDUs (Bridge Protocol Data Units) received in the spanning tree layer.

**BPDUs Transmitted** - The count of BPDUs (Bridge Protocol Data Units) transmitted from the spanning tree layer.

**802.3x Pause Frames Received** - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.

**GVRP PDU's Received** - The count of GVRP PDU's received in the GARP layer.

**GMRP PDU's received** - The count of GMRP PDU's received in the GARP layer.

**GMRP PDU's Transmitted** - The count of GMRP PDU's transmitted from the GARP layer.

**GMRP Failed Registrations** - The number of times attempted GMRP registrations could not be completed.

**STP BPDUs Transmitted** - Spanning Tree Protocol Bridge Protocol Data Units sent

**STP BPDUs Received** - Spanning Tree Protocol Bridge Protocol Data Units received

**RST BPDUs Transmitted** - Rapid Spanning Tree Protocol Bridge Protocol Data Units sent

**RSTP BPDUs Received** - Rapid Spanning Tree Protocol Bridge Protocol Data Units received

**MSTP BPDUs Transmitted** - Multiple Spanning Tree Protocol Bridge Protocol Data Units sent

**MSTP BPDUs Received** - Multiple Spanning Tree Protocol Bridge Protocol Data Units received

## Dot1x Statistics

**EAPOL Frames Received**- The number of valid EAPOL frames of any type that have been received by this authenticator.

**EAPOL Frames Transmitted** - The number of EAPOL frames of any type that have been transmitted by this authenticator.

## Time Since Counters Last Cleared

The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.

The display parameters, when the argument is 'switchport, are as follows :

**Octets Received** - The total number of octets of data received by the processor (excluding framing bits but including FCS octets).

**Total Packets Received Without Error**- The total number of packets (including broadcast packets and multicast packets) received by the processor.

**Unicast Packets Received** - The number of subnetwork-unicast packets delivered to a higher-layer protocol.

**Multicast Packets Received** - The total number of packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.

**Broadcast Packets Received** - The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.

**Receive Packets Discarded** - The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

**Octets Transmitted** - The total number of octets transmitted out of the interface, including framing characters.

**Packets Transmitted without Errors** - The total number of packets transmitted out of the interface.

**Unicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

**Multicast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

**Broadcast Packets Transmitted** - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

**Transmit Packets Discarded** - The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

**Most Address Entries Ever Used** - The highest number of Forwarding Database Address Table entries that have been learned by this switch since the most recent reboot.

**Address Entries in Use** - The number of Learned and static entries in the Forwarding Database Address Table for this switch.

**Maximum VLAN Entries** - The maximum number of Virtual LANs (VLANs) allowed on this switch.

**Most VLAN Entries Ever Used** - The largest number of VLANs that have been active on this switch since the last reboot.

**Static VLAN Entries** - The number of presently active VLAN entries on this switch that have been created statically.

**Dynamic VLAN Entries** - The number of presently active VLAN entries on this switch that have been created by GVRP registration.

**VLAN Deletes** - The number of VLANs on this switch that have been created and then deleted since the last reboot.

### **Time Since Counters Last Cleared**

The elapsed time, in days, hours, minutes, and seconds, since the statistics for this switch were last cleared.

### 4.1.17 show interface switchport

This command displays data concerning the internal port to the management agent.

**Format**

```
show interface switchport
```

**Mode**

Privileged EXEC and User EXEC

### 4.1.18 show logging

This command displays the trap log maintained by the switch. The trap log contains a maximum of 256 entries that wrap.

**Format**

```
show logging [buffered | hosts | traplogs |  
snmp-requests]
```

**Mode**

Privileged EXEC and User EXEC

**buffered**

Display buffered (in-memory) log entries.

**hosts**

Display logging hosts.

**traplogs**

Display trap records.

**snmp-requests**

Display logging SNMP requests and severity level.

## 4.1.19 show mac-addr-table

This command displays the forwarding database entries. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the optional *all* parameter. Alternatively, the administrator can enter a MAC Address to display the table entry for the requested MAC address and all entries following the requested MAC address.

**Note:** This command displays only learned unicast addresses. For other addresses use the command `show mac-filter-table`.

See “[show mac-filter-table gmrp](#)” on page 216.

### Format

```
show mac-addr-table [<macaddr> <1-4042> | all]
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Slot/Port

The port which this address was learned.

### if Index

This object indicates the ifIndex of the interface table entry associated with this port.

### Status

The status of this entry. The meanings of the values are:

**Learned** The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.

**Management** The value of the corresponding instance (system MAC address) is also the value of an existing instance of `dot1dStaticAddress`.

## 4.1.20 show signal-contact

The signal contact is for displaying

- D the manual setting and the current state of the signal contact,
- D the monitoring functions of the switch,
- D the signal-contacts trap setting.

### Format

```
show signal-contact  
    [1|2|all [mode|monitor|state|trap]]
```

### Mode

Privileged EXEC and User EXEC

### Signal contact mode

**Auto** The signal contact monitors the functions of the switch which makes it possible to perform remote diagnostics.

A break in contact is reported via the zero-potential signal contact (relay contact, closed circuit).

**Device Status** The signal contact monitors the device-status.

**Manual** This command gives you the option of remote switching the signal contact.

### Signal contact monitor

Displays the possible monitored events and which of them are monitored:

- the detected failure of at least one of the supply voltages.
- the removal of the ACA
- the removal of a media module
- the temperature limits
- the defective link status of at least one port. With the switch, the indication of link status can be masked by the management for each port. Link status is not monitored in the delivery condition.
- the loss of Redundancy guarantee.

Ring/network coupling:

- The following conditions are reported in Stand-by mode:
- interrupted control line
- partner device running in Stand-by mode.

HIPER-Ring:

- The following condition is reported in RM mode additionally:
- Ring redundancy guaranteed. Ring redundancy is not monitored in the delivery condition.



**Signal contact manual setting**

`closed` The signal contact's manual setting is closed.

`open` The signal contact's manual setting is open.

**Signal contact operating state**

`closed` The signal contact is currently closed.

`open` The signal contact is currently open.

**Signal contact trap**

`enabled` A trap is sent if the signal contact state changes.

`disabled` No trap is sent if the signal contact state changes.

**Note:** To show the signal contact's port related settings, use the command `show port {<slot/port> | all}` (see ["show port" on page 223](#)).

## 4.1.21 show slot

This command is used to display information about slot(s).  
For `[slot]` enter the slot ID.

**Format**

```
show slot [slot]
```

**Mode**

Privileged EXEC

## 4.1.22 show running-config

This command is used to display the current setting of different protocol packages supported on the switch. This command displays only those parameters, the values of which differ from default value. The output is displayed in the script format, which can be used to configure another switch with the same configuration.

### Format

```
show running-config [all | <scriptname>]
```

### Mode

Privileged EXEC

### all

Show all the running configuration on the switch. All configuration parameters will be output even if their value is the default value.

### <scriptname>

Script file name for writing active configuration.

**Note:** file extension must be .cli, file name must not exceed 16 characters, must not start with a dot (.) and must not contain a directory.

### 4.1.23 show sysinfo

This command displays switch information.

**Format**

```
show sysinfo
```

**Mode**

Privileged EXEC and User EXEC

**Alarm**

Displays the latest present Alarm for a signal contact.

**System Description**

Text used to identify this switch.

**System Name**

Name used to identify the switch.

**System Location**

Text used to identify the location of the switch. May be up to 31 alpha-numeric characters. The factory default is blank.

**System Contact**

Text used to identify a contact person for this switch. May be up to 31 alpha-numeric characters. The factory default is blank.

**System UpTime**

The time in days, hours and minutes since the last switch reboot.

**System Date and Time**

The system clock's date and time in local time zone.

**System IP Address**

The system's IP address.

**Boot Software Release**

The boot code's version number.

**Boot Software Build Date**

The boot code's build date.

**Operating system Software Release**

The operating system's software version number.

**Operating system Software Build Date**

The operating system's software build date.

**Running Software Release**

The operating system's software version number.

**Running Software Build Date**

The operating system's software build date.

**Stored Software Release**

The stored operating system's software version number.

**Stored Software Build Date**

The stored operating system's software build date.

**Backup Software Release**

The backup operating system's software version number.

**Backup Software Build Date**

The backup operating system's software build date.

**Backplane Hardware Revision**

The hardware's revision number.

**Backplane Hardware Description**

The hardware's device description.

**Serial Number (Backplane)**

The hardware's serial number.

**Base MAC Address (Backplane)**

The hardware's base MAC address.

**Number of MAC Addresses (Backplane)**

The number of hardware MAC addresses.

**Configuration state**

The state of the actual configuration.

**Auto Config Adapter, State**

The Auto Configuration Adapter's state.

**Auto Config Adapter, Serial Number**

The Auto Configuration Adapter's serial number (if present and operative).

**Fan Status**

The status of the MACH 4000 fan.

**Power Supply Information**

The status of the power supplies.

**Media Module Information**

The description of each media module

- Description: media module type,
- Serial Number of the media modul (if available),

SFP Information:

- SFP Part ID: SFP type (if available),
- SFP Serial No. of the SFP module (if available),
- SFP Supported: yes/no,
- SFP Temperature (°C, F),
- SFP Tx Pwr, SFP transmit power (dBm / mW),
- SFP Rx Pwr, SFP receive power (dBm / mW),
- SFP Rx Pwr State: ok/warning/alarm.

**CPU Utilization**

The utilization of the central processing unit.

**Flashdisk**

Free memory on flashdisk (in Kbytes).

## 4.1.24 show temperature

**Note:** The command is available for RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH100, MACH 1000, PowerMICE, MACH 4000 and OCTOPUS devices.

This command displays the lower and upper temperature limit for sending a trap.

### Format

```
show temperature
```

### Mode

```
Privileged EXEC and User EXEC
```

## 4.2 Debug Commands

### 4.2.1 debug tcpdump help

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command displays the supported options and expressions for the tcpdump command.

**Format**

```
debug tcpdump help
```

**Mode**

Privileged EXEC

### 4.2.2 debug tcpdump start cpu

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command starts a capture on the CPU interface with the options and expressions in the <command> parameter.

Without the <command> parameter this command starts a capture on the CPU interface using default options and no explicit filtering.

**Format**

```
debug tcpdump start cpu <command>
```

**Mode**

Privileged EXEC

### 4.2.3 debug tcpdump start cpu filter

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command starts a capture on the CPU interface with the options and expressions in the filter file.

**Format**

```
debug tcpdump start cpu filter <capturefilter>
```

**Mode**

Privileged EXEC

### 4.2.4 debug tcpdump stop

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command stops a running capture on the CPU interface.

**Format**

```
debug tcpdump stop
```

**Mode**

Privileged EXEC



### 4.2.5 debug tcpdump filter show

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command shows a saved filter file stored in flash memory.

**Format**

```
debug tcpdump filter show <capturefilter>
```

**Mode**

Privileged EXEC

### 4.2.6 debug tcpdump filter list

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command lists all saved filter files stored in flash memory.

**Format**

```
debug tcpdump filter list
```

**Mode**

Privileged EXEC

### 4.2.7 debug tcpdump filter delete

Run diagnostics commands. With the TCP dump you run a packet analyzer for capturing network traffic.

This command removes a saved filter file from the flash memory.

**Format**

```
debug tcpdump filter delete <capturefilter>
```

**Mode**

Privileged EXEC

## 4.3 Management VLAN Commands

### 4.3.1 network mgmt\_vlan

This command configures the Management VLAN ID. If you enter the VLAN ID "0", the agent can be accessed by all VLANs.

**Default**

1

**Format**

```
network mgmt_vlan <0-4042>
```

**Mode**

Privileged EXEC

## 4.4 Class of Service (CoS) Commands

This chapter provides a detailed explanation of the QoS CoS commands. The following commands are available.

The commands are divided into these different groups:

- D Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- D Show commands are used to display device settings, statistics and other information.

**Note:** The 'Interface Config' mode only affects a single interface, whereas the 'Global Config' mode is applied to all interfaces.

### 4.4.1 classofservice dot1p-mapping

This command maps an 802.1p priority to an internal traffic class for a device when in 'Global Config' mode. The number of available traffic classes may vary with the platform. Userpriority and trafficclass can both be the range from 0-7. The command is only available on platforms that support priority to traffic class mapping on a 'per-port' basis, and the number of available traffic classes may vary with the platform.

**Format**

```
classofservice dot1p-mapping
    <userpriority> <trafficclass>
```

**Mode**

Global Config or Interface Config

**userpriority**

Enter the 802.1p priority (0-7).

**trafficclass**

Enter the traffic class to map the 802.1p priority (0-3).

**U no classofservice dot1p-mapping**

This command restores the default mapping of the 802.1p priority to an internal traffic class.

**Format**

```
no classofservice dot1p-mapping
```

**Modes**

Global Config or Interface Config

## 4.4.2 classofservice ip-dscp-mapping

This command maps an IP DSCP value to an internal traffic class. The <ipdscp> value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

### Format

```
classofservice ip-dscp-mapping
                        <ipdscp> <trafficclass>
```

### Mode

Global Config

### ipdscp

Enter the IP DSCP value in the range of 0 to 63 or an IP DSCP keyword (af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef).

### trafficclass

Enter the traffic class to map the 802.1p priority (0-3).

### U no classofservice ip-dscp-mapping

This command restores the default mapping of the IP DSCP value to an internal traffic class.

### Format

```
no classofservice dot1p-mapping
```

### Modes

Global Config

### 4.4.3 classofservice trust

This command sets the class of service trust mode of an interface. The mode can be set to trust one of the Dot1p (802.1p) or IP DSCP packet markings.

**Note:** In `trust ip-dscp` mode the switch modifies the vlan priority for outgoing frames according to

– the DSCP mapping and VLAN mapping table

(PowerMICE, MACH 1000, MACH 4000)

– the a fix mapping table

(see Reference Manual „GUI Graphical User Interface“ (Web-based Interface) for further details).

#### Format

```
classofservice trust dot1p | ip-dscp
```

#### Mode

Global Config or

Interface Config (PowerMICE, MACH 1000, MACH 4000)

#### U no classofservice trust

This command sets the interface mode to untrusted, i.e. the packet priority marking is ignored and the default port priority is used instead.

#### Format

```
no classofservice trust
```

#### Modes

Global Config or

Interface Config (PowerMICE, MACH 1000, MACH 4000)

#### 4.4.4 show classofservice dot1p-mapping

This command displays the current 802.1p priority mapping to internal traffic classes for a specific interface. The slot/port parameter is required on platforms that support priority to traffic class mapping on a 'per-port' basis.

Platforms that support priority to traffic class mapping on a per-port basis:

**Format**

```
show classofservice dot1p-mapping
```

Platforms that do not support priority to traffic class mapping on a per-port basis:

**Format**

```
Show classofservice dot1p-mapping
```

**Mode**

```
Privileged EXEC and User EXEC
```



### 4.4.5 show classofservice ip-dscp-mapping

This command displays the current IP DSCP mapping to internal traffic classes for the global configuration settings.

**Format**

```
show classofservice ip-dscp-mapping [<slot/port>]
```

**Mode**

Privileged EXEC

The following information is repeated for each user priority.

**IP DSCP**

The IP DSCP value.

**Traffic Class**

The traffic class internal queue identifier to which the IP DSCP value is mapped.

**slot/port**

Valid slot and port number separated by forward slashes.

### 4.4.6 show classofservice trust

This command displays the current trust mode for the specified interface. The slot/port parameter is optional. If specified, the trust mode of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

**Format**

```
show classofservice trust [slot/port]
```

**Mode**

Privileged EXEC

**Class of Service Trust Mode**

The current trust mode: Dot1p, IP DSCP, or Untrusted.

**Untrusted Traffic Class**

The traffic class used for all untrusted traffic. This is only displayed when the COS trust mode is set to 'untrusted'.

**slot/port**

Valid slot and port number separated by forward slashes.

### 4.4.7 vlan port priority all

This command configures the port priority assigned for untagged packets for all ports presently plugged into the device. The range for the priority is 0-7. Any subsequent per port configuration will override this configuration setting.

**Format**

```
vlan port priority all <priority>
```

**Mode**

```
Global Config
```

### 4.4.8 vlan priority

This command configures the default 802.1p port priority assigned for untagged packets for a specific interface. The range for the priority is 0-7

**Default**

```
0
```

**Format**

```
vlan priority <priority>
```

**Mode**

```
Interface Config
```

## 4.4.9 dvlan-tunnel etherType

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

This command configures the etherType for all core ports. The etherType may have the values of 802.1q, vMAN or custom. The configured etherType is used for VLAN classification on all ports which are configured as core ports.

### Default

802.1Q

### Format

```
dvlan-tunnel etherType  
                {802.1Q | vman | custom <0-65535>}
```

### Mode

Global Config

### 802.1Q

Configure the etherType as 0x8100.

### custom

Custom configure the etherType for the DVlan tunnel.

Range for the optional value of the custom etherType: 0 to 65535.

### vman

Configure the etherType as 0x88A8.

## 4.4.10 mode dvlan-tunnel

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

Use this command to configure the port either as core port or access port.

### Default

Disabled

### Format

```
mode dvlan-tunnel {access | core}
```

### Mode

Interface Config

### access

Configure this port as a customer port.

### core

Configure this port as a provider network port.

### U no mode dvlan-tunnel

Use this command to configure the port as normal switch port and to disable the DVLAN tunneling.

### Default

Disabled

### Format

```
no mode dvlan-tunnel
```

### Mode

Interface Config

### 4.4.11 show dvlan-tunnel

**Note:** This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH104, MACH1000, MACH1040, MACH4002-24G/48G (XG), OCTOPUS, OS20/OS30 devices.

Use this command to display the DVLAN-Tunnel mode and used ether-type for the specified interface(s).

#### Format

```
show dvlan-tunnel [interface {slot/port} | all]
```

#### Modes

Privileged EXEC

User EXEC

#### <slot/port>

Enter an interface in slot/port format.

#### all

Enter 'all' for all interfaces.

#### Interface

Display the number of the interface (slot/port).

Possible values (example): 1/1, 1/2, 2/1, 2/2, 2/3.

#### Mode

Display the DVLAN-Tunnel mode.

Possible values: normal, ....

#### EtherType

Display the used ether-type.

Possible values: 802.1Q, vman, custom.

## 4.5 Link Aggregation(802.3ad) Commands

### 4.5.1 link-aggregation staticcapability

This command enables the support of link-aggregations (static LAGs) on the device. By default, the static capability for all link-aggregations is disabled.

**Default**

disabled

**Format**

```
link-aggregation staticcapability
```

**Mode**

Global Config

**U no link-aggregation staticcapability**

This command disables the support of static link-aggregations (LAGs) on the device.

**Default**

disabled

**Format**

```
no link-aggregation staticcapability
```

**Mode**

Global Config

## 4.5.2 show link-aggregation brief

This command displays the static capability of all link-aggregations (LAGs) on the device as well as a summary of individual link-aggregations.

### Format

```
show link-aggregation brief
```

### Mode

Privileged EXEC and User EXEC

### Static Capability

This field displays whether or not the device has static capability enabled.

For each link-aggregation the following information is displayed:

### Name

This field displays the name of the link-aggregation.

### Link State

This field indicates whether the link is up or down.

### Mbr Ports

This field lists the ports that are members of this link-aggregation, in <slot/port> notation.

### Max. num. of LAGs

Displays the maximum number of concurrently configured link aggregations on this device.

### Slot no. for LAGs

Displays the slot number for all configured link aggregations on this device.



## 4.6 Management Commands

These commands manage the switch and show current management settings.

### 4.6.1 telnet

This command establishes a new outbound telnet connection to a remote host. The host value must be a valid IP address. Valid values for port should be a valid decimal integer in the range of 0 to 65535, where the default value is 23. If [debug] is used, the current telnet options enabled is displayed. The optional line parameter sets the outbound telnet operational mode as 'linemode', where by default, the operational mode is 'character mode'. The echo option enables local echo and only takes effect when the local switch is accessed via the serial connection (V.24).

#### **Format**

```
telnet <host> <port> [debug] [line] [echo]
```

#### **Mode**

```
Privileged EXEC and User EXEC
```

## 4.6.2 transport input telnet

This command regulates new telnet sessions. If sessions are enabled, new telnet sessions can be established until there are no more sessions available. If sessions are disabled, no new telnet sessions are established. An established session remains active until the session is ended or an abnormal network error ends the session.

**Default**

enabled

**Format**

```
transport input telnet
```

**Mode**

Line Config

**U no transport input telnet**

This command disables telnet sessions. If sessions are disabled, no new telnet sessions are established.

**Format**

```
no transport input telnet
```

**Mode**

Line Config

### 4.6.3 transport output telnet

This command regulates new outbound telnet connections. If enabled, new outbound telnet sessions can be established until it reaches the maximum number of simultaneous outbound telnet sessions allowed.

If disabled, no new outbound telnet session can be established. An established session remains active until the session is ended or an abnormal network error ends it.

**Default**

enabled

**Format**

```
transport output telnet
```

**Mode**

Line Config

**U no transport output telnet**

This command disables new outbound telnet connections. If disabled, no new outbound telnet connection can be established.

**Format**

```
no transport output telnet
```

**Mode**

Line Config

### 4.6.4 session-limit

This command specifies the maximum number of simultaneous outbound telnet sessions. A value of 0 indicates that no outbound telnet session can be established.

**Default**

4

**Format**`session-limit <0-5>`**Mode**

Line Config

**U no session-limit**

This command sets the maximum number of simultaneous outbound telnet sessions to the default value.

**Format**`no session-limit`**Mode**

Line Config

### 4.6.5 session-timeout

This command sets the telnet session timeout value. The timeout value unit of time is minutes.

**Default**

5

**Format**

```
session-timeout <1-160>
```

**Mode**

Line Config

**U no session-timeout**

This command sets the telnet session timeout value to the default. The timeout value unit of time is minutes.

**Format**

```
no session-timeout
```

**Mode**

Line Config

### 4.6.6 bridge address-learning

To enable you to observe the data at all the ports, the Switch allows you to disable the learning of addresses. When the learning of addresses is disabled, the Switch transfers all the data from all ports to all ports. The default value is enable.

**Format**

```
bridge address-learning {disable|enable}
```

**Mode**

Global Config

### 4.6.7 bridge address-relearn detect operation

This command enables or disables Bridge Address Relearn Detection. The default value is disable.

**Default**

Disabled

**Format**

```
bridge address-relearn detect operation  
{disable|enable}
```

**Mode**

Global Config

### 4.6.8 bridge address-relearn detect threshold

This command defines the value of relearned addresses to signal address relearn threshold exceeded.

The default relearn threshold is 1. Possible values to configure threshold count are 1 to 1024.

**Default**

1

**Format**

```
bridge address-relearn-detect threshold <value>
```

**Mode**

Global Config

**value**

1 to 1024

### 4.6.9 bridge aging-time

This command configures the forwarding database address aging timeout in seconds.

**Default**

30

**Format**

```
bridge aging-time <10-630>
```

**Mode**

Global Config

**Seconds**

The <seconds> parameter must be within the range of 10 to 630 seconds.

**U no bridge aging-time**

This command sets the forwarding database address aging timeout to 30 seconds.

**Format**

```
no bridge aging-time
```

**Mode**

Global Config

### 4.6.10 bridge fast-link-detection

This command enables or disables the Bridge Fast Link Detection.

**Default**

Enabled

**Format**

```
bridge fast-link-detection {disable|enable}
```

**Mode**

Global Config

### 4.6.11 bridge duplex-mismatch-detect operation

This command enables or disables Bridge Duplex Mismatch Detection.

Reasons for Duplex Mismatch can be:

- A local port is configured to fix full-duplex.
- A port is configured to auto-negotiation and has negotiated HalfDuplex-Mode.

Duplex Mismatch can be excluded, when the local port is configured to auto-negotiation and duplex mode is negotiated to full-duplex.

**Note:** If counters and configuration settings indicate a Duplex Mismatch, the reason can also be a bad cable and/or EMI.

**Default**

Enabled

**Format**

```
bridge duplex-mismatch-detect operation  
{disable|enable}
```

**Mode**

Global Config



### 4.6.12 bridge vlan-learning

With "independent" you set the Shared VLAN Learning mode to Independent. The switch will treat equal MAC source addresses from different VLANs as separate addresses.

With "shared" you set the Shared VLAN Learning mode to Shared. The switch will treat equal MAC source addresses from different VLANs as the same address.

#### Format

```
bridge vlan-learning {independent|shared}
```

#### Mode

```
Global Config
```

### 4.6.13 digital-input

This command configures the MICE IO-Module digital inputs.

#### Format

```
digital-input
  admin-state {enable | disable}
  refresh-interval <refresh-interval>
  log-event {all | <slot/input>} {enable|disable}
  snmp-trap {all | <slot/input>} {enable|disable}
```

#### Mode

```
Global Config
```

#### admin-state

This command enables or disables the polling task for digital inputs of the MICE IO-Module. When disabled, no event logging or SNMP traps will work. Default: `disable`.

`disable` Disable the IO-Module digital inputs admin state.

`enable` Enable the IO-Module digital inputs admin state.

### refresh-interval

This command configures the digital inputs refresh interval. Each input configured for event logging or SNMP traps is polled with this interval.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### log-event

This command enables or disables the event logging of input status changes for one or all digital inputs. Default: `disable`.

The input state will be checked according to the interval set with `IO-<refresh-interval>`.

`all` Configure the IO-Module event logging for all digital inputs.

`<slot/input>` Configure the IO-Module event logging for a single digital input.

`disable` Disable event logging for digital input status changes.

`enable` Enable event logging for digital input status changes.

### snmp-trap

This command enables or disables the sending of SNMP traps in case of input status changes for one or all digital inputs. Default: `disable`.

The trap will be sent to all SNMP trap receivers configured with `snmptrap`.

The input state will be checked according to the interval set with `IO-<refresh-interval>`.

`all` Configure the IO-Module SNMP trap for all digital inputs.

`<slot/input>` Configure the IO-Module SNMP trap for a single digital input.

`disable` Disable SNMP traps for digital input status changes.

`enable` Enable SNMP traps for digital input status changes.

## 4.6.14 digital-output

This command configures the IO-Module digital outputs.

### Format

```
digital-output
  admin-state {enable | disable}
  refresh-interval <refresh-interval>
  retry-count <refresh-interval>
  log-event {all | <slot/output>} {enable|disable}
  snmp-trap {all | <slot/output>} {enable|disable}
  mirror all | <slot>/<output> {disable |
                                from <IPAddress> <slot>/<input>}
```

### Mode

Global Config

### admin-state

This command enables or disables the polling task for digital outputs of the MICE IO-Module. When disabled, no event logging or SNMP traps will work. Default: `disable`.

`disable` Disable the IO-Module digital outputs admin state.

`enable` Enable the IO-Module digital outputs admin state.

### refresh-interval

This command configures the IO-Module digital outputs refresh interval. Each output configured for input mirroring is refreshed (input is polled) with this interval.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### retry-count

This command configures the number of retry counts for setting digital outputs of the MICE IO-Module. Each output configured for input mirroring is set to the default value (low) when after the number of configured retries no SNMP get request was answered.

`<refresh-interval>` The refresh interval is in the range of 1..10 seconds. Default: 1.

### log-event

This command enables or disables the event logging of output status changes for one or all digital outputs. Default: `disable`.

The output state will be checked according to the interval set with IO-

`<refresh-interval>`.

Configure the IO-Module event logging for one or all digital outputs.

`all` Configure the IO-Module event logging for all digital outputs.

`<slot/output>` Configure the IO-Module event logging for a single digital output.

`disable` Disable event logging for digital output status changes.

`enable` Enable event logging for digital output status changes.

### **snmp-trap**

This command enables or disables the sending of SNMP traps in case of output status changes for one or all digital outputs. Default: `disable`.

The trap will be sent to all SNMP trap receivers configured with `snmptrap`.

The output state will be checked according to the interval set with `IO-  
<refresh-interval>`.

`all` Configure the IO-Module SNMP trap for all digital outputs.

`<slot/output>` Configure the IO-Module SNMP trap for a single digital output.

`disable` Disable SNMP traps for digital output status changes.

`enable` Enable SNMP traps for digital output status changes.

## mirror

Configure the IO-Module mirroring for one or all digital outputs. This command determines the input mirrored to the currently selected output.

To disable mirroring, the following commands are equivalent:

```
digital-output mirror 1/2 disable
```

```
digital-output mirror 1/2 from 0.0.0.0 1/1
```

**<all>**: Configure the IO-Module mirroring for all digital outputs.

**<slot/output>**: Configure the IO-Module mirroring for a single digital output. The **<slot>** value determines the IO-module slot number on the device with the selected IP address.

**disable**: Disable the IO-Module mirroring for a single digital output.

**from**: Enable the IO-Module mirroring for a single digital output from **<IP-address>** **<slot/input>**

**<IPaddress>**: The IP address value determines the IP address used for reading the input value. Use IP address 127.0.0.1 or the system IP address to mirror inputs from a local IO module. When IP address is 0.0.0.0 no input is mirrored to the output (the output value is set to 'low'). Default: 0.0.0.0.

**<slot/input>**: The **<input>** value determines the input number on this device. Default: 1/1.

### 4.6.15 show digital-input

This command shows the input value or configuration from all available digital inputs of the MICE I/O Module.

**Format**

```
show digital-input
```

**Mode**

```
Global Config
```

**Digital Input System Information:****Admin State**

Show the IO-Module digital inputs Admin State.  
Possible values: Disabled, Enabled.

**Refresh Interval [s]**

Show the IO-Module digital inputs Refresh Interval in seconds.  
Value range: 1-10.

**Digital Input Information:****Input**

Show numbers of the IO-Module digital input.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

**Value**

Show the value of the IO-Module digital inputs.  
Possible values: Not available, High, Low.

**Log-Event**

Show if Event logging is enabled or disabled for the IO-Module digital inputs.  
Possible values: Disabled, Enabled.

**SNMP-trap**

Show if SNMP traps are enabled or disabled for the IO-Module digital inputs.  
Possible values: Disabled, Enabled.

## 4.6.16 show digital-input config

This command shows the IO-Module digital inputs global configuration.

### **Format**

```
show digital-input config
```

### **Mode**

```
Global Config
```

### **Digital Input System Information:**

#### **Admin State**

Show the IO-Module digital inputs Admin State.  
Possible values: Disabled, Enabled.

#### **Refresh Interval [s]**

Show the IO-Module digital inputs Refresh Interval in seconds.  
Value range: 1-10.

### 4.6.17 show digital-input all

This command shows the IO-Module value or configuration for all inputs.

**Format**

```
show digital-input all {all | config | value}
```

**Mode**

Global Config

**all**

Show the IO-Module configuration and value for all inputs

**config**

Show the IO-Module configuration for all inputs.

**value**

Show the IO-Module value for all inputs.

**Digital Input Information:****Input**

Show numbers of the IO-Module digital input.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

**Value**

Show the value of the IO-Module digital inputs.

Possible values: Not available, High, Low.

**Log-Event**

Show if Event logging is enabled or disabled for the IO-Module digital inputs. Possible values: Disabled, Enabled.

**SNMP-trap**

Show if SNMP traps are enabled or disabled for the IO-Module digital inputs. Possible values: Disabled, Enabled.



### 4.6.18 show digital-input <slot/input>

This command shows the IO-Module value or configuration for a single input.

**Format**

```
show digital-input <slot/input>
                               {all | config | value}
```

**Mode**

Global Config

**all**

Show the IO-Module configuration and value for one input.

**config**

Show the IO-Module configuration for one input.

**value**

Show the IO-Module value for one input.

**Digital Input <slot/input> Value**

Show the value of the IO-Module digital input.

Possible values: Not available, High, Low.

**Digital Input <slot/input> Log-Event**

Show if Event logging is enabled or disabled for the IO-Module digital input. Possible values: Disabled, Enabled.

**Digital Input <slot/input> SNMP-trap**

Show if SNMP traps are enabled or disabled for the IO-Module digital input. Possible values: Disabled, Enabled.

### 4.6.19 show digital-output

This command shows the output value or configuration from all available digital outputs of the MICE I/O Module.

**Format**

```
show digital-output
```

**Mode**

```
Global Config
```

**Digital output System Information:****Admin State**

Show the IO-Module digital outputs Admin State.  
Possible values: Disabled, Enabled.

**Refresh Interval [s]**

Show the IO-Module digital outputs Refresh Interval in seconds.  
Value range: 1-10.

**Retry Count**

Show the value of the IO-Module digital outputs Retry count.  
Value range: 1-10.

**Digital output Information:****Output**

Show numbers of the IO-Module digital output.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

**Value**

Show the value of the IO-Module digital outputs.  
Possible values: Not available, High, Low.

**Log-Event**

Show if Event logging is enabled or disabled for the IO-Module digital outputs.  
Possible values: Disabled, Enabled.

**SNMP-trap**

Show if SNMP traps are enabled or disabled for the IO-Module digital outputs.  
Possible values: Disabled, Enabled.

**Mirror from IP**

Show the IP address used for reading the input value.  
Possible values: None, a.b.c.d (valid IP address).

**Input**

Show the input number of the device used for reading the input value.  
Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

## 4.6.20 show digital-output config

This command shows the IO-Module digital outputs global configuration.

**Format**

```
show digital-output config
```

**Mode**

```
Global Config
```

**Digital output System Information:****Admin State**

Show the IO-Module digital outputs Admin State.  
Possible values: Disabled, Enabled.

**Refresh Interval [s]**

Show the IO-Module digital outputs Refresh Interval in seconds.  
Value range: 1-10.

**Retry Count**

Show the value of the IO-Module digital outputs Retry count.  
Value range: 1-10.

### 4.6.21 show digital-output all

This command shows the IO-Module value or configuration for all outputs.

**Format**

```
show digital-output all {all | config | value}
```

**Mode**

Global Config

**all**

Show the IO-Module configuration and value for all outputs

**config**

Show the IO-Module configuration for all outputs.

**value**

Show the IO-Module value for all outputs.

**Digital output Information:****output**

Show numbers of the IO-Module digital output.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

**Value**

Show the value of the IO-Module digital outputs.

Possible values: Not available, High, Low.

**Log-Event**

Show if Event logging is enabled or disabled for the IO-Module digital outputs. Possible values: Disabled, Enabled.

**SNMP-trap**

Show if SNMP traps are enabled or disabled for the IO-Module digital outputs. Possible values: Disabled, Enabled.

**Mirror from IP**

Show the IP address used for reading the input value.

Possible values: None, a.b.c.d (valid IP address).

**Input**

Show the input number of the device used for reading the input value.

Possible values (example): 1/1, 1/2, 1/3, 1/4,  
3/1, 3/2, 3/3, 3/4

## 4.6.22 show digital-output <slot/output>

This command shows the IO-Module value or configuration for a single output.

### Format

```
show digital-output <slot/output>
                               {all | config | value}
```

### Mode

Global Config

### all

Show the IO-Module configuration and value for one output.

### config

Show the IO-Module configuration for one output.

### value

Show the IO-Module value for one output.

### Digital output <slot/output> Value

Show the value of the IO-Module digital output.  
Possible values: Not available, High, Low, Invalid.

### Digital output <slot/output> Log-Event

Show if Event logging is enabled or disabled for the IO-Module digital output. Possible values: Disabled, Enabled.

### Digital output <slot/output> SNMP-trap

Show if SNMP traps are enabled or disabled for the IO-Module digital output. Possible values: Disabled, Enabled.

### Digital Output <slot/output> Mirror from IP

Show the IP address used for reading the input value.  
Possible values: Not configured, a.b.c.d (valid IP address).

### 4.6.23 ethernet-ip

This command controls the EtherNet/IP function on the switch. Detailed information you can find in the User Manual Industrial Protocols.

**Default**

depends on the order code (standard = disable)

**Format**

```
ethernet-ip admin-state {enable | disable}
```

**Mode**

Global Config

**Admin-state**

`disable` Disables the EtherNet/IP function on this device.

Note: the relevant MIB objects are still accessible.

`enable` Enables the EtherNet/IP function on this device.

### 4.6.24 network javascriptmode

When the user accesses the switch's graphical user interface (web-based interface), the switch's web server will deliver a HTML page that contains JavaScript.

**Default**

enabled

**Format**

```
network javascriptmode
```

**Mode**

Privileged EXEC

**U** `no network javascriptmode`

When the user accesses the switch's graphical user interface (web-based interface), the switch's web server will deliver a HTML page that contains no JavaScript.

**Format**

```
no network javascriptmode
```

**Mode**

```
Privileged EXEC
```

### 4.6.25 network mgmt-access add

This command is used to configure the restricted management access feature (RMA).

It creates a new empty entry at the <index> (if you enter the command with parameter <index>) or at the next free index (if you enter the command without parameter <index>).

**Format**

```
network mgmt-access add [index]
```

**Mode**

```
Global Config
```

**[index]**

Index of the entry in the range 1..16.

## 4.6.26 network mgmt-access delete

This command is used to configure the restricted management access feature (RMA).

It deletes an existing entry with `<index>`.

### **Format**

```
network mgmt-access delete <index>
```

### **Mode**

Global Config

### **<index>**

Index of the entry in the range 1..16.



### 4.6.27 network mgmt-access modify

This command is used to configure the restricted management access feature (RMA).

The command modifies an existing rule with <index> to change IP address, net mask and allowed services.

#### Format

```
network mgmt-access modify <index>
                                { ip <address> |
                                  mask <netmask> |
                                  http {enable | disable} |
                                  snmp {enable | disable} |
                                  telnet {enable | disable} |
                                  ssh {enable |disable } }
```

#### Mode

Global Config

#### <index>

Index of the entry in the range 1..16.

#### <ip>

Configure IP address which should have access to management

#### <mask>

Configure network mask to allow a subnet for management access.

#### <http>

Configure if HTTP is allowed to have management access.

#### <snmp>

Configure if SNMP is allowed to have management access.

#### <telnet>

Configure if TELNET is allowed to have management access.

#### <ssh>

Configure if SSH is allowed to have management access.

#### enable

Allow the service to have management access.

#### disable

Do not allow the service to have management access.

## 4.6.28 network mgmt-access operation

This command is used to configure the restricted management access feature (RMA).

It enables or disables the service to have management access. The default value is disable.

### Format

```
network mgmt-access operation {disable|enable}
```

### Mode

Global Config

### enable

Enable the restricted management access function globally.

### disable

Disable the restricted management access function globally.

## 4.6.29 network mgmt-access status

This command is used to configure the restricted management access feature (RMA).

It activates/deactivates an existing rule with <index>.

### Format

```
network mgmt-access status <index>
                                     {enable | disable}
```

### Mode

Global Config

### <index>

Index of the entry in the range 1..16.

### enable

Allow the service to have management access.

### disable

Do not allow the service to have management access.

### 4.6.30 network parms

This command sets the IP Address, subnet mask and gateway of the router. The IP Address and the gateway must be on the same subnet.

**Format**

```
network parms <ipaddr> <netmask> [gateway]
```

**Mode**

Privileged EXEC

### 4.6.31 network protocol

This command specifies the network configuration protocol to be used. If you modify this value, change is effective immediately after you saved your changes.

The parameter `bootp` indicates that the switch periodically sends requests to a Bootstrap Protocol (BootP) server or a DHCP server until a response is received.

`none` indicates that the switch should be manually configured with IP information.

Independently of the BootP and DHCP settings, HiDiscovery can be configured as an additional protocol.

**Default**

DHCP

**Format**

```
network protocol {none | bootp | dhcp | hidiscovery  
                 {off | read-only | read-write}}
```

**Mode**

Privileged EXEC

### 4.6.32 network priority

This command configures the VLAN priority or the IP DSCP value for outgoing management packets. The <ipdscp> is specified as either an integer from 0-63, or symbolically through one of the following keywords:

af11,af12,af13,af21,af22,af23,af31,af32,af33,af41,af42,af43,be,cs0, cs1, cs2,cs3,cs4,cs5,cs6,cs7,ef.

**Default**

0 for both values

**Format**

```
network priority {dot1p-vlan <0-7> |  
ip-dscp <ipdscp> }
```

**Mode**

Privileged EXEC

**U no network priority**

This command sets the VLAN priority or the IP DSCP value for outgoing management packets to default which means VLAN priority 0 or IP DSCP value 0 (Best effort).

**Format**

```
no network priority {dot1p-vlan | ip-dscp }
```

**Mode**

Privileged EXEC

### 4.6.33 profinetio

This command controls the PROFINET IO function on the switch. Detailed information you can find in the User Manual Industrial Protocols.

**Default**

depends on the order code (standard = disable)

**Format**

```
profinetio admin-state {enable | disable}
```

**Mode**

Global Config

**Admin-state**

`disable` Disables the PROFINET IO function on this device.

Note: the relevant MIB objects are still accessible.

`enable` Enables the PROFINET IO function on this device.

### 4.6.34 serial timeout

This command specifies the maximum connect time (in minutes) without console activity. A value of 0 indicates that a console can be connected indefinitely. The time range is 0 to 160.

**Default**

5

**Format**

```
serial timeout <0-160>
```

**Mode**

Line Config

**U no serial timeout**

This command sets the maximum connect time without console activity (in minutes) back to the default value.

**Format**

```
no serial timeout
```

**Mode**

Line Config

### 4.6.35 set prompt

This command changes the name of the prompt. The length of name may be up to 64 alphanumeric characters.

**Format**

```
set prompt <prompt string>
```

**Mode**

Privileged EXEC

### 4.6.36 show ethernet-ip

This command displays the admin state of the EtherNet/IP function.

**Format**

```
show ethernet-ip
```

**Mode**

Privileged EXEC and User EXEC

### 4.6.37 show network

This command displays configuration settings associated with the switch's network interface. The network interface is the logical interface used for in-band connectivity with the switch via any of the switch's front panel ports. The configuration parameters associated with the switch's network interface do not affect the configuration of the front panel ports through which traffic is switched or routed.

**Format**

```
show network
```

**Mode**

Privileged EXEC and User EXEC

**System IP Address**

The IP address of the interface. The factory default value is 0.0.0.0

**Subnet Mask**

The IP subnet mask for this interface. The factory default value is 0.0.0.0

**Default Gateway**

The default gateway for this IP interface. The factory default value is 0.0.0.0

**Burned In MAC Address**

The burned in MAC address used for in-band connectivity.

**Network Configuration Protocol (BootP/DHCP)**

Indicates which network protocol is being used. The options are `bootp` | `dhcp` | `none`.

**DHCP Client ID (same as SNMP System Name)**

Displays the DHCP Client ID.

**Network Configuration Protocol HiDiscovery**

Indicates in which way the HiDiscovery protocol is being used. The options are `off` | `read-only` | `read-write`.

**Management VLAN ID**

Specifies the management VLAN ID.

**Management VLAN Priority**

Specifies the management VLAN Priority.



**Management VLAN IP-DSCP Value**

Specifies the management VLAN IP-DSCP value.

**Java Script Mode**

Specifies if the Switch will use Java Script to start the Management Applet. The factory default is enabled.

### 4.6.38 show network mgmt-access

This command displays the operating status and entries for restricted management access (RMA).

**Format**

```
show network mgmt-access
```

**Mode**

Privileged EXEC and User EXEC

**Operation**

Indicates whether the operation for RMA is enabled or not.  
The options are `Enabled` | `Disabled`.

**ID**

Index of the entry for restricted management access (1 to max. 16).

**IP Address**

The IP address which should have access to management.  
The factory default value is 0.0.0.0.

**Netmask**

The network mask to allow a subnet for management access.  
The factory default value is 0.0.0.0.

**HTTP**

Indicates whether HTTP is allowed to have management access or not. The options are `Yes` | `No`.

**SNMP**

Indicates whether SNMP is allowed to have management access or not. The options are `Yes` | `No`.

**TELNET**

Indicates whether TELNET is allowed to have management access or not. The options are `Yes` | `No`.

**SSH**

Indicates whether SSH is allowed to have management access or not. The options are `Yes` | `No`.

**Active**

Indicates whether the feature is active or not. The options are `[x]` | `[ ]`.

### 4.6.39 show profinetio

This command displays the admin state of the PROFINET IO function.

**Format**

```
show profinetio
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.6.40 show serial

This command displays serial communication settings for the switch.

**Format**

```
show serial
```

**Mode**

Privileged EXEC and User EXEC

**Serial Port Login Timeout (minutes)**

Specifies the time, in minutes, of inactivity on a Serial port connection, after which the Switch will close the connection. Any numeric value between 0 and 160 is allowed, the factory default is 5. A value of 0 disables the timeout.

### 4.6.41 show snmp-access

This command displays SNMP access information related to global and SNMP version settings. SNMPv3 is always enabled.

**Format**

```
show snmp-access
```

**Mode**

Privileged EXEC

## 4.6.42 show snmpcommunity

This command displays SNMP community information. Six communities are supported. You can add, change, or delete communities. The switch does not have to be reset for changes to take effect.

The SNMP agent of the switch complies with SNMP Version 1 (for more about the SNMP specification, see the SNMP RFCs). The SNMP agent sends traps through TCP/IP to an external SNMP manager based on the SNMP configuration (the trap receiver and other SNMP community parameters).

### Format

```
show snmpcommunity
```

### Mode

Privileged EXEC

### SNMP Community Name

The community string to which this entry grants access. A valid entry is a case-sensitive alphanumeric string of up to 32 characters. Each row of this table must contain a unique community name.

### Client IP Address -

An IP address (or portion thereof) from which this device will accept SNMP packets with the associated community. The requesting entity's IP address is ANDed with the Subnet Mask before being compared to the IP Address. Note: that if the Subnet Mask is set to 0.0.0.0, an IP Address of 0.0.0.0 matches all IP addresses. The default value is 0.0.0.0

### Client IP Mask -

A mask to be ANDed with the requesting entity's IP address before comparison with IP Address. If the result matches with IP Address then the address is an authenticated IP address. For example, if the IP Address = 9.47.128.0 and the corresponding Subnet Mask = 255.255.255.0 a range of incoming IP addresses would match, i.e. the incoming IP Address could equal 9.47.128.0 - 9.47.128.255. The default value is 0.0.0.0

### Access Mode

The access level for this community string.

### Status

The status of this community access entry.

### 4.6.43 show snmptrap

This command displays SNMP trap receivers. Trap messages are sent across a network to an SNMP Network Manager. These messages alert the manager to events occurring within the switch or on the network. Six trap receivers are simultaneously supported.

**Format**

```
show snmptrap
```

**Mode**

Privileged EXEC

**SNMP Trap Name**

The community string of the SNMP trap packet sent to the trap manager. This may be up to 32 alphanumeric characters. This string is case sensitive.

**IP Address**

The IP address to receive SNMP traps from this device. Enter four numbers between 0 and 255 separated by periods.

**Status**

A pull down menu that indicates the receiver's status (enabled or disabled) and allows the administrator/user to perform actions on this user entry:

**Enable** - send traps to the receiver

**Disable** - do not send traps to the receiver.

**Delete** - remove the table entry.

### 4.6.44 show telnet

This command displays outbound telnet settings.

**Format**

```
show telnet
```

**Mode**

Privileged EXEC and User EXEC

**Outbound Telnet Connection Login Timeout (minutes)**

This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. May be specified as a number from 1 to 160. The factory default is 5.

**Maximum Number of Outbound Telnet Sessions**

This object indicates the number of simultaneous outbound connection sessions allowed. The factory default is 5.

**Allow New Outbound Telnet Sessions**

Indicates that new outbound telnet sessions will not be allowed when set to no. The factory default value is yes.

## 4.6.45 show telnetcon

This command displays inbound telnet settings.

### **Format**

```
show telnetcon
```

### **Mode**

Privileged EXEC and User EXEC

### **Telnet Connection Login Timeout (minutes)**

This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. May be specified as a number from 1 to 160. The factory default is 4.

### **Maximum Number of Remote Telnet Sessions**

This object indicates the number of simultaneous remote connection sessions allowed. The factory default is 2 (4 for version L2P).

### **Allow New Telnet Sessions**

Indicates that new telnet sessions will not be allowed when set to no. The factory default value is yes.

## 4.6.46 show trapflags

This command displays trap conditions. Configure which traps the switch should generate by enabling or disabling the trap condition. If a trap condition is enabled and the condition is detected, the switch's SNMP agent sends the trap to all enabled trap receivers. The switch does not have to be reset to implement the changes. Cold and warm start traps are always generated and cannot be disabled.

### Format

```
show trapflags
```

### Mode

Privileged EXEC and User EXEC

### Authentication Flag

May be enabled or disabled. The factory default is enabled. Indicates whether authentication failure traps will be sent.

### Chassis

Indicates whether traps that are related to the chassis functionality of the switch will be sent. These functions include the signal contacts, the ACA, temperature limits exceeded, changes in the module map, addition or removal of SFP modules, status of power supply has changed and the LLDP and Sntp features. May be enabled or disabled.

Default: enabled.

### Layer 2 Redundancy

Indicates whether traps that are related to the layer 2 redundancy features of the switch will be sent. The HiPER-Ring and the Redundant Coupling will tell you with these traps when the main line has become inoperative or returned. May be enabled or disabled.

Default: enabled.

### Link Up/Down Flag

May be enabled or disabled. The factory default is enabled. Indicates whether link status traps will be sent.

### Multiple Users Flag

May be enabled or disabled. The factory default is enabled. Indicates whether a trap will be sent when the same user ID is logged into the switch more than once at the same time (either via telnet or serial port).



**Port Security (MAC, IP and 802.1X)**

Enable/disable sending port security event traps (for MAC/IP port security as well as for 802.1X).

**Spanning Tree Flag**

May be enabled or disabled. The factory default is enabled. Indicates whether spanning tree traps will be sent.

#### 4.6.47 snmp-access global

This command configures the global SNMP access setting (for all SNMP versions).

**Format**

```
snmp-access global {disable|enable|read-only}
```

**Mode**

```
Global Config
```

**disable**

Disable SNMP access to this switch, regardless of the SNMP version used.

**enable**

Enable SNMP read and write access to this switch, regardless of the SNMP version used.

**read-only**

Enable SNMP read-only access to this switch (disable write access), regardless of the SNMP version used.

### 4.6.48 snmp-access version

This command configures the SNMP version specific access mode for SNMPv1 and SNMPv2.

**Format**

```
snmp-access version {all|v1|v2} {disable|enable}
```

**Mode**

Global Config

**all**

Enable or disable SNMP access by all protocol versions (v1 and v2).

**v1**

Enable or disable SNMP access by v1.

**v2**

Enable or disable SNMP access by v2.

### 4.6.49 snmp-access version v3-encryption

Use this command to activate/deactivate SNMPv3 data encryption.

**Format**

```
snmp-access version v3-encryption  
                    {readonly | readwrite} {enable | disable}
```

**Mode**

Global Config

**disable**

Disable SNMP access to this switch by SNMPv3 protocol version.

**enable**

Enable SNMP read and write access to this switch by SNMPv3 protocol version.

**readonly**

Enable SNMP read-only access to this switch (disable write access) by SNMPv33 protocol version.

**readwrite**

Enable SNMP read-write access to this switch (enable write access) by SNMPv3 protocol version.

### 4.6.50 snmp-server

This command sets the name and the physical location of the switch, and the organization responsible for the network. The range for name, location and contact is from 0 to 64 alphanumeric characters.

**Default**

None

**Format**

```
snmp-server
{community <name> |
 ipaddr <ipaddr> <name> |
 ipmask <ipmask> <name> |
 mode <name> |
 ro <name> |
 rw <name> |
 contact <con> |
 enable traps { chassis | l2redundancy |
  linkmode | multiusers | port-sec | stpmode }
 location <loc> |
 sysname <name> }
```

**Mode**

Global Config

### 4.6.51 snmp-server community

This command adds a new SNMP community name. A community name is a name associated with the switch and with a set of SNMP managers that manage it with a specified privileged level. The length of name can be up to 32 case-sensitive characters.

**Note:** Community names in the SNMP community table must be unique. When making multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

#### Default

Two default community names: Public and Private. You can replace these default community names with unique identifiers for each community. The default values for the remaining four community names are blank.

#### Format

```
snmp-server community <name>
```

#### Mode

```
Global Config
```

#### U no snmp-server community

This command removes this community name from the table. The name is the community name to be deleted.

#### Format

```
no snmp-server community <name>
```

#### Mode

```
Global Config
```

### 4.6.52 snmp-server contact

This command adds a new SNMP server contact.

**Format**

```
snmp-server contact <con>
```

**Mode**

```
Global Config
```

**con**

Enter system contact up to 63 characters in length.

If the name contains spaces, enclose it in quotation marks (").

**U no snmp-server contact**

This command removes this SNMP server contact from the table.

<con> is the SNMP server contact to be deleted.

**Format**

```
no snmp-server contact <con>
```

**Mode**

```
Global Config
```

### 4.6.53 snmp-server community ipaddr

This command sets a client IP address for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP mask value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 0.0.0.0 allows access from any IP address. Otherwise, this value is ANDed with the mask to determine the range of allowed client IP addresses. The name is the applicable community name.

**Default**

0.0.0.0

**Format**

```
snmp-server community ipaddr <ipaddr> <name>
```

**Mode**

Global Config

**U no snmp-server community ipaddr**

This command sets a client IP address for an SNMP community to 0.0.0.0. The name is the applicable community name.

**Format**

```
no snmp-server community ipaddr <name>
```

**Mode**

Global Config

### 4.6.54 snmp-server community ipmask

This command sets a client IP mask for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP address value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 255.255.255.255 will allow access from only one station, and will use that machine's IP address for the client IP Address. A value of 0.0.0.0 will allow access from any IP address. The name is the applicable community name.

**Default**

0.0.0.0

**Format**

```
snmp-server community ipmask <ipmask> <name>
```

**Mode**

Global Config

**U no snmp-server community ipmask**

This command sets a client IP mask for an SNMP community to 0.0.0.0. The name is the applicable community name. The community name may be up to 32 alphanumeric characters.

**Format**

```
no snmp-server community ipmask <name>
```

**Mode**

Global Config

### 4.6.55 snmp-server community mode

This command activates an SNMP community. If a community is enabled, an SNMP manager associated with this community manages the switch according to its access right. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

**Default**

The default private and public communities are enabled by default. The four undefined communities are disabled by default.

**Format**

```
snmp-server community mode <name>
```

**Mode**

Global Config

**U no snmp-server community mode**

This command deactivates an SNMP community. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

**Format**

```
no snmp-server community mode <name>
```

**Mode**

Global Config



### 4.6.56 snmp-server community ro

This command restricts access to switch information. The access mode is read-only (also called public).

**Format**

```
snmp-server community ro <name>
```

**Mode**

```
Global Config
```

### 4.6.57 snmp-server community rw

This command restricts access to switch information. The access mode is read/write (also called private).

**Format**

```
snmp-server community rw <name>
```

**Mode**

```
Global Config
```

### 4.6.58 snmp-server location

This command configures the system location.

**Format**

```
snmp-server location <system location>
```

**Mode**

```
Global Config
```

### 4.6.59 snmp-server sysname

This command configures the system name.

**Format**

```
snmp-server sysname <system name>
```

**Mode**

```
Global Config
```

### 4.6.60 snmp-server enable traps

This command enables the Authentication Trap Flag.

**Default**

```
enabled
```

**Format**

```
snmp-server enable traps
```

**Mode**

```
Global Config
```

U no snmp-server enable traps

This command disables the Authentication Trap Flag.

**Format**

```
no snmp-server enable traps
```

**Mode**

```
Global Config
```

### 4.6.61 snmp-server enable traps chassis

Configures whether traps that are related to the chassis functionality of the switch will be sent. These functions include the signal contacts, the ACA, temperature limits exceeded, changes in the module map, addition or removal of SFP modules, status of power supply has changed and the LLDP and SNTTP features. May be enabled or disabled.

Default: enabled.

**Default**

enabled

**Format**

```
snmp-server enable traps chassis
```

**Mode**

Global Config

**U no snmp-server enable traps chassis**

This command disables chassis traps for the entire switch.

**Format**

```
no snmp-server enable traps chassis
```

**Mode**

Global Config

### 4.6.62 snmp-server enable traps l2redundancy

Indicates whether traps that are related to the layer 2 redundancy features of the switch will be sent. The HiPER-Ring and the Redundant Coupling will tell you with these traps when the main line has become inoperative or returned. May be enabled or disabled.

Default: enabled.

**Default**

enabled

**Format**

```
snmp-server enable traps l2redundancy
```

**Mode**

Global Config

**U** no snmp-server enable traps l2redundancy

This command disables layer 2 redundancy traps for the entire switch.

**Format**

```
no snmp-server enable traps l2redundancy
```

**Mode**

Global Config

### 4.6.63 snmp-server enable traps linkmode

This command enables Link Up/Down traps for the entire switch. When enabled, link traps are sent only if the Link Trap flag setting associated with the port is enabled (see 'snmp trap link-status' command).

**Default**

enabled

**Format**

```
snmp-server enable traps linkmode
```

**Mode**

Global Config

**U no snmp-server enable traps linkmode**

This command disables Link Up/Down traps for the entire switch.

**Format**

```
no snmp-server enable traps linkmode
```

**Mode**

Global Config

### 4.6.64 snmp-server enable traps multiusers

This command enables Multiple User traps. When the traps are enabled, a Multiple User Trap is sent when a user logs in to the terminal interface (EIA 232 (serial port) or telnet) and there is an existing terminal interface session.

**Default**

enabled

**Format**

```
snmp-server enable traps multiusers
```

**Mode**

Global Config

**U** no snmp-server enable traps multiusers  
This command disables Multiple User traps.

**Format**

```
no snmp-server enable traps multiusers
```

**Mode**

Global Config

### 4.6.65 snmp-server enable traps port-sec

This command enables port security traps. When the traps are enabled, a Port Security Trap is sent if a port security event occurs (applies to MAC/IP Port Security as well as to 802.1X Port Security).

**Default**

enabled

**Format**

```
snmp-server enable traps port-sec
```

**Mode**

Global Config

**U** no snmp-server enable traps port-sec  
This command disables Port Security traps.

**Format**

```
no snmp-server enable traps port-sec
```

**Mode**

Global Config

### 4.6.66 snmp-server enable traps stpmode

This command enables the sending of new root traps and topology change notification traps.

**Default**

enabled

**Format**

```
snmp-server enable traps stpmode
```

**Mode**

Global Config

**U** no snmp-server enable traps stpmode

This command disables the sending of new root traps and topology change notification traps.

**Format**

```
no snmp-server enable traps stpmode
```

**Mode**

Global Config



### 4.6.67 snmptrap

This command adds an SNMP trap name. The maximum length of name is 32 case-sensitive alphanumeric characters.

**Default**

The default name for the six undefined community names is Delete.

**Format**

```
snmptrap <name> <ipaddr> [snmpversion snmpv1]
```

**Mode**

Global Config

**U no snmptrap**

This command deletes trap receivers for a community.

**Format**

```
no snmptrap <name> <ipaddr>
```

**Mode**

Global Config

### 4.6.68 snmptrap ipaddr

This command assigns an IP address to a specified community name. The maximum length of name is 32 case-sensitive alphanumeric characters.

**Note:** IP addresses in the SNMP trap receiver table must be unique. If you make multiple entries using the same IP address, the first entry is retained and processed. All duplicate entries are ignored.

**Format**

```
snmptrap ipaddr <name> <ipaddr> <ipaddrnew>
```

**Mode**

Global Config

**ipaddr**

Enter the old IP Address.

**ipaddrnew**

Enter the new IP Address.

### 4.6.69 snmptrap mode

This command activates or deactivates an SNMP trap. Enabled trap receivers are active (able to receive traps). Disabled trap receivers are inactive (not able to receive traps).

**Format**

```
snmptrap mode <name> <ipaddr>
```

**Mode**

```
Global Config
```

**U no snmptrap mode**

This command deactivates an SNMP trap. Disabled trap receivers are inactive (not able to receive traps).

**Format**

```
no snmptrap mode <name> <ipaddr>
```

**Mode**

```
Global Config
```

### 4.6.70 snmptrap snmpversion

This command configures SNMP trap version for a specified community.

**Format**

```
snmptrap snmpversion <name> <ipAddr>
    {snmpv1 | snmpv2}
```

**Mode**

Global Config

**name**

Enter the community name.

**ipAddr**

Enter the IP Address.

**snmpv1**

Use SNMP v1 to send traps.

**snmpv2**

Use SNMP v2 to send traps.

### 4.6.71 telnetcon maxsessions

Configure the number of remote telnet connections allowed.

**Default**

5

**Format**

```
telnetcon maxsessions <0-5>
```

**Mode**

Privileged EXEC

**U no telnetcon maxsessions**

This command sets the maximum number of telnet connection sessions that can be established to the default value.

**Format**

```
no telnetcon maxsessions
```

**Mode**

Privileged EXEC

## 4.6.72 telnetcon timeout

This command sets the telnet connection session timeout value, in minutes. A session is active as long as the session has not been idle for the value set. The time is a decimal value from 1 to 160.

**Default**

5

**Format**

```
telnetcon timeout <1-160>
```

**Mode**

Privileged EXEC

**U no telnetcon timeout**

This command sets the telnet connection session timeout value to the default.

Changing the timeout value for active sessions does not become effective until the session is reaccessed. Also, any keystroke activates the new timeout duration.

**Format**

```
no telnetcon timeout
```

**Mode**

Privileged EXEC

## 4.7 Syslog Commands

This section provides a detailed explanation of the Syslog commands. The commands are divided into two functional groups:

- D Show commands display spanning tree settings, statistics, and other information.
- D Configuration Commands configure features and options of the device. For every configuration command there is a show command that displays the configuration setting.

### 4.7.1 logging buffered

This command enables logging to an in-memory log where up to 128 logs are kept.

**Default**

enabled

**Format**

logging buffered

**Mode**

Global Config

U no logging buffered

This command disables logging to in-memory log.

**Format**

no logging buffered

## 4.7.2 logging buffered wrap

This command enables wrapping of in-memory logging when full capacity reached. Otherwise when full capacity is reached, logging stops.

### Default

wrap

### Format

logging buffered wrap

### Mode

Privileged EXEC

### U no logging buffered wrap

This command disables wrapping of in-memory logging and configures logging to stop when capacity is full.

### Format

no logging buffered wrap



### 4.7.3 logging cli-command

This command enables the CLI command Logging feature. The Command Logging component enables the switch software to log all Command Line Interface (CLI) commands issued on the system.

**Default**

disabled

**Format**

logging cli-command

**Mode**

Global Config

U no logging cli-command

This command disables the CLI command Logging feature.

**Format**

no logging cli-command

## 4.7.4 logging console

This command enables logging to the console. The <severitylevel> value is specified as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), debug (7).

### Default

```
disabled; alert
```

### Format

```
logging console [severitylevel] | <[0-7]>
```

### Mode

```
Global Config
```

### severitylevel | [0-7]

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

Note: selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

Possible severity levels: see Table 15

### U no logging console

This command disables logging to the console.

### Format

```
no logging console
```

### 4.7.5 logging host

This command enables logging to a host where up to eight hosts can be configured.

#### Default

```
Port - 514; Level - Critical;
```

#### Format

```
logging host <hostaddress>
  [<port> [<severitylevel>]]
```

#### Mode

```
Global Config
```

Severity number	Severity name	Meaning
0	emergency	Minimum severity to be logged is 0. This is the highest level and will result in all other messages of lower levels not being logged.
1	alert	Minimum severity to be logged is 1.
2	critical	Minimum severity to be logged is 2.
3	error	Minimum severity to be logged is 3.
4	warning	Minimum severity to be logged is 4.
5	notice	Minimum severity to be logged is 5.
6	info	Minimum severity to be logged is 6.
7	debug	Minimum severity to be logged is 7. This is the lowest level and will result in messages of all levels being logged.

*Tab. 15: Possible severity levels*

### 4.7.6 logging host reconfigure

The Logging Host Index for which to change the IP Address.

**Format**

```
logging host reconfigure <hostindex> <hostaddress>
```

**Mode**

Global Config

### 4.7.7 logging host remove

The Logging Host Index to be removed.

**Format**

```
logging host remove <hostindex>
```

**Mode**

Global Config

### 4.7.8 logging snmp-requests get operation

This command enables or disables the logging of SNMP GET requests.

**Default**

Disabled

**Format**

```
logging snmp-requests get operation  
{ enable | disable }
```

**Mode**

Global Config

### 4.7.9 logging snmp-requests set operation

This command enables or disables the logging of SNMP SET requests.

**Default**

Disabled

**Format**

```
logging snmp-requests set operation
    { enable | disable }
```

**Mode**

Global Config

### 4.7.10 logging snmp-requests get severity

With this command you can define the severity level of logging SNMP GET requests.

**Default**

Disabled

**Format**

```
logging snmp-requests get severity <level|[0-7]>
```

**Mode**

Global Config

**level | [0-7]**

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

Note: selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

### 4.7.11 logging snmp-requests set severity

With this command you can define the severity level of logging SNMP SET requests.

**Default**

Disabled

**Format**

```
logging snmp-requests set severity <level|[0-7]>
```

**Mode**

Global Config

**level | [0-7]**

Enter Logging Severity Level (emergency|0, alert|1, critical|2, error|3, warning|4, notice|5, info|6, debug|7).

Note: selecting a lower severity level (larger number) will include all messages from higher severity levels (smaller numbers).

### 4.7.12 logging syslog

This command enables syslog logging.

**Default**

disabled

**Format**

logging syslog

**Mode**

Global Config

U no logging syslog

This command disables syslog logging.

**Format**

no logging syslog

### 4.7.13 logging syslog port

Enter the port number of the syslog server.

**Default**

514

**Format**

logging syslog port <portid>

**Mode**

Global Config

## 4.8 Scripting Commands

Configuration Scripting allows the user to generate text-formatted script files representing the current configuration. These configuration script files can be uploaded to a PC and edited, downloaded to the system and applied to the system. Configuration scripts can be applied to one or more switches with no/minor modifications.

Use the `show running-config` command to capture the running configuration into a script. Use the `copy` command to transfer the configuration script to and from the switch.

Scripts are intended to be used on systems with default configuration but users are not prevented from applying scripts on systems with non-default configurations.

### Note:

- D The file extension must be “.cli”.
- D A maximum of ten scripts are allowed on the switch.
- D The combined size of all script files on the switch shall not exceed 1024 KB.

### 4.8.1 `script apply`

This command applies the commands in the script to the switch. We recommend that the system have default configurations but users are not prevented from applying scripts on systems with non-default configurations. The `<scriptname>` parameter is the name of the script to apply.

#### Format

```
script apply <scriptname>
```

#### Mode

```
Privileged EXEC
```



## 4.8.2 script delete

This command deletes a specified script where the <scriptname> parameter is the name of the script to be deleted. The 'all' option deletes all the scripts present on the switch.

### Format

```
script delete {<scriptname> | all}
```

### Mode

Privileged EXEC

## 4.8.3 script list

This command lists all scripts present on the switch as well as the remaining available space.

### Format

```
script list [aca]
```

### Mode

Privileged EXEC

### Configuration Script

Name of the script.

Without the optional ACA parameter: Listing of the scripts in the switch's flash memory.

With the optional ACA parameter: Listing of the scripts on the external ACA 21-USB.

### Size

Size of the script.

### 4.8.4 script show

This command displays the contents of a script file. The parameter <script-name> is the name of the script file.

**Format**

```
script show <scriptname>
```

**Mode**

Privileged EXEC

The format of display is

Line <no>: <Line contents>

### 4.8.5 script validate

This command validates a script file by parsing each line in the script file where <scriptname> is the name of the script to validate. The validate option is intended to be used as a tool for script development.

Validation identifies potential problems. It may or may not identify all problems with a given script on any given device.

**Format**

```
script validate <scriptname>
```

**Mode**

Privileged EXEC

## 4.9 Device Configuration Commands

### 4.9.1 addport

This command adds one port to the Link Aggregation (LAG). The given interface is a logical slot and port number of a configured Link Aggregation.

**Note:** Before adding a port to a Link Aggregation, set the physical mode of the port. See 'speed' command.

#### **Format**

```
addport <logical slot/port>
```

#### **Mode**

```
Interface Config
```

### 4.9.2 adminmode

This command enables the whole Link Aggregation as one single port.

**Note:** Before adding a port to a Link Aggregation, set the physical mode of the port. See 'speed' command.

**Format**

adminmode

**Mode**

Interface Config

**U no adminmode**

This command disables the whole Link Aggregation as one single port.

**Format**

no adminmode

**Mode**

Interface Config

### 4.9.3 auto-negotiate

This command enables automatic negotiation on a port. The default value is enable.

**Format**

```
auto-negotiate
```

**Mode**

```
Interface Config
```

**U no auto-negotiate**

This command disables automatic negotiation on a port.

**Format**

```
no auto-negotiate
```

**Mode**

```
Interface Config
```

## 4.9.4 cable-crossing

**Note:** The `cable-crossing` function is available for the RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH 1000, PowerMICE and OCTOPUS devices.

Enable or disable the cable crossing function.

**Note:** The `cable-crossing` settings become effective for a certain port, if `auto-negotiate` is disabled for this port.

The `cable-crossing` settings are irrelevant for a certain port, if `auto-negotiate` is enabled for this port.

### Format

```
cable-crossing {enable|disable}
```

### Mode

```
Interface Config
```

### **cable-crossing enable**

The device swaps the port output and port input of the TP port.

### **cable-crossing disable**

The device does not swap the port output and port input of the TP port.

### 4.9.5 auto-negotiate all

This command enables automatic negotiation on all ports. The default value is enable.

**Format**

```
auto-negotiate all
```

**Mode**

```
Global Config
```

**U** no auto-negotiate all

This command disables automatic negotiation on all ports.

**Format**

```
no auto-negotiate all
```

**Mode**

```
Global Config
```

### 4.9.6 media-module remove

This command logically removes a media-module that has already been physically removed.

**Format**

```
media-module remove <1..n>
```

**Mode**

```
Global Config
```

### 4.9.7 deleteport

This command deletes the port from the link-aggregation (LAG). The interface is a logical slot and port number of a configured link aggregation.

**Note:** This command has to be issued in the member port's interface config mode.

**Format**

```
deleteport <logical slot/port>
```

**Mode**

```
Interface Config
```

### 4.9.8 deleteport all

This command deletes all configured ports from the link-aggregation (LAG). The interface is a logical slot and port number of a configured link-aggregation.

**Format**

```
deleteport <logical slot/port> all
```

**Mode**

```
Global Config
```



### 4.9.9 macfilter

This command adds a static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The restricted MAC Addresses are: 00:00:00:00:00:00, 01:80:C2:00:00:00 to 01:80:C2:00:00:0F, 01:80:C2:00:00:20 to 01:80:C2:00:00:21, and FF:FF:FF:FF:FF:FF.

The <vlanid> parameter must identify a valid VLAN (1 to 4042) .

Up to 100 static MAC filters may be created.

**Format**

```
macfilter <macaddr> <vlanid>
```

**Mode**

```
Global Config
```

**U no macfilter**

This command removes all filtering restrictions and the static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

**Format**

```
no macfilter <macaddr> <vlanid>
```

**Mode**

```
Global Config
```

### 4.9.10 macfilter adddest

This command adds the interface to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1-4042).

**Format**

```
macfilter adddest <macaddr> <vlanid>
```

**Mode**

```
Interface Config
```

**U no macfilter adddest**

This command removes a port from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1-4042).

**Format**

```
no macfilter adddest <macaddr> <vlanid>
```

**Mode**

```
Interface Config
```

### 4.9.11 macfilter adddest all

This command adds all interfaces to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

**Format**

```
macfilter adddest {all | <macaddr> <vlanid>}
```

**Mode**

```
Global Config
```

**U no macfilter adddest all**

This command removes all ports from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN (1 to 4042).

**Format**

```
no macfilter adddest [all | <macaddr> <vlanid>}
```

**Mode**

```
Global Config
```

### 4.9.12 monitor session <session-id>

This command configures a probe port and a monitored port for monitor session (port monitoring). The first slot/port is the source monitored port and the second slot/port is the destination probe port. If this command is executed while port monitoring is enabled, it will have the effect of changing the probe and monitored port values.

**Format**

```
monitor session <session-id>  
  [mode | {source | destination}  
  interface <slot/port>]
```

**Mode**

Global Config

**destination**

Configure the probe interface.

**mode**

Enable/Disable port mirroring session.

Note: does not affect the source or destination interfaces.

**source**

Configure the source interface.

**session-id**

Session number (currently, session number 1 is supported).

**U no monitor session <session-id>**

This command removes the monitor session (port monitoring) designation from both the source probe port and the destination monitored port and removes the probe port from all VLANs. The port must be manually re-added to any desired VLANs.

**Format**

```
no monitor session <session-id> [mode]
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

### 4.9.13 monitor session <session-id> mode

This command configures the monitor session (port monitoring) mode to enable. The probe and monitored ports must be configured before monitor session (port monitoring) can be enabled. If enabled, the probe port will monitor all traffic received and transmitted on the physical monitored port. It is not necessary to disable port monitoring before modifying the probe and monitored ports.

**Default**

disabled

**Format**

```
monitor session <session-id> mode
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

**U no monitor session <session-id> mode**

This command sets the monitor session (port monitoring) mode to disable.

**Format**

```
no monitor session <session-id> mode
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

### 4.9.14 monitor session <session-id> source/ destination

This command allows you to configure and activate the port mirroring function of the switch. Port mirroring is when the data traffic of a source port is copied to a specified destination port. The data traffic at the source port is not influenced by port mirroring. A management tool connected at the specified port, e.g., an RMON probe, can thus monitor the data traffic of the source port.

This command can be called multiple times with different ports to add more than one source port to the session.

It is possible to add/remove ports to/from an active session.

**Note:**

- The device supports a maximum of one session.
- The maximum number of source ports is 8.
- Ports configured as mirror source or destination ports have to be physical ports.

**Note:** In active port mirroring, the specified destination port is used solely for observation purposes.

**Default**

none

**Format**

```
monitor session <session-id> {source | destination}  
interface <slot/port>
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

- U no monitor session <session-id> source/destination  
This command resets the monitor session (port monitoring) source/destination. The port will be removed from port mirroring

**Format**

```
no monitor session <session-id> {source | destination} interface
```

**Mode**

Global Config

**session-id**

Session number (currently, session number 1 is supported).

### 4.9.15 link-aggregation

This command configures a new Link Aggregation (LAG) and generates a logical slot/port number for the Link Aggregation. Display this number using the “show link-aggregation”.

**Note:** Before including a port in a Link Aggregation, set the port physical mode. See ‘speed’ command.

**Format**

```
link-aggregation <name>
```

**Mode**

Global Config

### 4.9.16 link-aggregation adminmode

This command enables a Link Aggregation (LAG). The interface is a logical slot/port for a configured Link Aggregation. The option `all` sets every configured Link Aggregation with the same administrative mode setting.

**Format**

```
link-aggregation adminmode all
```

**Mode**

```
Global Config
```

**U no link-aggregation adminmode**

This command disables a Link Aggregation (LAG). The interface is a logical slot/port for a configured Link Aggregation. The option `all` sets every configured Link Aggregation with the same administrative mode setting.

**Format**

```
no link-aggregation adminmode all
```

**Mode**

```
Global Config
```



### 4.9.17 link-aggregation linktrap

This command enables link trap notifications for the link-aggregation (LAG). The interface is a logical slot/port for a configured link-aggregation. The option `all` sets every configured link-aggregation with the same administrative mode setting.

**Default**

enabled

**Format**

```
link-aggregation linktrap {<logical slot/port> /  
all}
```

**Mode**

Global Config

**U no link-aggregation linktrap**

This command disables link trap notifications for the link-aggregation (LAG). The interface is a logical unit, slot and port slot and port for a configured link-aggregation. The option `all` sets every configured link-aggregation with the same administrative mode setting.

**Format**

```
no link-aggregation linktrap {<logical slot/port> /  
all}
```

**Mode**

GlobalConfig

### 4.9.18 link-aggregation name

This command defines a name for the link-aggregation (LAG). The interface is a logical slot/port for a configured link-aggregation, and name is an alphanumeric string up to 15 characters. This command is used to modify the name that was associated with the link-aggregation when it was created.

**Format**

```
link-aggregation name {<logical slot/port> | all |  
<name>}
```

**Mode**

Global Config

### 4.9.19 rmon-alarm add

This command adds an RMON alarm.

**Format**

```
rmon-alarm add <index>  
                [<mib-variable>  
                <rising-threshold>  
                <falling-threshold>]
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**mib-variable**

Enter the MIB variable.

**rising-threshold**

Enter the rising threshold for the RMON alarm.

**falling-threshold**

Enter the falling threshold for the RMON alarm.

### 4.9.20 rmon-alarm delete

This command deletes an RMON alarm.

**Format**

```
rmon-alarm delete <index>
```

**Mode**

```
Global Config
```

**index**

Enter the index of the RMON alarm.

### 4.9.21 rmon-alarm enable

This command enables an RMON alarm.

**Format**

```
rmon-alarm enable <index>
```

**Mode**

```
Global Config
```

**index**

Enter the index of the RMON alarm.

### 4.9.22 rmon-alarm disable

This command disables an RMON alarm.

**Format**

```
rmon-alarm disable <index>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

### 4.9.23 rmon-alarm modify mib-variable

This command modifies the mib-variable of an RMON alarm.

**Format**

```
rmon-alarm modify <index> mib-variable <mib-variable>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**mib-variable**

Enter the MIB variable.

### 4.9.24 rmon-alarm modify thresholds

This command modifies the thresholds of an RMON alarm.

**Format**

```
rmon-alarm modify <index> thresholds  
                    <rising-threshold>  
                    <falling-threshold>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**rising-threshold**

Enter the rising threshold for the RMON alarm.

**falling-threshold**

Enter the falling threshold for the RMON alarm.

### 4.9.25 rmon-alarm modify interval

This command modifies the interval of an RMON alarm.

**Format**

```
rmon-alarm modify <index> interval <interval>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**interval**

Enter the interval for the RMON alarm.

### 4.9.26 rmon-alarm modify sample-type

This command modifies the sample-type of an RMON alarm.

**Format**

```
rmon-alarm modify <index> sample-type {absolute|delta}
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**absolute**

Sample-type for RMON alarm is absolute.

**delta**

Sample-type for RMON alarm is delta.

### 4.9.27 rmon-alarm modify startup-alarm

This command modifies the startup-alarm of an RMON alarm.

**Format**

```
rmon-alarm modify <index> startup-alarm  
                    {rising | falling | risingorfalling}
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**rising**

Start-up alarm if the value is rising.

**falling**

Start-up alarm if the value is falling.

**risingorfalling**

Start-up alarm if the value is rising or falling.

### 4.9.28 rmon-alarm modify rising-event

This command modifies the rising-event of an RMON alarm.

**Format**

```
rmon-alarm modify <index> rising-event  
                    <rising-event-index>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**rising-event-index**

Enter the index for the rising event for the RMON alarm.

### 4.9.29 rmon-alarm modify falling-event

This command modifies the falling-event of an RMON alarm.

**Format**

```
rmon-alarm modify <index> falling-event  
                    <falling-event-index>
```

**Mode**

Global Config

**index**

Enter the index of the RMON alarm.

**falling-event-index**

Enter the index for the falling event for the RMON alarm.

### 4.9.30 set garp timer join

This command sets the GVRP join time per port and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or re-registering) membership for a VLAN or multicast group. This command has an effect only when GVRP is enabled. The time is from 10 to 100 (centiseconds). The value 20 centiseconds is 0.2 seconds.

**Default**

20

**Format**

```
set garp timer join <10-100>
```

**Mode**

Global Config  
Interface Config

**U no set garp timer join**

This command sets the GVRP join time per port and per GARP to 20 centiseconds (0.2 seconds). This command has an effect only when GVRP is enabled.

**Format**

```
no set garp-timer join
```

**Mode**

Global Config  
Interface Config



### 4.9.31 set garp timer leave

This command sets the GVRP leave time per port. Leave time is the time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. time is 20 to 600 (centiseconds). The value 60 centiseconds is 0.6 seconds.

**Note:** This command has an effect only when GVRP is enabled.

#### Default

60

#### Format

```
set garp timer leave <20-600>
```

#### Mode

Global Config

Interface Config

U no set garp timer leave

T This command sets the GVRP leave time per port to 60 centiseconds (0.6 seconds).

**Note:** This command has an effect only when GVRP is enabled.

#### Format

```
no set garp timer leave
```

#### Mode

Global Config

Interface Config

### 4.9.32 set garp timer leaveall

This command sets how frequently *Leave All PDUs* are generated per port. A *Leave All PDU* indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds). The value 1000 centiseconds is 10 seconds.

**Note:** This command has an effect only when GVRP is enabled.

**Default**

1000

**Format**

```
set garp timer leaveall <200-6000>
```

**Mode**

Global Config  
Interface Config

**U no set garp timer leaveall**

This command sets how frequently *Leave All PDUs* are generated per port to 1000 centiseconds (10 seconds).

**Note:** This command has an effect only when GVRP is enabled.

**Format**

```
no set garp timer leaveall
```

**Mode**

Global Config  
Interface Config

### 4.9.33 set gmrp adminmode

This command enables GARP Multicast Registration Protocol (GMRP) on the system. The default value is disable.

**Format**

```
set gmrp adminmode
```

**Mode**

```
Privileged EXEC and Global Config
```

U no set gmrp adminmode

This command disables GARP Multicast Registration Protocol (GMRP) on the system.

**Format**

```
no set gmrp adminmode
```

**Mode**

```
Privileged EXEC and Global Config
```

### 4.9.34 set gmrp interfacemode

This command enables GARP Multicast Registration Protocol on a selected interface. If an interface which has GARP enabled is enlisted as a member of a Link Aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if Link Aggregation (LAG) membership is removed from an interface that has GARP enabled.

**Default**

enabled

**Format**

```
set gmrp interfacemode
```

**Mode**

Interface Config

**U no set gmrp interfacemode**

This command disables GARP Multicast Registration Protocol on a selected interface. If an interface which has GARP enabled is enlisted as a member of a Link Aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if Link Aggregation (LAG) membership is removed from an interface that has GARP enabled.

**Format**

```
no set gmrp interfacemode
```

**Mode**

Interface Config

### 4.9.35 set gmrp interfacemode

This command enables GARP Multicast Registration Protocol on all interfaces. If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a link-aggregation (LAG), GARP functionality will be disabled on that interface. GARP functionality will subsequently be re-enabled if routing is disabled and link-aggregation (LAG) membership is removed from an interface that has GARP enabled.

**Default**

disabled

**Format**

```
set gmrp interfacemode
```

**Mode**

Global Config

**U no set gmrp interfacemode**

This command disables GARP Multicast Registration Protocol on a selected interface.

**Format**

```
no set gmrp interfacemode
```

**Mode**

Global Config

### 4.9.36 set gmrp forward-all-groups

This command enables the GMRP Multicast Registration Protocol feature 'Forward All Groups' for all ports.

**Default**

disabled

**Format**

```
set gmrp forward-all-groups
```

**Mode**

Interface Config

Global Config

**U no set gmrp forward-all-groups**

This command disables the GMRP Multicast Registration Protocol feature 'Forward All Groups' for all ports.

**Format**

```
no set gmrp forward-all-groups
```

**Mode**

Interface Config

Global Config

### 4.9.37 set igmp

This command enables IGMP Snooping on the system. The default value is disable.

**Note:** The IGMP snooping application supports the following:

- D Global configuration or per interface configuration.
- D Validation of the IP header checksum (as well as the IGMP header checksum) and discarding of the frame upon checksum error.
- D Maintenance of the forwarding table entries based on the MAC address versus the IP address.
- D Flooding of unregistered multicast data packets to all ports in the VLAN.

#### Format

```
set igmp
```

#### Mode

```
Global Config
```

U no set igmp

This command disables IGMP Snooping on the system.

#### Format

```
no set igmp
```

#### Mode

```
Global Config
```

### 4.9.38 set igmp

This command enables IGMP Snooping on a selected interface.

**Default**

enabled

**Format**

set igmp

**Mode**

Interface Config

**U no set igmp**

This command disables IGMP Snooping on a selected interface.

**Format**

no set igmp

**Mode**

Interface Config



### 4.9.39 set igmp aging-time-unknown

This command configures the IGMP Snooping aging time for unknown multicast frames (unit: seconds, min.: 3, max.: 3,600, default: 260).

**Format**

```
set igmp aging-time-unknown <3-3600>
```

**Mode**

```
Global Config
```

### 4.9.40 set igmp automatic-mode

If enabled, this port is allowed to be set as static query port automatically, if the LLDP protocol has found a switch or router connected to this port. Use the command's normal form to enable the feature, the 'no' form to disable it.

**Default**

```
disabled (RS20: enabled)
```

**Format**

```
set igmp automatic-mode
```

**Mode**

```
Interface Config
```

### 4.9.41 set igmp forward-all

This command activates the forwarding of multicast frames to this interface even if the given interface has not received any reports by hosts. N. B.: this applies only to frames that have been learned via IGMP Snooping. The purpose is that an interface (e. g. a HIPER Ring's ring port) may need to forward all such frames even if no reports have been received on it. This enables faster recovery from ring interruptions for multicast frames.

**Default**

disabled

**Format**

```
set igmp forward-all
```

**Mode**

Interface Config

**U no set igmp forward-all**

This command disables the forwarding of all multicast frames learned via IGMP Snooping on a selected interface.

**Format**

```
no set igmp forward-all
```

**Mode**

Interface Config

## 4.9.42 set igmp forward-unknown

**Note:** This command is available for MS20/MS30.

This command defines how to handle unknown multicast frames.

**Format**

```
set igmp forward-unknown
    { discard | flood | query-ports }
```

**Mode**

```
Global Config
```

**discard**

Unknown multicast frames will be discarded.

**flood**

Unknown multicast frames will be flooded.

**query-ports**

Unknown multicast frames will be forwarded only to query ports.

### 4.9.43 set igmp static-query-port

This command activates the forwarding of IGMP membership report frames to this interface even if the given interface has not received any queries. The purpose is that a port may need to forward such frames even if no queries have been received on it (e. g., if a router is connected to the interface that sends no queries).

**Default**

disabled

**Format**

```
set igmp static-query-port
```

**Mode**

Interface Config

**U no set igmp**

This command disables the unconditional forwarding of IGMP membership report frames to this interface.

**Format**

```
no set igmp static-query-port
```

**Mode**

Interface Config

#### 4.9.44 set igmp groupmembershipinterval

This command sets the IGMP Group Membership Interval time on the system. The Group Membership Interval time is the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface before deleting the interface from the entry. This value must be greater than the IGMP Maximum Response time value. The range is 3 to 3,600 seconds.

**Default**

260

**Format**

```
set igmp groupmembershipinterval <3-3600>
```

**Mode**

Global Config

**U no set igmp groupmembershipinterval**

This command sets the IGMP Group Membership Interval time on the system to 260 seconds.

**Format**

```
no set igmp groupmembershipinterval
```

**Mode**

Global Config

### 4.9.45 set igmp interfacemode

This command enables IGMP Snooping on all interfaces. If an interface which has IGMP Snooping enabled is enabled for port-based routing or is enlisted as a member of a link-aggregation (LAG), IGMP Snooping functionality will be disabled on that interface. IGMP Snooping functionality will subsequently be re-enabled if routing is disabled or link-aggregation (LAG) membership is removed from an interface that has IGMP Snooping enabled.

**Format**

```
set igmp interfacemode
```

**Mode**

```
Global Config
```

**U no set igmp interfacemode**

This command disables IGMP Snooping on all interfaces.

**Format**

```
no set igmp interfacemode
```

**Mode**

```
Global Config
```

#### 4.9.46 set igmp lookup-interval-unknown

This command configures the IGMP Snooping lookup response time for unknown multicast frames (unit: seconds, min.: 2, max.: 3,599, default: 125).

**Format**

```
set igmp lookup-interval-unknown <2-3599>
```

**Mode**

```
Global Config
```

**<2-3599>**

Enter the IGMP Snooping lookup response time for unknown multicast frames (unit: seconds, min.: 2, max.: 3,599, default: 125).

#### 4.9.47 set igmp lookup-resp-time-unknown

This command configures the IGMP Snooping lookup interval for unknown multicast frames (unit: seconds, min.: 1, max.: 3,598, default: 10).

**Format**

```
set igmp lookup-resp-time-unknown <1-3598>
```

**Mode**

```
Global Config
```

**<2-3598>**

Enter the IGMP Snooping lookup interval for unknown multicast frames (unit: seconds, min.: 1, max.: 3,598, default: 10).

### 4.9.48 set igmp maxresponse

This command sets the IGMP Maximum Response time on the system. The Maximum Response time is the amount of time in seconds that a switch will wait after sending a query in response to a received leave message, before deleting the multicast group received in the leave message. If the switch receives a report in response to the query within the maxresponse time, then the multicast group is not deleted. This value must be less than the IGMP Query Interval time value. The range is 1 to 3,598 seconds.

**Default**

10

**Format**

```
set igmp maxresponse <1-3598>
```

**Mode**

Global Config

**Note:** the IGMP Querier's max. response time was also set. It is always the same value as the IGMP Snooping max. response time.

**U no set igmp maxresponse**

This command sets the IGMP Maximum Response time on the system to 10 seconds.

**Format**

```
no set igmp maxresponse
```

**Mode**

Global Config



### 4.9.49 set igmp querier max-response-time

Configure the IGMP Snooping Querier's maximum response time. The range is 1 to 3,598 seconds. The default value is 10 seconds.

**Default**

10

**Format**

```
set igmp querier max-response-time <1-3598>
```

**Mode**

Global Config

**Note:** The IGMP Snooping max. response time was also set. It is always the same value as the IGMP Querier's max. response time.

### 4.9.50 set igmp querier protocol-version

Configure the IGMP Snooping Querier's protocol version (1, 2 or 3).

**Default**

2

**Format**

```
set igmp querier protocol-version {1 | 2 | 3}
```

**Mode**

Global Config

### 4.9.51 set igmp querier status

Configure the IGMP Snooping Querier's administrative status (enable or disable).

**Default**

disable

**Format**

```
set igmp querier status {enable | disable}
```

**Mode**

Global Config

### 4.9.52 set igmp querier tx-interval

Configure the IGMP Snooping Querier's transmit interval. The range is 2 to 3,599 seconds.

**Default**

125

**Format**

```
set igmp querier tx-interval <2-3599>
```

**Mode**

Global Config

### 4.9.53 set igmp query-ports-to-filter

This command enables or disables the addition of query ports to multicast filter portmasks. The setting can be enable or disable.

**Default**

Disable

**Format**

```
set igmp query-ports-to-filter {enable | disable}
```

**Mode**

Global Config

**enable**

Addition of query ports to multicast filter portmasks.

**disable**

No addition of query ports to multicast filter portmasks.

### 4.9.54 selftest ramtest

Enable or disable the RAM test for a cold start of the device. Deactivating the RAM test reduces the booting time for a cold start of the device.

Default: enabled.

**Format**

```
selftest ramtest {disable|enable}
```

**Mode**

Global Config

**selftest ramtest disable**

Disable the ramtest.

**selftest ramtest enable**

Enable the ramtest. This is the default.

### 4.9.55 selftest reboot-on-error

Enable or disable a restart due to an undefined software or hardware state.  
Default: disabled.

**Format**

```
selftest reboot-on-error  
                        {disable|enable|seriousOnly}
```

**Mode**

Global Config

**selftest reboot-on-error disable**

Disable the reboot-on-error function. This is the default.

**selftest reboot-on-error enable**

Enable the reboot-on-error function.

**selftest reboot-on-error seriousOnly**

The device will only reboot on errors considered to be critical.

**Note:** Duplex mismatch errors are considered to be non-critical. In case of a detected duplex mismatch error, the device will not reboot. Reset the device to restore ports to an usable state.

### 4.9.56 show garp

This command displays Generic Attributes Registration Protocol (GARP) information.

**Format**

```
show garp
```

**Mode**

Privileged EXEC and User EXEC

**GMRP Admin Mode**

This displays the administrative mode of GARP Multicast Registration Protocol (GMRP) for the system.

## 4.9.57 show gmrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

### Format

```
show gmrp configuration {<slot/port> | all}
```

### Mode

Privileged EXEC and User EXEC

### Interface

This displays the slot/port of the interface that this row in the table describes.

### Join Timer

Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10 to 100 centiseconds (0.1 to 1.0 seconds). The factory default is 20 centiseconds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

### Leave Timer

Specifies the period of time to wait after receiving an unregister request for an attribute before deleting the attribute. Current attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

### LeaveAll Timer

This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registrations will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5\*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is

1000 centiseconds (10 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

### **Port GMRP Mode**

Indicates the GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time and Leave All Time have no effect. The factory default is disabled.

## 4.9.58 show igmpsnooping

This command displays IGMP Snooping information. Configured information is displayed whether or not IGMP Snooping is enabled. Status information is only displayed when IGMP Snooping is enabled.

### **Format**

```
show igmpsnooping
```

### **Mode**

**Privileged EXEC and User EXEC**

### **Admin Mode**

This indicates whether or not IGMP Snooping is globally enabled on the switch.

### **Forwarding of Unknown Frames**

This displays if and how unknown multicasts are forwarded. The setting can be Discard, Flood or Query Ports. The default is Query Ports.

### **Group Membership Interval**

This displays the IGMP Group Membership Interval. This is the amount of time a switch will wait for a report for a particular group on a particular interface before it sends a query on that interface. This value may be configured.

### **Multicast Control Frame Count**

This displays the number of multicast control frames that are processed by the CPU.

### **Interfaces Enabled for IGMP Snooping**

This is the list of interfaces on which IGMP Snooping is enabled. Additionally, if a port has a special function, it will be shown to the right of its slot/port number. There are 3 special functions:

Forward All, Static Query Port and Learned Query Port.

### **Querier Status (the administrative state).**

This displays the IGMP Snooping Querier's administrative status.

### **Querier Mode (the actual state, read only)**

This displays the IGMP Snooping Querier's operating status.

### **Querier Transmit Interval**

This displays the IGMP Snooping Querier's transmit interval in seconds.

### **Querier Max. Response Time**

This displays the IGMP Snooping Querier's maximum response time in seconds.

### **Querier Protocol Version**

This displays the IGMP Snooping Querier's protocol version number.

## 4.9.59 show mac-filter-table gmrp

This command displays the GARP Multicast Registration Protocol (GMRP) entries in the Multicast Forwarding Database (MFDB) table.

### Format

```
show mac-filter-table gmrp
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).



## 4.9.60 show mac-filter-table igmpsnooping

This command displays the IGMP Snooping entries in the Multicast Forwarding Database (MFDB) table.

### Format

```
show mac-filter-table igmpsnooping
```

### Mode

Privileged EXEC and User EXEC

### Mac Address

A multicast MAC address for which the switch has forwarding and or filtering information. The format is two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

### Type

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

### Description

The text description of this multicast table entry.

### Interfaces

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

### 4.9.61 show mac-filter-table multicast

This command displays the Multicast Forwarding Database (MFDB) information. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the optional `all` parameter. The user can display the table entry for one MAC Address by specifying the MAC address as an optional parameter.

**Format**

```
show mac-filter-table multicast  
    [<macaddr> <1-4042>]
```

**Mode**

Privileged EXEC and User EXEC

**Mac Address**

A multicast MAC address for which the switch has forwarding and or filtering information. The format is two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

**Type**

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

**Component**

The component that is responsible for this entry in the Multicast Forwarding Database. Possible values are IGMP Snooping, GMRP and Static Filtering.

**Description**

The text description of this multicast table entry.

**Interfaces**

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

**Forwarding Interfaces**

The resultant forwarding list is derived from combining all the component's forwarding interfaces and removing the interfaces that are listed as the static filtering interfaces.

## 4.9.62 show mac-filter-table static

This command displays the Static MAC Filtering information for all Static MAC Filters. If `all` is selected, all the Static MAC Filters in the system are displayed. If a `macaddr` is entered, a `vlan` must also be entered and the Static MAC Filter information will be displayed only for that MAC address and VLAN.

### Format

```
show mac-filter-table static {<macaddr> <vlanid> |  
all}
```

### Mode

Privileged EXEC and User EXEC

### MAC Address

Is the MAC Address of the static MAC filter entry.

### VLAN ID

Is the VLAN ID of the static MAC filter entry.

### Source Port(s)

Indicates the source port filter set's slot and port(s).

### Destination Port(s)

Indicates the destination port filter set's slot and port(s).

### 4.9.63 show mac-filter-table staticfiltering

This command displays the Static Filtering entries in the Multicast Forwarding Database (MFDB) table.

**Format**

```
show mac-filter-table staticfiltering
```

**Mode**

Privileged EXEC and User EXEC

**Mac Address**

A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for example 01:23:45:67:89:AB.

**Type**

This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.

**Description**

The text description of this multicast table entry.

**Interfaces**

The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

## 4.9.64 show mac-filter-table stats

This command displays the Multicast Forwarding Database (MFDB) statistics.

### **Format**

```
show mac-filter-table stats
```

### **Mode**

Privileged EXEC and User EXEC

### **Total Entries**

This displays the total number of entries that can possibly be in the Multicast Forwarding Database table.

### **Most MFDB Entries Ever Used**

This displays the largest number of entries that have been present in the Multicast Forwarding Database table. This value is also known as the MFDB high-water mark.

### **Current Entries**

This displays the current number of entries in the Multicast Forwarding Database table.

## 4.9.65 show monitor session

This command displays the Port monitoring information for the system.

### **Format**

```
show monitor session <Session Number>
```

### **Mode**

Privileged EXEC and User EXEC

### **Session**

Display port monitor session settings.

### **Session Number**

Session Number. Enter 1 for the Session Number.

### **Port Monitor Mode**

indicates whether the Port Monitoring feature is enabled or disabled.  
The possible values are enable and disable.

### **Probe Port slot/port**

is the slot/port configured as the probe port. If this value has not been configured, 'Not Configured' will be displayed.

### **Monitored Port slot/port**

is the slot/port configured as the monitored port. If this value has not been configured, 'Not Configured' will be displayed.

## 4.9.66 show port

This command displays port information.

### Format

```
show port {<slot/port> | all} [name]
```

### Mode

Privileged EXEC and User EXEC

### Slot/Port

Valid slot and port number separated by forward slashes.

### Name

When the optional command parameter `name` was specified, the output is different. It specifically includes the Interface Name as the second column, followed by other basic settings that are also shown by the normal command without the command parameter `name`.

### Type

If not blank, this field indicates that this port is a special type of port. The possible values are:

`Mon` - this port is a monitoring port. Look at the Port Monitoring screens to find out more information.

`LA Mbr` - this port is a member of a Link Aggregation (LAG).

`Probe` - this port is a probe port.

### Admin Mode

Indicates the Port control administration state. The port must be enabled in order for it to be allowed into the network. - May be enabled or disabled. The factory default is enabled.

### Physical Mode

Indicates the desired port speed and duplex mode. If auto-negotiation support is selected, then the duplex mode and speed will be set from the auto-negotiation process. Note that the port's maximum capability (full duplex -100M) will be advertised. Otherwise, this object will determine the port's duplex mode and transmission rate. The factory default is Auto.

### Physical Status

Indicates the port speed and duplex mode.

### Link Status

Indicates whether the Link is up or down.

**Link Trap**

This object determines whether or not to send a trap when link status changes. The factory default is enabled.

**Flow**

Indicates if enable flow control is enabled on this port.

**Device Status**

Indicates whether or not the given port's link status is monitored by the device status.

**VLAN Prio**

This object displays the port VLAN priority.

## 4.9.67 show link-aggregation

This command displays an overview of all link-aggregations (LAGs) on the switch.

**Format**

```
show link-aggregation {<logical slot/port> | all}
```

**Mode**

Privileged EXEC and User EXEC

**Logical slot/port**

Valid slot and port number separated by forward slashes.

**Name**

The name of this link-aggregation (LAG). You may enter any string of up to 15 alphanumeric characters.

**Link State**

Indicates whether the Link is up or down.

**Admin Mode**

May be enabled or disabled. The factory default is enabled.



**Link Trap Mode**

This object determines whether or not to send a trap when link status changes. The factory default is enabled.

**STP Mode**

The Spanning Tree Protocol Administrative Mode associated with the port or link-aggregation (LAG). The possible values are:

`Disable` - Spanning tree is disabled for this port.

`Enable` - Spanning tree is enabled for this port.

**Mbr Ports**

A listing of the ports that are members of this link-aggregation (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a given link-aggregation (LAG).

**Port Speed**

Speed of the link-aggregation port.

**Type**

This field displays the status designating whether a particular link-aggregation (LAG) is statically or dynamically maintained. The possible values of this field are `Static`, indicating that the link-aggregation is statically maintained; and `Dynamic`, indicating that the link-aggregation is dynamically maintained.

**Active Ports**

This field lists the ports that are actively participating in the link-aggregation (LAG).

### 4.9.68 show rmon-alarm

This command displays switch configuration information.

**Format**

```
show rmon-alarm
```

**Mode**

Privileged EXEC and User EXEC

### 4.9.69 show selftest

This command displays switch configuration information.

**Format**

```
show selftest
```

**Mode**

Privileged EXEC and User EXEC

**Ramtest state**

May be enabled or disabled. The factory default is enabled.

**Reboot on error**

May be enabled, disabled or seriousOnly. The factory default is enabled.

## 4.9.70 show storm-control

This command displays switch configuration information.

### **Format**

```
show storm-control
```

### **Mode**

Privileged EXEC and User EXEC

### **Ingress Limiting**

May be enabled or disabled. The factory default is disabled.

### **Ingress Limiter Mode (MACH 4000 and PowerMICE only)**

Sets the global mode for the ingress limiter. The factory default is: Broadcasts only.

### **Egress Broadcast Limiting**

May be enabled or disabled. The factory default is disabled.

### **Egress Limiting (all traffic)**

May be enabled or disabled. The factory default is disabled.

### **802.3x Flow Control Mode**

May be enabled or disabled. The factory default is disabled.

### 4.9.71 show storm-control limiters port

This command displays the limiter settings per port. "0" means that the respective limiter is disabled.

**Format**

```
show storm-control limiters port {<slot/port>|all}
```

**Mode**

Privileged EXEC and User EXEC

**Ingress Mode (RS20/RS30/RS40, MS20/MS30 and OCTOPUS only)**

Shows the mode for the ingress limiter. The factory default is: Broadcasts only.

**Ingress Limit**

Shows the ingress rate limit. The factory default is: 0.

**Egress Broadcast Limit**

Shows the egress broadcast rate limit. The factory default is: 0.

**Egress Limit (all traffic; RS20/RS30/RS40, MS20/MS30 and OCTOPUS only)**

Shows the egress rate limit for all frame types.  
The factory default is: 0.

### 4.9.72 show vlan

This command displays detailed information, including interface information, for a specific VLAN. The ID is a valid VLAN identification number

**Format**

```
show vlan <vlanid>
```

**Mode**

Privileged EXEC and User EXEC

**VLAN ID**

There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4042.

**VLAN Name**

A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of `Default`. This field is optional.

**VLAN Type**

Type of VLAN, which can be Default, (VLAN ID = 1), a static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).

**VLAN Creation Time**

Time since VLAN has been created:  
d days, hh:mm:ss (System Uptime).

**Interface**

Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.

**Current**

Determines the degree of participation of this port in this VLAN. The permissible values are:

`Include` - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

`Exclude` - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

`Autodetect` - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

**Configured**

Determines the configured degree of participation of this port in this VLAN. The permissible values are:

`Include` - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard.

`Exclude` - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q standard.

`Autodetect` - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.

## Tagging

Select the tagging behavior for this port in this VLAN.

`Tagged` - specifies to transmit traffic for this VLAN as tagged frames.

`Untagged` - specifies to transmit traffic for this VLAN as untagged frames.

## 4.9.73 show vlan brief

This command displays a list of all configured VLANs.

### Format

```
show vlan brief
```

### Mode

Privileged EXEC and User EXEC

### VLAN ID

There is a VLAN Identifier (vlanid) associated with each VLAN. The range of the VLAN ID is 1 to 4042.

### VLAN Name

A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of `Default`. This field is optional.

### VLAN Type

Type of VLAN, which can be Default, (VLAN ID = 1), a static (one that is configured and permanently defined), or a Dynamic (one that is created by GVRP registration).

### VLAN Creation Time

Displays the time (as the system time up time) when the VLAN was created.

## 4.9.74 show vlan port

This command displays VLAN port information.

### Format

```
show vlan port {<slot/port> | all}
```

### Mode

Privileged EXEC and User EXEC

### Slot/Port

Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selectors on the top line.

### Port VLAN ID

The VLAN ID that this port will assign to untagged frames or priority tagged frames received on this port. The value must be for an existing VLAN. The factory default is 1.

### Acceptable Frame Types

Specifies the types of frames that may be received on this port. The options are 'VLAN only' and 'Admit All'. When set to 'VLAN only', untagged frames or priority tagged frames received on this port are discarded. When set to 'Admit All', untagged frames or priority tagged frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance to the 802.1Q VLAN specification.

### Ingress Filtering

May be enabled or disabled. When enabled, the frame is discarded if this port is not a member of the VLAN with which this frame is associated. In a tagged frame, the VLAN is identified by the VLAN ID in the tag. In an untagged frame, the VLAN is the Port VLAN ID specified for the port that received this frame. When disabled, all frames are forwarded in accordance with the 802.1Q VLAN bridge specification. The factory default is disabled.

### GVRP

The protocol for VLAN administration, GVRP (GARP VLAN Registration Protocol) is particularly used for the adjustment of terminal devices and VLAN switches. In realtime, it traces users log-in and log-off and provides updated configuration data to the network management system. In order to be able to use this protocol, GVRP has

to be supported by every switch.

GVRP may be enabled or disabled. The factory default is disabled.

### **Default Priority**

The 802.1p priority assigned to tagged packets arriving on the port.

### 4.9.75 show voice vlan

Use this command to display the current global Voice VLAN Administrative Mode.

Voice VLAN is a feature used to automatically separate voice and data traffic on a port, by VLAN and/or priority. A primary benefit of using Voice VLAN is to ensure that the sound quality of an IP phone is safeguarded from deteriorating when the data traffic on the port is high.

#### **Format**

```
show voice vlan
```

#### **Mode**

```
Privileged EXEC
```

#### **Administrative Mode**

Possible values: Disable, Enable



## 4.9.76 show voice vlan interface

Use this command to display Use this command to display a summary of the current Voice VLAN configuration for a specific interface.

<slot/port> indicates a specific physical interface.

all indicates all valid interfaces.

### Format

```
show voice vlan interface {<slot/port> | all}
```

### Mode

Privileged EXEC

### <slot/port>

Indicates a specific physical interface.

### all

Indicates all valid interfaces.

### Interface

Displays the physical interface.

### Voice VLAN Interface Mode

Displays the Voice VLAN Interface Mode.

Value range: Disabled, Enabled.

### Voice VLAN Authentication

Displays the Voice VLAN Authentication.

Value range: Disabled, Enabled.

### Voice VLAN Port Status

Displays the Voice VLAN Port Status.

Value range: Disabled, Enabled.

### 4.9.77 shutdown

This command disables a port.

**Default**

enabled

**Format**

shutdown

**Mode**

Interface Config

U no shutdown

This command enables a port.

**Format**

no shutdown

**Mode**

Interface Config

### 4.9.78 shutdown all

This command disables all ports.

**Default**

enabled

**Format**

shutdown all

**Mode**

Global Config

U no shutdown all

This command enables all ports.

**Format**

no shutdown *all*

**Mode**

Global Config

### 4.9.79 snmp trap link-status

This command enables link status traps by interface.

**Note:** This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command.

**Format**

```
snmp trap link-status
```

**Mode**

```
Interface Config
```

U no snmp trap link-status

This command disables link status traps by interface.

**Note:** This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command).

**Format**

```
no snmp trap link-status
```

**Mode**

```
Interface Config
```

### 4.9.80 snmp trap link-status all

This command enables link status traps for all interfaces.

**Note:** This command is valid only when the Link Up/Down Flag is enabled (see “snmp-server enable traps linkmode” ).

**Format**

```
snmp trap link-status all
```

**Mode**

```
Global Config
```

U no snmp trap link-status all

This command disables link status traps for all interfaces.

**Note:** This command is valid only when the Link Up/Down Flag is enabled (see “snmp-server enable traps linkmode”).

**Format**

```
no snmp trap link-status all
```

**Mode**

```
Global Config
```

### 4.9.81 spanning-tree bpdumigrationcheck

This command enables BPDU migration check on a given interface. This will force the specified port to transmit RST or MST BPDUs. The **all** option enables BPDU migration check on all interfaces.

**Format**

```
spanning-tree bpdumigrationcheck {<slot/port>|all}
```

**Mode**

Global Config

#### U no spanning-tree bpdumigrationcheck

This command disables BPDU migration check on a given interface. The **all** option disables BPDU migration check on all interfaces.

**Format**

```
no spanning-tree bpdumigrationcheck {<slot/  
port>|all}
```

**Mode**

Global Config

## 4.9.82 speed

This command sets the speed and duplex setting for the interface.

### Format

```
speed {<100 / 10> <half-duplex / full-duplex> / 1000  
full-duplex}
```

### Mode

```
Interface Config
```

Acceptable values are:

#### 1000f

```
1000BASE-T full duplex
```

#### 100h

```
100BASE-T half duplex
```

#### 100f

```
100BASE-T full duplex
```

#### 10h

```
10BASE-T half duplex
```

#### 10f

```
100BASE-T full duplex
```

### 4.9.83 storm-control broadcast

This command enables the egress broadcast limiter globally.

**Format**

```
storm-control broadcast
```

**Mode**

```
Global Config
```

#### U no storm-control broadcast

This command disables the egress broadcast limiter globally.

**Format**

```
no storm-control broadcast
```

**Mode**

```
Global Config
```

### 4.9.84 storm-control egress-limiting

This command enables or disables the egress limiter globally for all frame types.

**Format**

```
storm-control egress-limiting {disable | enable}
```

**Mode**

```
Global Config
```



### 4.9.85 storm-control ingress-limiting

This command enables or disables the ingress limiter globally.

**Format**

```
storm-control ingress-limiting {disable | enable}
```

**Mode**

```
Global Config
```

### 4.9.86 storm-control ingress-mode

This command sets the frame type for the ingress limiter globally to: BC or BC+MC (MACH 4000 and PowerMICE only).

**Format**

```
storm-control ingress-mode {bc | mc+bc}
```

**Mode**

```
Global Config
```

### 4.9.87 storm-control broadcast (port-related)

This command enables the broadcast limiter per port.  
Enter the maximum number of broadcasts that the given port is allowed to send (unit: frames per second, min.: 0 (no limit), default: 0 (no limit)).

**Format**

```
storm-control broadcast <max. broadcast rate>
```

**Mode**

```
Interface Config
```

### 4.9.88 storm-control egress-limit

Sets the egress rate limit in kbit/s. "0" means: no limit (RS20/RS30/RS40, MS20/MS30, OCTOPUS only).

**Format**

```
storm-control egress-limit <max. egress rate>
```

**Mode**

```
Interface Config
```

### 4.9.89 storm-control ingress-limit

Sets the ingress rate limit in kbit/s. "0" means: no limit.

**Format**

```
storm-control ingress-limit <max. ingress rate>
```

**Mode**

```
Interface Config
```

### 4.9.90 storm-control ingress-mode

This command sets the frame type for the ingress limiter to: All, BC, BC+MC, BC+MC+uUC (RS20/RS30/RS40, MS20/MS30, OCTOPUS only).

**Format**

```
storm-control ingress-mode {all | bc | mc+bc |  
uuc+mc+bc}
```

**Mode**

```
Interface Config
```

### 4.9.91 storm-control flowcontrol

This command enables 802.3x flow control for the switch.

**Note:** This command only applies to full-duplex mode ports.

**Default**

disabled

**Format**

```
storm-control flowcontrol
```

**Mode**

Interface Config  
Global Config

**U no storm-control flowcontrol**

This command disables 802.3x flow control for the switch.

**Note:** This command only applies to full-duplex mode ports.

**Format**

```
no storm-control flowcontrol
```

**Mode**

Interface Config  
Global Config

### 4.9.92 storm-control flowcontrol per port

This command enables 802.3x flow control for the port.

**Note:** This command only applies to full-duplex mode ports.

#### Default

enabled

#### Format

```
storm-control flowcontrol
```

#### Mode

Interface Config

U no storm-control flowcontrol per port

This command disables 802.3x flow control for the port.

**Note:** This command only applies to full-duplex mode ports.

#### Format

```
no storm-control flowcontrol
```

#### Mode

Interface Config

### 4.9.93 vlan

This command creates a new VLAN and assigns it an ID. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 1-4042.

**Format**

```
vlan <1-4042>
```

**Mode**

```
VLAN database
```

**U no vlan**

This command deletes an existing VLAN. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 1-4042.

**Format**

```
no vlan <1-4042>
```

**Mode**

```
VLAN database
```

### 4.9.94 vlan0-transparent-mode

Activate the “Transparent Mode“ to be able to switch priority tagged frames without a VLAN affiliation thus with VLAN-ID “0”.

In this mode the VLAN-ID “0” persists in the frame, irrespective of the Port VLAN ID setting in the “VLAN Port“ dialog.

Note for PowerMICE, MACH100, MACH 1000 and MACH 4000:

In transparency mode devices ignore received vlan tags. Set the vlan membership of the ports to untagged for all vlans.

Note for RS20/RS30/RS40, MS20/MS30 and OCTOPUS:

In transparency mode devices ignore the configured port vlan id. Set the vlan membership of the ports from vlan 1 to untagged or member.

#### **Format**

```
vlan0-transparent-mode {disable|enable}
```

#### **Mode**

```
VLAN database
```

## 4.9.95 vlan acceptframe

This command sets the frame acceptance mode per interface. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

### Default

```
Admit All
```

### Format

```
vlan acceptframe <vlanonly | all>
```

### Mode

```
Interface Config
```

## U no vlan acceptframe

This command sets the frame acceptance mode per interface to `Admit All`. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

### Format

```
vlan acceptframe <vlanonly | all>
```

### Mode

```
Interface Config
```

### 4.9.96 vlan database

This command switches into the global VLAN mode.

**Default**

Admit All

**Format**

vlan database

**Mode**

Privileged EXEC

### 4.9.97 vlan ingressfilter

This command enables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

**Default**

disabled

**Format**

vlan ingressfilter

**Mode**

Interface Config



**U** no vlan ingressfilter

This command disables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

**Format**

```
no vlan ingressfilter
```

**Mode**

```
Interface Config
```

## 4.9.98 vlan name

This command changes the name of a VLAN. The name is an alphanumeric string of up to 32 characters, and the ID is a valid VLAN identification number. ID range is 1-4042.

**Default**

The name for VLAN ID 1 is always Default. The name for other VLANs is defaulted to a blank string.

**Format**

```
vlan name <1-4042> <newname>
```

**Mode**

```
VLAN database
```

**U** no vlan name

This command sets the name of a VLAN to a blank string. The VLAN ID is a valid VLAN identification number. ID range is 1-4042.

**Format**

```
no vlan name <1-4042>
```

**Mode**

```
VLAN database
```

## 4.9.99 vlan participation

This command configures the degree of participation for a specific interface in a VLAN. The ID is a valid VLAN identification number, and the interface is a valid interface number .

### Format

```
vlan participation  
  <exclude | include | auto> <1-4042>
```

### Mode

Interface Config

Participation options are:

#### **include**

The interface is always a member of this VLAN. This is equivalent to registration fixed.

#### **exclude**

The interface is never a member of this VLAN. This is equivalent to registration forbidden.

#### **auto**

The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

## 4.9.100vlan participation all

This command configures the degree of participation for all interfaces in a VLAN. The ID is a valid VLAN identification number .

### Format

```
vlan participation all <exclude | include | auto>  
<1-4042>
```

### Mode

```
Global Config
```

Participation options are:

#### **include**

The interface is always a member of this VLAN. This is equivalent to registration fixed.

#### **exclude**

The interface is never a member of this VLAN. This is equivalent to registration forbidden.

#### **auto**

The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

### 4.9.101vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

**Default**

```
Admit All
```

**Format**

```
vlan port acceptframe all <vlanonly | all>
```

**Mode**

```
Global Config
```

**U no vlan port acceptframe all**

This command sets the frame acceptance mode for all interfaces to Admit All. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

**Format**

```
no vlan port acceptframe all
```

**Mode**

```
Global Config
```

## 4.9.102vlan port ingressfilter all

This command enables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

**Default**

disabled

**Format**

```
vlan port ingressfilter all
```

**Mode**

Global Config

**U no vlan port ingressfilter all**

This command disables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

**Format**

```
no vlan port ingressfilter all
```

**Mode**

Global Config

### 4.9.103vlan port pvid all

This command changes the VLAN ID for all interface.

**Default**

1

**Format**

```
vlan port pvid all <1-4042>
```

**Mode**

Global Config

**U no vlan port pvid all**

This command sets the VLAN ID for all interfaces to 1.

**Format**

```
no vlan port pvid all <1-4042>
```

**Mode**

Global Config

## 4.9.104vlan port tagging all

This command configures the tagging behavior for all interfaces in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

**Format**

```
vlan port tagging all <1-4042>
```

**Mode**

```
Global Config
```

**U no vlan port tagging all**

This command configures the tagging behavior for all interfaces in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

**Format**

```
no vlan port tagging all <1-4042>
```

**Mode**

```
Global Config
```

### 4.9.105vlan pvid

This command changes the VLAN ID per interface.

**Default**

1

**Format**

```
vlan pvid <1-4042>
```

**Mode**

Interface Config

**U no vlan pvid**

This command sets the VLAN ID per interface to 1.

**Format**

```
no vlan pvid <1-4042>
```

**Mode**

Interface Config



## 4.9.106vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

### Format

```
vlan tagging <1-4042>
```

### Mode

```
Interface Config
```

### U no vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

### Format

```
no vlan tagging <1-4042>
```

### Mode

```
Interface Config
```

### 4.9.107 voice vlan (Global Config Mode)

This command enables the Voice VLAN feature.

Voice VLAN is a feature used to automatically separate voice and data traffic on a port, by VLAN and/or priority. A primary benefit of using Voice VLAN is to ensure that the sound quality of an IP phone is safeguarded from deteriorating when the data traffic on the port is high.

**Default**

Disabled

**Format**

voice vlan

**Mode**

Global Config

**U no voice vlan**

This command disables the Voice VLAN feature.

**Default**

Disabled

**Format**

no voice vlan

**Mode**

Global Config

### 4.9.108 voice vlan <id>

Use this command to configure VLAN tagging and 802.1p priority.

**Format**

```
voice vlan <id> [dot1p <priority>] }
```

**Mode**

Interface Config

**<id>**

Enter the Voice VLAN ID.

**dot1p**

Configure Voice VLAN 802.1p priority tagging for voice traffic.

**<priority>**

The priority tag range is 0–7.

**U no voice vlan**

This command disables the Voice VLAN feature on the interface.

**Default**

Disabled

**Format**

```
no voice vlan
```

**Mode**

Interface Config

### 4.9.109 voice vlan dot1p

Use this command to configure Voice VLAN 802.1p priority tagging for voice traffic.

**Format**

```
voice vlan dot1p <priority>
```

**Mode**

```
Interface Config
```

**<priority>**

Configure Voice VLAN 802.1p priority tagging for voice traffic.  
The priority tag range is 0–7.

### 4.9.110 voice vlan none

Use this command to allow the IP phone to use its own configuration to send untagged voice traffic.

**Format**

```
voice vlan none
```

**Mode**

```
Interface Config
```

### 4.9.111 voice vlan untagged

Use this command to configure the phone to send untagged voice traffic.

**Format**

```
voice vlan untagged
```

**Mode**

```
Interface Config
```

### 4.9.112 voice vlan auth

Use this command to set Voice VLAN Authentication Mode. If disabled, VOIP devices which are detected via LLDP-med will have access to the Voice VLAN without authentication.

**Default**

```
Enabled
```

**Format**

```
voice vlan auth [enabled | disabled]
```

**Mode**

```
Interface Config
```

**disable**

VOIP devices which are detected via LLDP-MED will have access to the Voice VLAN without authentication.

**enable**

VOIP devices which are detected via LLDP-MED will not have access to the Voice VLAN without authentication.



## 4.10 User Account Management Commands

These commands manage user accounts.

### 4.10.1 disconnect

This command closes a telnet session.

**Format**

```
disconnect {<sessionID> | all}
```

**Mode**

```
Privileged EXEC
```

**Session ID**

Enter the session ID (1-11).

### 4.10.2 show loginsession

This command displays current telnet and serial port connections to the switch.

**Format**

```
show loginsession
```

**Mode**

```
Privileged EXEC and User EXEC
```

**ID**

```
Login Session ID
```

**User Name**

The name the user will use to login using the serial port or Telnet. A new user may be added to the switch by entering a name in a blank entry. The user name may be up to 8 characters, and is not case sensitive. Two users are included as the factory default, 'admin' and 'user'.

**Connection From**

IP address of the telnet client machine or EIA-232 for the serial port connection.

**Idle Time**

Time this session has been idle.

**Session Time**

Total time this session has been connected.



### 4.10.3 show users

This command displays the configured user names and their settings. This command is only available for users with readwrite privileges. The SNMPv3 fields will only be displayed if SNMP is available on the system.

**Format**

```
show users
```

**Mode**

```
Privileged EXEC
```

**User Name**

The name the user will use to login using the serial port, Telnet or Web. A new user may be added to the switch by entering a name in a blank entry. The user name may be up to eight characters, and is not case sensitive. Two users are included as the factory default, 'admin' and 'user'

**Access Mode**

Shows whether the operator is able to change parameters on the switch (Read/Write) or is only able to view them (Read Only). As a factory default, the 'admin' user has Read/Write access and the 'user' has Read Only access. There can only be one Read/Write user and up to five Read Only users.

**SNMPv3 AccessMode**

This field displays the SNMPv3 Access Mode. If the value is set to ReadWrite, the SNMPv3 user will be able to set and retrieve parameters on the system. If the value is set to ReadOnly, the SNMPv3 user will only be able to retrieve parameter information. The SNMPv3 access mode may be different than the CLI and Web access mode.

**SNMPv3 Authentication**

This field displays the authentication protocol to be used for the specified login user.

**SNMPv3 Encryption**

This field displays the encryption protocol to be used for the specified login user.

### 4.10.4 users defaultlogin

This command assigns the authentication login list to use for non-configured users when attempting to log in to the system. This setting is overridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

**Format**

```
users defaultlogin <listname>
```

**Mode**

```
Global Config
```

**listname**

Enter an alphanumeric string of not more than 15 characters.

### 4.10.5 users login <user>

Enter user name.

**Format**

```
users login <user> <listname>
```

**Mode**

```
Global Config
```

**Note:**

When assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable (use 'authentication login <listname> [method1 [method2 [method3]]]').

U no users login <user>

This command removes an operator.

**Format**

```
no users login <user> <listname>
```

**Mode**

```
Global Config
```

**Note:**

The 'admin' user account cannot be deleted.

### 4.10.6 users access

This command sets access for a user: readonly/readwrite.

#### **Format**

```
users access <username> {readonly / readwrite}
```

#### **Mode**

Global Config

#### **<username>**

Enter a name up to 32 alphanumeric characters in length.

#### **readonly**

Enter the access mode as readonly.

#### **readwrite**

Enter the access mode as readwrite.

### U no users access

This command deletes access for a user.

#### **Format**

```
no users access <username>
```

#### **Mode**

Global Config

### 4.10.7 users name

This command adds a new user (account) if space permits. The account <username> can be up to eight characters in length. The name may be comprised of alphanumeric characters as well as the dash ('-') and underscore ('\_'). The <username> is not case-sensitive.

Six user names can be defined.

**Format**

```
users name <username>
```

**Mode**

```
Global Config
```

**U no users name**

This command removes an operator.

**Format**

```
no users name <username>
```

**Mode**

```
Global Config
```

**Note:**

The 'admin' user account cannot be deleted.

## 4.10.8 users passwd

This command is used to change a password. The password should not be more than eight alphanumeric characters in length. If a user is authorized for authentication or encryption is enabled, the password must be at least eight alphanumeric characters in length. The username and password are case-sensitive. When a password is changed, a prompt will ask for the former password. If none, press enter.

**Note:** Make sure, that the passwords of the users differ from each other. If two or more users try to choose the same password, the CLI will display an error message.

### Default

No Password

### Format

```
users passwd <username> {<password>}
```

### Mode

Global Config

## U no users passwd

This command sets the password of an existing operator to blank. When a password is changed, a prompt will ask for the operator's former password. If none, press enter.

### Format

```
no users passwd <username> {<password>}
```

### Mode

Global Config

### 4.10.9 users snmpv3 accessmode

This command specifies the snmpv3 access privileges for the specified login user. The valid accessmode values are `readonly` or `readwrite`. The `<username>` is the login user name for which the specified access mode applies. The default is `readwrite` for 'admin' user; `readonly` for all other users

**Default**

```
admin -- readwrite; other -- readonly
```

**Format**

```
users snmpv3 accessmode <username> <readonly |  
readwrite>
```

**Mode**

```
Global Config
```

**U no users snmpv3 accessmode**

This command sets the snmpv3 access privileges for the specified login user as `readwrite` for the 'admin' user; `readonly` for all other users. The `<username>` is the login user name for which the specified access mode will apply.

**Format**

```
no users snmpv3 accessmode <username>
```

**Mode**

```
Global Config
```

### 4.10.10 users snmpv3 authentication

This command specifies the authentication protocol to be used for the specified login user. The valid authentication protocols are `none`, `md5` or `sha`. If `md5` or `sha` are specified, the user login password is also used as the snmpv3 authentication password and therefore must be at least eight characters in length. The `<username>` is the login user name associated with the authentication protocol.

**Default**

```
no authentication
```

**Format**

```
users snmpv3 authentication <username> <none | md5  
| sha>
```

**Mode**

```
Global Config
```

**U no users snmpv3 authentication**

This command sets the authentication protocol to be used for the specified login user to `none`. The `<username>` is the login user name for which the specified authentication protocol will be used.

**Format**

```
users snmpv3 authentication <username>
```

**Mode**

```
Global Config
```



### 4.10.11 users snmpv3 encryption

This command specifies the encryption protocol to be used for the specified login user. The valid encryption protocols are `des` or `none`.

If `des` is specified, the required key may be specified on the command line.

The `key` may be up to 16 characters long. If the `des` protocol is specified but a key is not provided, the user will be prompted for the key. When using the `des` protocol, the user login password is also used as the snmpv3 encryption password and therefore must be at least eight characters in length.

If `none` is specified, a key must not be provided. The `<username>` is the login user name associated with the specified encryption.

**Default**

```
no encryption
```

**Format**

```
users snmpv3 encryption <username> <none |  
des[key]>
```

**Mode**

```
Global Config
```

**U no users snmpv3 encryption**

This command sets the encryption protocol to `none`. The `<username>` is the login user name for which the specified encryption protocol will be used.

**Format**

```
no users snmpv3 encryption <username>
```

**Mode**

```
Global Config
```



## 4.11 System Utilities

This section describes system utilities.

### 4.11.1 address-conflict

This command configures the setting for detection possible address conflicts of the agent's IP address with other devices' IP addresses in the network.

#### Format

```
address-conflict
  {detection-mode { active-only | disable |
    enable | passive-only}|
  ongoing-detection { disable | enable } }
```

#### Mode

Global Config

#### detection mode

Configure the device's address conflict detection mode (active-only, disable, enable or passive-only). Default: enable.

#### ongoing detection

Disable or enable the ongoing address conflict detection.  
Default: enable.

### 4.11.2 boot skip-aca-on-boot

Use this command to skip external memory (AutoConfiguration Adapter ACA21) during boot phase to shorten startup duration. The ACA21 functionality will be available after the boot phase.

**Format**

```
boot skip-aca-on-boot {disable | enable}
```

**Mode**

Global Config

**Default**

disabled

**enable**

Enable ACA21 skip during boot phase.

**disable**

Disable ACA21 skip during boot phase.

### 4.11.3 show boot skip-aca-on-boot

Use this command display the status of the option of skipping external memory (AutoConfiguration Adapter ACA21) during boot phase.

**Format**

```
show boot skip-aca-on-boot
```

**Mode**

Global Config

**Default**

disabled

**Enabled**

ACA21 skip during boot phase is enabled.

**Disabled**

ACA21 skip during boot phase is disabled.

### 4.11.4 cablestatus

This command tests the cable attached to an interface for short or open circuit. During the test the traffic is interrupted on this port.

**Format**

```
cablestatus <slot/port>
```

**Mode**

```
Privileged EXEC
```

### 4.11.5 clear eventlog

Clear the event log. The CLI will ask for confirmation.

Answer *y* (yes) or *n* (no).

The CLI displays the end of this operation.

**Format**

```
clear eventlog
```

**Mode**

```
Privileged EXEC
```

## 4.11.6 traceroute

This command is used to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis.

<ipaddr> should be a valid IP address.

The optional port parameter is the UDP port used as the destination of packets sent as part of the traceroute. This port should be an unused port on the destination system. [port] should be a valid decimal integer in the range of 0 (zero) to 65,535. The default value is 33,434.

### Format

```
traceroute <ipaddr> [port]
```

### Mode

Privileged EXEC

## 4.11.7 clear arp-table-switch

This command clears the agent's ARP table (cache).

### Format

```
clear arp-table-switch
```

### Mode

Privileged EXEC

### 4.11.8 clear config

This command resets the configuration in RAM to the factory defaults without powering off the switch.

**Format**

```
clear config
```

**Mode**

```
Privileged EXEC
```

### 4.11.9 clear config factory

This command resets the whole configuration to the factory defaults. Configuration data and scripts stored in nonvolatile memory will also be deleted.

**Format**

```
clear config factory
```

**Mode**

```
Privileged EXEC
```

### 4.11.10 clear counters

This command clears the stats for a specified <slot/port> or for all the ports or for the entire switch based upon the argument.

**Format**

```
clear counters {<slot/port> | all}
```

**Mode**

```
Privileged EXEC
```

### 4.11.11 clear hiper-ring

This command clears the HIPER Ring configuration (deletes it).

**Format**

```
clear hiper-ring
```

**Mode**

```
Privileged EXEC
```

### 4.11.12 clear igmpsnooping

This command clears the tables managed by the IGMP Snooping function and will attempt to delete these entries from the Multicast Forwarding Database.

**Format**

```
clear igmpsnooping
```

**Mode**

```
Privileged EXEC
```



### 4.11.13 clear mac-addr-table

This command clears the switch's MAC address table (the forwarding database that contains the learned MAC addresses).

**Note:** this command does not affect the MAC filtering table.

**Format**

```
clear mac-addr-table
```

**Mode**

```
Privileged EXEC
```

### 4.11.14 clear pass

This command resets all user passwords to the factory defaults without powering off the switch. You are prompted to confirm that the password reset should proceed.

**Format**

```
clear pass
```

**Mode**

```
Privileged EXEC
```

### 4.11.15 clear link-aggregation

This command clears all link-aggregations (LAGs).

**Format**

```
clear link-aggregation
```

**Mode**

Privileged EXEC

### 4.11.16 clear signal-contact

This command clears the signal-contact output configuration.

Switches the signal contact 1's mode to `auto` and its manual setting to `open`.

Switches the signal contact 2's mode to `manual` and its manual setting to `closed`.

Enables the monitoring of the power supplies for signal contact 1 only.

Disables the sending of signal contact traps.

**Format**

```
clear signal-contact
```

**Mode**

Privileged EXEC

### 4.11.17 clear traplog

This command clears the trap log.

**Format**

```
clear traplog
```

**Mode**

```
Privileged EXEC
```

### 4.11.18 clear ring-coupling

This command clears the ring-coupling configuration.

**Format**

```
clear ring-coupling
```

**Mode**

```
Privileged EXEC
```

### 4.11.19 clear vlan

This command resets VLAN configuration parameters to the factory defaults.

**Format**

```
clear vlan
```

**Mode**

Privileged EXEC

### 4.11.20 config-watchdog

If the function is enabled and the connection to the switch is interrupted for longer than the time specified in “timeout [s]”, the switch then loads the last configuration saved.

**Format**

```
config-watchdog {admin-state {disable|enable}}|  
timeout <10..600>}
```

**Mode**

Global Config

**admin-state**

Enable or disable the Auto Configuration Undo feature  
(default: disabled).

**timeout**

Configure the Auto Configuration Undo timeout (unit: seconds).

## 4.11.21 copy

This command uploads and downloads to/from the switch. Remote URLs can be specified using tftp.

`copy` (without parameters) displays a brief explanation of the most important copy commands. A list of valid commands is provided below.

The command can be used to save the running configuration to nvram by specifying the source as `system:running-config` and the destination as `nvram:startup-config`.

### Default

none

### Format

```
copy
copy aca:script <sourcefilename> nvram:script
    [targetfilename]
copy aca:capturefilter <sourcefilename>
    nvram:capturefilter [targetfilename]
copy aca:sfp-white-list <sourcefilename>
    nvram:sfp-white-list
copy nvram:backup-image system:image
copy nvram:clibanner <url>
copy nvram:capture aca:capture
copy nvram:capture <url>
copy nvram:capturefilter <sourcefilename>
    aca:capturefilter <targetfilename>
copy nvram:capturefilter <sourcefilename>
copy nvram:errorlog <url>
copy nvram:script <sourcefilename> aca:script
    [targetfilename]
copy nvram:script <sourcefilename> <url>
copy nvram:startup-config <url>
copy nvram:startup-config system:running-config
copy nvram:traplog <url>
copy system:running-config nvram:startup-config
<url>
copy system:running-config <url>
copy <tftp://ip/filepath/fileName>
    nvram:sfp-white-list
copy tftp://<server_ip>/<path_to_pem>
    nvram:https-cert
```

```
copy <url> nvram:clibanner
copy <url> nvram:capturefilter <destfilename>
copy aca:capturefilter <sourcefilename>
  nvram:capturefilter <destfilename>
copy <url> nvram:script <destfilename>
copy <url> nvram:startup-config
copy <url> system:image
copy <url> system:running-config
copy <url> system:bootcode
```

**Mode**

Privileged EXEC

U copy aca:script <sourcefilename>  
nvram:script [targetfilename]

Copies the script from the Auto Configuration Adapter.

– sourcefilename: Filename of source configuration Script. File-name length may be max. 20 characters, including extension '.cli' or '.CLI'.

– targetfilename: Filename on the switch's NVRAM. Filename length may be max. 20 characters, including extension '.cli'.

U copy aca:capturefilter <sourcefilename>  
nvram:capturefilter [targetfilename]

Copies a capture filter file from the Auto Configuration Adapter.

– sourcefilename: Filename of source capture filter expressions file.

– targetfilename: Filename on the switch's NVRAM.

U copy aca:sfp-white-list <sourcefilename>  
nvram:sfp-white-list

Use this command to load the SFP white list file from a ACA21.

**Note:** In order to delete the SFP white list file from the flash memory:

use the command `clear sfp-white-list`.

The `clear config factory` command deletes the SFP white list, too.

U `copy nvram:backup-image system:image`

Use this command to swap current and backup images. The backup image (backup.bin) and current image (main.bin) will exchange the file name, after reboot the both OS and configuration files will be swapped.

U `copy <tftp://ip/filepath/fileName> nvram:sfp-white-list`

Use this command to load the SFP white list file from a TFTP server.

**Note:** In order to delete the SFP white list file from the flash memory: use the command `clear sfp-white-list`.

The `clear config factory` command deletes the SFP white list, too.

U `copy tftp://<server_ip>/<path_to_pem> nvram:httpscert`

Use this command for uploading a PEM certificate for HTTPS over TFTP

**Note:** Reboot the device or re-enable the HTTPS server after uploading a PEM certificate.

U `copy nvram:clibanner <url>`

Downloads the CLI banner file via TFTP using `<tftp://ip/filepath/fileName>`.

U `copy nvram:capture aca:capture`

Save the internal packet capture file to the Auto Configuration Adapter ACA21 (file name: "capture.cap").

- U `copy nvram:capture <url>`  
Save the internal packet capture file to a tftp URL using `<tftp://ip/filepath/fileName>`.
- U `copy nvram:capturefilter <sourcefilename>`  
`aca:capturefilter <targetfilename>`  
Save a capture filter file from the flash memory to the Auto Configuration Adapter.  
– `sourcefilename`: Filename of source capture filter expressions file.  
– `targetfilename`: Filename of target capture filter expressions file.
- U `copy nvram:capturefilter <sourcefilename> <url>`  
Save the internal packet capture filter file from the flash memory to a tftp URL using `<tftp://ip/filepath/fileName>`.  
– `sourcefilename`: Filename of source capture filter expressions file.
- U `copy nvram:errorlog <url>`  
Uploads Errorlog file.  
– `<url>`: Uploads Error log file using `<tftp://ip/filepath/fileName>`.
- U `copy nvram:script <sourcefilename>`  
`aca:script [targetfilename]`  
Uploads configuration script file. Save the script to the AutoConfiguration Adapter.  
– `sourcefilename`: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.  
– `targetfilename`: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.



- U `copy nvram:script <sourcefilename> <url>`  
Uploads Configuration Script file using `<tftp://ip/filepath/fileName>`.  
Filename length may be max. 20 characters, including extension `'.cli'`.  
– `sourcefilename`: Filename length may be max. 20 characters, including extension `'.cli'` or `'.CLI'`.
  
- U `copy nvram:startup-config <url>`  
Uploads config file using `<tftp://ip/filepath/fileName>`.
  
- U `copy nvram:startup-config system:running-config`  
Uploads/Copies config file. The target is the currently running configuration.
  
- U `copy nvram:traplog <url>`  
Uploads Trap log file. Uploads Trap log file using `<tftp://ip/filepath/fileName>`.
  
- U `copy system:running-config nvram:startup-config`  
Copies system config file. Save the running configuration to NVRAM.
  
- U `copy system:running-config <url>`  
Copies system config file. Uploads system running-config via tftp using `<tftp://ip/filepath/fileName>`.

U copy <url> nvram:clibanner

This feature provides a privileged user the capability to change the CLI default banner:

```
-----  
Copyright (c) 2004-2010 <Company Name>
```

```
    All rights reserved
```

```
    <Product Name> Release L3P-06.0.00
```

```
    (Build date 2010-05-01 00:30)
```

```
System Name:   <Product Name>-518280  
Mgmt-IP       :   a.b.c.d  
1.Router-IP   :   0.0.0.0  
Base-MAC      :   aa:bb:cc:dd:ee:ff  
System Time   :   2010-01-02 05:51:11  
-----
```

The command uploads the CLI Banner file by tftp using <tftp://ip/filepath/fileName>.

After the upload you logout from CLI and the new CLI banner file will be displayed at the next login.

- url: Upload CLI banner file using <tftp://ip/filepath/fileName>.

If no cli banner file is defined, the default cli banner is displayed (see above).

**Note:** See that the the CLI banner file you created has the following properties:

- Use ASCII format (character codes 0x20 .. 0x7F, \n and \t as C-like sequences)
- Do not use regular expressions
- Do not exceed the limit of 2048 byte
- Do not exceed the limit of 20 lines
- Do not exceed the limit of 80 characters per line
- A device can only have one banner file at the moment
- Save the CLI banner file as \*.bnr.

- U `no clibanner`  
This command deletes an existing CLI banner file.
  
- U `copy <url> nvram:capturefilter <destfilename>`  
Load a Capture Filter file from a tftp URL into the flash memory using `<tftp://ip/filepath/fileName>`.
  - `destfilename`: Destination filename of capture filter expressions file.
  
- U `copy aca:capturefilter <sourcefilename> nvram:capturefilter <targetfilename>`  
Load a capture filter file from AutoConfiguration Adapter ACA21 into the flash memory.
  - `sourcefilename`: Filename of source capture filter expressions file.
  - `targetfilename`: Specify the file name on the switch's NVRAM.
  
- U `copy <url> nvram:script <destfilename>`  
Downloads Configuration Script file using `<tftp://ip/filepath/fileName>`.
  - `destfilename`: Filename length may be max. 20 characters, including extension '.cli' or '.CLI'.
  
- U `copy <url> nvram:startup-config`  
Downloads Config file by tftp using `<tftp://ip/filepath/fileName>`.
  
- U `copy <url> system:image`  
Downloads code file by tftp using `<tftp://ip/filepath/fileName>`.

**U** `copy <url> system:running-config`

Downloads Code/Config file using `<tftp://ip/filepath/fileName>`.  
The target is the currently running configuration.

**U** `copy <url> system:bootcode`

Use the "copy <url> system:bootcode" command to load the bootcode file via tftp into the device. For <url> enter the path of the tftp server using the following notation: "`<tftp://ip/filepath/fileName>`", e.g. "`tftp://10.1.112.214/switch/switch01.cfg`".

**U** `clear sfp-white-list`

Use this command to delete the SFP white list file from the flash memory.

**Note:** The `clear config factory` command deletes the SFP white list, too.

## 4.11.22device-status connection-error

This command configures the device status link error monitoring for this port.

**Default**

`ignore`

**Format**

`device-status connection-error {ignore|propagate}`

**Mode**

Interface Config

### 4.11.23 device-status monitor

This command configures the device-status.

#### Format

```
device-status monitor
  {aca-removal | all | connection-error |
  hiper-ring |
  module-removal | power-supply-1 |
  power-supply-2 | power-supply-3-1 |
  power-supply-3-2 | power-supply-4-1 |
  power-supply-4-2 | ring-coupling | temperature }
  {error|ignore}
device-status trap {disable|enable}
```

#### Mode

Global Config

#### monitor

Determines the monitoring of the selected event or all events.

- **error** If the given event signals an error, the device state will also signal error,
- **ignore** Ignore the given event - even if it signals an error, the device state will not signal 'error' because of that.

#### trap

Configure if a trap is sent when the device status changes its state.

- **enable** enables sending traps,
- **disable** disables sending traps.

## 4.11.24logout

This command closes the current telnet connection or resets the current serial connection.

**Note:** Save configuration changes before logging out.

### Format

```
logout
```

### Mode

```
Privileged EXEC
```

## 4.11.25ping

This command checks if another computer is on the network and listens for connections. To use this command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends, three pings to the target station.

### Format

```
ping <ipaddr>
```

### Mode

```
Privileged EXEC and User EXEC
```

## 4.11.26 signal-contact connection-error

This command configures the signal contact link error monitoring for this port.

### Format

```
signal-contact connection-error {disable|enable}
```

### Mode

Interface Config

### disable

A link down event on this port will be not monitored by a signal contact (default).

### enable

A link down event on this port will be monitored by a signal contact.

## 4.11.27 signal-contact

This command configures the signal contacts.

### Format

```
signal-contact {1|2|all}
  {mode {auto|device-status|manual}
  |monitor {aca-removal|
    all|
    connection-error|hiper-ring|module-removal
    |power-supply-1| power-supply-2
    |power-supply-3-1|power-supply-3-2
    |power-supply-4-1|power-supply-4-2
    |ring-coupling|temperature} {disable|enable}
  |state {closed|open}
  |trap {disable|enable} }
```

### Mode

Global Config

**Contact No.**

Selection of the signal contact:

- 1 signal contact 1,
- 2 signal contact 2,
- all signal contact 1 and signal contact 2.

**mode**

Selection of the operational mode:

- auto function monitoring,
- device-status the device-status determines the signal contact's status.
- manual manually setting the signal contact.

**monitor**

Enables or disables the monitoring of the selected event or all events.

- enable monitoring,
- disable no monitoring.

**state**

Set the manual setting of the signal contact:

- closed ,
- open.

Only takes immediate effect in manual mode.

**trap**

Configures the sending of traps concerning the signal contact.

- enable enables sending traps,
- disable disables sending traps.



## 4.11.28 temperature

**Note:** The command is available for RS20/RS30/RS40, MS20/MS30, RSR20/RSR30, MACH100, MACH 1000, PowerMICE, MACH 4000 and OCTOPUS devices.

This command configures the lower and upper temperature limit for the device. If these limits are exceeded, a trap is sent. The unit for the temperature limit is °C (Celsius), the minimum value is -99, the maximum value is 99. The default for the lower limit is 0, for the upper limit, it is 70.

**Note:** To give the temperature in Fahrenheit, use the suffix f.

### Format

```
temperature {lower-limit|upper-limit} <temperature  
value> [c|f]
```

### Mode

Global Config

### lower-limit

Configure the lower temperature limit.

### upper-limit

Configure the upper temperature limit.

## 4.11.29reboot

This command resets the switch (cold start) after a given time delay, for warm start [See “reload” on page 299](#). Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. A successful reset is indicated by the LEDs on the switch.

### Format

```
reboot {delay <seconds>}
```

### Mode

Privileged EXEC

### <seconds>

The number of seconds after which the switch will reboot.

Value range: None (no reboot sceduled), 0 - 2,147,483 sec (= 596 h + 31 min + 23 sec).

## U clear reboot

This command cancels a scheduled reboot.

## 4.11.30show reboot

This command displays if a reboot is sceduled for the device. If sceduled, the command displays the number of seconds after which the switch will reboot.

### Format

```
show reboot
```

### Modes

Privileged EXEC

User Exec

**<seconds>**

The number of seconds after which the switch will reboot.

Value range: None (no reboot scheduled), 0 - 2,147,483 sec (= 596 h + 31 min + 23 sec) .

### 4.11.31 reload

This command enables you to reset the switch (warm start) after a given time delay, for cold start [See “reboot” on page 298](#).

Note: First, the device is checking the software in the flash memory and then it resets. If a warm start is not possible, the device automatically executes a cold start.

Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. A successful reset is indicated by the LEDs on the switch.

**Format**

```
reload {delay <seconds>}
```

**Mode**

Privileged EXEC

**<seconds>**

The number of seconds after which the switch will reload.

Value range: 0 - 2,147,483 sec.

U clear reload

This command cancels a scheduled reload.

## 4.11.32 show reload

This command displays if a reload is scheduled for the device. If scheduled, the command displays the number of seconds after which the switch will reload.

### Format

```
show reload
```

### Modes

```
Privileged EXEC
```

```
User Exec
```

### <seconds>

The number of seconds after which the switch will reload.

Possible values: None (no reload scheduled), 0 - 2,147,483 sec.

## 4.12 LLDP - Link Layer Discovery Protocol

These commands show and configure the LLDP parameters in compliance with IEEE 802.1 AB.

### 4.12.1 show lldp

This command shows all LLDP settings.

**Format**

```
show lldp
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.2 show lldp config

This command shows all LLDP configuration settings.

**Format**

```
show lldp config
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.3 show lldp config chassis

This command shows all LLDP configuration settings concerning the entire device.

**Format**

```
show lldp config chassis
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.4 show lldp config chassis admin-state

Display the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol is inactive but the LLDP MIBs can still be accessed.

**Format**

```
show lldp config chassis admin-state
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.5 show lldp config chassis notification-interval

Display the LLDP minimum notification trap interval (unit: seconds).

**Format**

```
show lldp config chassis notification-interval
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.6 show lldp config chassis re-init-delay

Display the LLDP configuration's chassis re-initialization delay (unit: seconds).

**Format**

```
show lldp config chassis re-init-delay
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.7 show lldp config chassis tx-delay

Display the LLDP transmit delay (unit: seconds). It indicates the delay between successive LLDP frame transmissions.

**Format**

```
show lldp config chassis tx-delay
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.8 show lldp config chassis tx-hold-mult

Display the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval).

**Format**

```
show lldp config chassis tx-hold-mult
```

**Mode**

Privileged EXEC and User EXEC

### 4.12.9 show lldp config chassis tx-interval

Display the interval (unit: seconds) at which LLDP frames are transmitted on behalf of this LLDP agent.

**Format**

```
show lldp config chassis tx-interval
```

**Mode**

Privileged EXEC and User EXEC



## 4.12.10 show lldp config port

This command shows all LLDP configuration settings and states concerning one or all ports.

### Format

```
show lldp config port <{slot/port|all}>  
  admin-state | fdb-mode | hm-mode |  
  max-neighbors | notification | tlv
```

### Mode

Privileged EXEC and User EXEC

### admin-state

Display the port's LLDP admin state (if LLDP/IEEE802.1AB frames will be transmitted and/or received).

### fdb-mode

Display the port's LLDP FDB mode.

### hm-mode

Display the port's LLDP Hirschmann mode.

### .max-neighbors

Display the port's max. no. of LLDP neighbors.

### notification

Display the port's LLDP notification (trap) setting.

### tlv

Display the port's LLDP TLV settings (they determine which information is included in the LLDP frames that are sent). The command is a group command and will output several lines of data.

### 4.12.11 show lldp config port tlv

This command shows all LLDP TLV configuration settings (if the given information is included in the sent LLDP frames or not) concerning one or all ports.

**Format**

```
show lldp config port <{slot/port|all}> tlv
```

**Mode**

Privileged EXEC and User EXEC

**inlinepower**

Enable or disable the sending of the port's Power over Ethernet capabilities (PoE, IEEE 802.3af), available for devices supporting PoE.

**link-aggregation**

Display the port's LLDP TLV inclusion of Link Aggregation.

**mac-phy-config-state**

Display the port's LLDP TLV inclusion of MAC Phy. Cfg. State.

**max-frame-size**

Display the port's LLDP TLV inclusion of Max. Frame Size.

**PROFINET IO Status**

Display the port's LLDP TLV inclusion of PROFINET IO Status.

**PROFINET IO Alias**

Display the port's LLDP TLV inclusion of PROFINET IO Alias.

**PROFINET IO MRP**

Display the port's LLDP TLV inclusion of PROFINET IO MRP.

**mgmt-addr**

Display the port's LLDP TLV inclusion of Management Address.

**port-desc**

Display the port's LLDP TLV inclusion of Port Description.

**port-vlan**

Display the port's LLDP TLV inclusion of Port VLAN.

**protocol**

Display the port's LLDP TLV inclusion of Protocol.

**sys-cap**

Display the port's LLDP TLV inclusion of System Capabilities.

**sys-desc**

Display the port's LLDP TLV inclusion of System Description.

**sys-name**

Display the port's LLDP TLV inclusion of System Name.

**vlan-name**

Display the port's LLDP TLV inclusion of VLAN Name.

### 4.12.12 show lldp med

Use this command to display a summary of the current LLDP MED global configuration.

**Format**

```
show lldp med
```

**Mode**

Privileged EXEC

**Fast Start Repeat Count**

Display the Fast Start Repeat Count, e.g. the number of LLDP PDUs that will be transmitted when the product is enabled.

The range is 1 to 10.

**Device class**

Display the Device class.

### 4.12.13 show lldp med interface

Use this command to display a summary of the current LLDP MED configuration for a specific interface.

**Format**

```
show lldp med interface {<unit/slot/port> | all}
```

**Mode**

Privileged EXEC

**<unit/slot/port>**

Indicates a specific physical interface.

**all**

Indicates all valid LLDP interfaces.

**Interface**

Displays the physical interface.

**Link**

Displays the link status. Value range: Up, Down.

**configMED**

Displays if confignotification for the Media Endpoint Devices is Enabled/Disabled.

**operMED**

Displays if operation for the Media Endpoint Devices is Enabled/Disabled.

**ConfigNotify**

Displays the ConfigNotify. Value range: Enabled, Disabled.

**TLVsTx**

Displays the TLVsTx.

### 4.12.14 show lldp med local-device detail

Use this command to display detailed information about the LLDP MED data that a specific interface transmits. <unit/slot/port> indicates a specific physical interface.

**Format**

```
show lldp med local-device detail {<slot/port>}
```

**Mode**

Privileged EXEC

**<slot/port>**

Indicates a specific physical interface.

**Interface**

Displays the physical interface.

**Network Policies**

Displays the Network Policies.

### 4.12.15 show lldp med remote-device

Use this command to display the summary information about remote devices that transmit current LLDP MED data to the system. You can show information about LLDP MED remote data received on all valid LLDP interfaces or on a specific physical interface.

**Format**

```
show lldp med remote-device{<slot/port> | all}
```

**Mode**

Privileged EXEC

**<slot/port>**

Indicates a specific physical interface.

**all**

Indicates all valid LLDP interfaces.

**Local Interface**

Displays the local interface.

**RemoteID**

Displays the RemoteID.

**Device Class**

Displays the Device Class.

## 4.12.16 show lldp med remote-device detail

Use this command to display detailed information about remote devices that transmit current LLDP MED data to an interface on the system.

**Format**

```
show lldp med remote-device detail <slot/port>
```

**Mode**

Privileged EXEC

**Local Interface**

Displays the local interface.

## 4.12.17 show lldp remote-data

This command shows all LLDP remote-data settings and states concerning one or all ports.

**Format**

```
show lldp remote-data <{slot/port|all}>  
  chassis-id | detailed | ether-port-info |  
  inlinepower | link-aggregation-info |
```

```
mgmt-addr | profinetio-port-info |  
port-desc | port-id | summary | sys-desc |  
sys-name | vlan-info
```

**Mode**

Privileged EXEC and User EXEC

**chassis-id**

Display the remote data's chassis ID only.

**detailed**

Display remote data in detailed format (i. e., all available data).

Note: most important data is output first (not in alphabetic order of command names). This is the default command if no specific command is given.

**ether-port-info**

Display the remote data's port Ethernet properties only (group command, outputs: Port Autoneg. Supported, Port Autoneg. Enabled, Port Autoneg. Advertized Capabilities and Port Operational MAU Type).

**inlinepower**

Displays the remote port's Power over Ethernet capabilities (PoE, IEEE 802.3af). Included are if the remote device is a PSE (Power Source Device) or a PD (Powered Device), if PoE is supported and if the power pairs are selectable.

**link-aggregation-info**

Display the remote data's link aggregation information only (group command, outputs: Link Agg. Status and Link Agg. Port ID).

**mgmt-addr**

Display the remote data's management address only.

**profinetio-port-info**

Display the remote data's Port ProfinetIO properties only.

**port-desc**

Display the port's LLDP TLV inclusion of Port Description.

**port-id**

Display the remote data's port ID only.

**summary**

Display remote data in summary format (table with most important data only, strings will be truncated if necessary, indicated by an appended '>' character).

**sys-desc**

Display the remote data's system description only.

**sys-name**

Display the remote data's system name only.

**vlan-info**

Display the remote data's VLAN information only (group command, outputs: Port VLAN ID, Membership VLAN IDs and their respective names).

## 4.12.18lldp

Enable/disable the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol will become inactive, but the LLDP MIBs can still be accessed. This command is a shorthand notation for `lldp config chassis admin-state {off|on}` (see [“lldp config chassis admin-state” on page 313](#)).

The default setting is `on`.

**Format**

```
lldp
```

**Mode**

```
Global Config
```



U no lldp

Disable the LLDP/IEEE802.1AB functionality on this device.

**Format**

```
no lldp
```

**Mode**

```
Global Config
```

### 4.12.19 lldp config chassis admin-state

Configure the LLDP/IEEE802.1AB functionality on this device. If disabled, the LLDP protocol will become inactive, but the LLDP MIBs can still be accessed.

D off: Disable the LLDP/IEEE802.1AB functionality.

D on: Enable the LLDP/IEEE802.1AB functionality.

The default setting is on.

**Format**

```
lldp config chassis admin-state {off|on}
```

**Mode**

```
Global Config
```

## 4.12.20 lldp config chassis notification-interval

Configure the LLDP minimum notification interval (the minimum time after a notification trap has been sent until a new trap can be sent, unit: seconds, min.: 5 sec., max.: 3600 sec., default: 5 sec.).

### Format

```
lldp config chassis notification-interval  
<notification interval>
```

### Mode

Global Config

### Notification interval

Configure the LLDP minimum notification interval (the minimum time after a notification trap has been sent until a new trap can be sent, unit: seconds, min.: 5 sec., max.: 3600 sec., default: 5 sec.).

## 4.12.21 lldp config chassis re-init-delay

Configure the LLDP re-initialization delay (unit: seconds, min.: 1 sec., max.: 10 sec., default: 2 sec.).

### Format

```
lldp config chassis re-init-delay <re-init delay>
```

### Mode

Global Config

### Re-init-delay

Configure the LLDP re-initialization delay (unit:seconds, min.: 1 sec., max.: 10 sec., default: 2 sec.).

## 4.12.22 lldp config chassis tx-delay

Configure the LLDP transmit delay, the delay between successive LLDP frame transmissions (unit: seconds, min.: 1 sec., max.: 8192 sec., default: 2 sec.).

### Format

```
lldp config chassis tx-delay <tx delay>
```

### Mode

```
Global Config
```

### Tx-delay

Configure the LLDP transmit delay, the delay between successive LLDP frame transmissions (unit: seconds, min.: 1 sec., max.: 8192 sec., default: 2 sec.).

## 4.12.23 lldp config chassis tx-hold-mult

Configure the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval), min.: 2, max.: 10, default: 4.

### Format

```
lldp config chassis tx-hold-mult  
                                <tx hold multiplier>
```

### Mode

```
Global Config
```

### Tx-hold-mult

Configure the LLDP transmit hold multiplier, a time-to-live value expressed as a multiple of the LLDP Message Tx Interval (tx-interval), min.: 2, max.: 10, default: 4.

### 4.12.24lldp chassis tx-interval

Configure the interval at which LLDP frames are transmitted on behalf of this LLDP agent (unit: seconds, min.: 5 sec., max.: 32768 sec., default: 30 sec.)

**Format**

```
lldp chassis tx-interval <tx interval>
```

**Mode**

Global Config

**Tx-interval**

Configure the interval at which LLDP frames are transmitted on behalf of this LLDP agent (unit: seconds, min.: 5 sec., max.: 32768 sec., default: 30 sec.).

### 4.12.25clear lldp config all

Clear the LLDP configuration, i. e., set all configurable parameters to default values (all chassis- as well as port-specific parameters at once).

Note: LLDP Remote data remains unaffected.

**Format**

```
clear lldp config all
```

**Mode**

Privileged EXEC

### 4.12.26 lldp admin-state

Configure the port's LLDP admin state (if LLDP/IEEE802.1AB frames will be transmitted to and/or received from the standard IEEE multicast address 01:80:c2:00:00:0e).

The default setting is tx-and-rx.

**Format**

```
lldp admin-state <{tx-only|rx-only|tx-and-rx|off}>
```

**Mode**

```
Interface Config
```

### 4.12.27 lldp fdb-mode

Configure the port's LLDP FDB mode.

The default setting is autodetect.

**Format**

```
lldp fdb-mode <{lldp-only|mac-only|lldp-and-  
mac|autodetect}>
```

**Mode**

```
Interface Config
```

### 4.12.28 lldp hm-mode

Configure the port's LLDP Hirschmann mode (if LLDP/IEEE802.1AB frames will be transmitted to and/or received from the Hirschmann-specific multicast address 01:80:63:2f:ff:0b).

The default setting is `tx-and-rx`.

**Format**

```
lldp hm-mode <{tx-only|rx-only|tx-and-rx|off}>
```

**Mode**

```
Interface Config
```

### 4.12.29 lldp max-neighbors

Configure the port's LLDP max. no. of neighbors (min.: 1, max.: 50, default: 10).

**Format**

```
lldp max-neighbors <1..50>
```

**Mode**

```
Interface Config
```

### 4.12.30 lldp med

LLDP for Media Endpoint Devices (LLDP-MED) is an extension to LLDP that operates between endpoint devices such as IP phones, Voice / Media Gateways, Media Servers, IP Communications Controllers or other VoIP devices or servers, and network devices such as switches. It specifically provides support for voice over IP (VoIP) applications. In this purpose, it provides an additional set of common advertisement messages (TLVs), for capabilities

discovery, network policy, Power over Ethernet, inventory management and location information.

Use this command to enable MED. By enabling MED, you will be effectively enabling the transmit and receive function of LLDP.

**Default**

Enabled

**Format**

lldp med

**Mode**

Interface Config

U no lldp med

Use this command to disable MED.

**Format**

no lldp med

**Mode**

Interface Config

### 4.12.31 lldp med all

Use this command to configure LLDP-MED on all the ports.

**Default**

Enabled

**Format**

lldp med all

**Mode**

Global Config

### 4.12.32 lldp med confignotification

Use this command to configure all the ports to send the topology change notification.

**Default**

Disabled

**Format**

lldp med confignotification

**Mode**

Interface Config

### U no lldp med confignotification

Use this command to disable notifications.

**Format**

no lldp med confignotification

**Mode**

Interface Config

### 4.12.33 lldp med confignotification all

Use this command to configure all the ports to send the topology change notification.

**Default**

Disabled

**Format**

lldp med confignotification all

**Mode**

Global Config



### 4.12.34 lldp med faststartrepeatcount

Use this command to set the value of the fast start repeat count.

**Default**

3

**Format**

```
lldp med faststartrepeatcount [count]
```

**Mode**

Global Config

**[count]**

The number of LLDP PDUs that will be transmitted when the product is enabled. The range is 1 to 10.

U no lldp med faststartrepeatcount

Use this command to return to the factory default value.

**Format**

```
no lldp med faststartrepeatcount
```

**Mode**

Global Config

### 4.12.35 lldp med transmit-tlv

Use this command to specify which optional Type Length Values (TLVs) in the LLDP-MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

**Default**

By default, the capabilities and network policy TLVs are included.

**Format**

```
lldp med transmit-tlv [capabilities]
                               [network-policy]
```

**Mode**

Interface Config

**capabilities**

Include/Exclude LLDP capabilities TLV.

**network-policy**

Include/Exclude LLDP network policy TLV.

U no lldp med transmit-tlv

Use this command to remove a TLV.

**Format**

```
no lldp med transmit-tlv [capabilities]
                               [network-policy]
```

**Mode**

Interface Config

### 4.12.36lldp med transmit-tlv all

Use this command to specify which optional Type Length Values (TLVs) in the LLDP MED set will be transmitted in the Link Layer Discovery Protocol Data Units (LLDPDUs).

**Default**

By default, the capabilities and network policy TLVs are included.

**Format**

```
lldp med transmit-tlv all [capabilities]
                               [network-policy]
```

**Mode**

Global Config

**capabilities**

Include/Exclude LLDP capabilities TLV.

**network-policy**

Include/Exclude LLDP network policy TLV.

U no lldp med med transmit-tlv all

Use this command to remove a TLV.

**Format**

```
no lldp med transmit-tlv all [capabilities]
                               [network-policy]
```

**Mode**

Global Config

### 4.12.37 lldp notification

Configure the port's LLDP notification setting (on or off, default: off).

**Format**

```
lldp notification <{off|on}>
```

**Mode**

Interface Config

### 4.12.38 lldp tlv link-aggregation

Configure the port's LLDP TLV inclusion of Link Aggregation (on or off, default: on).

**Format**

```
lldp tlv link-aggregation <{off|on}>
```

**Mode**

Interface Config

### 4.12.39 lldp tlv mac-phy-config-state

Configure the port's LLDP TLV inclusion of MAC Phy. Cfg. State (on or off, default: on).

**Format**

```
lldp tlv mac-phy-config-state <{off|on}>
```

**Mode**

Interface Config

#### 4.12.40 lldp tlv max-frame-size

Configure the port's LLDP TLV inclusion of Max. Frame Size (on or off, default: on).

**Format**

```
lldp tlv max-frame-size <{off|on}>
```

**Mode**

```
Interface Config
```

#### 4.12.41 lldp tlv mgmt-addr

Configure the port's LLDP TLV inclusion of Management Address (on or off, default: on).

**Format**

```
lldp tlv mgmt-addr <{off|on}>
```

**Mode**

```
Interface Config
```

#### 4.12.42 lldp tlv pnie

Configure the port's LLDP TLV inclusion of PROFINET IO Status (on or off, default: on).

**Format**

```
lldp tlv pnie <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.43 lldp tlv pnio-alias

Configure the port's LLDP TLV inclusion of PROFINET IO Alias (on or off, default: on).

**Format**

```
lldp tlv pnio-alias <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.44 lldp tlv pnio-mrp

Configure the port's LLDP TLV inclusion of PROFINET IO MRP (on or off, default: on).

**Format**

```
lldp tlv pnio-mrp <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.45 lldp tlv port-desc

Configure the port's LLDP TLV inclusion of Port Description (on or off, default: on).

**Format**

```
lldp tlv port-desc <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.46 lldp tlv port-vlan

Configure the port's LLDP TLV inclusion of Port VLAN (on or off, default: on).

**Format**

```
lldp tlv port-vlan <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.47 lldp tlv gmrp

Configure the port's LLDP TLV inclusion of GMRP (on or off, default: on).

**Format**

```
lldp tlv gmrp <{off|on (on)}>
```

**Mode**

```
Interface Config
```

### 4.12.48 lldp tlv igmp

Configure the port's LLDP TLV inclusion of IGMP (on or off, default: on).

**Format**

```
lldp tlv igmp <{off|on (on)}>
```

**Mode**

```
Interface Config
```

### 4.12.49 lldp tlv portsec

Configure the port's LLDP TLV inclusion of PortSec (on or off, default: on).

**Format**

```
lldp tlv portsec <{off|on (on)}>
```

**Mode**

Interface Config

### 4.12.50 lldp tlv ptp

Configure the port's LLDP TLV inclusion of PTP (on or off, default: on).

**Format**

```
lldp tlv ptp <{off|on (on)}>
```

**Mode**

Interface Config

### 4.12.51 lldp tlv protocol

Configure the port's LLDP TLV inclusion of Protocol (on or off, default: on).

**Format**

```
lldp tlv protocol <{off|on (on)}>
```

**Mode**

Interface Config



### 4.12.52 lldp tlv sys-cap

Configure the port's LLDP TLV inclusion of System Capabilities (on or off, default: on).

**Format**

```
lldp tlv sys-cap <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.53 lldp tlv sys-desc

Configure the port's LLDP TLV inclusion of System Description (on or off, default: on).

**Format**

```
lldp tlv sys-desc <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.54 lldp tlv sys-name

Configure the port's LLDP TLV inclusion of System Name (on or off, default: on).

**Format**

```
lldp tlv sys-name <{off|on}>
```

**Mode**

```
Interface Config
```

### 4.12.55 lldp tlv vlan-name

Configure the port's LLDP TLV inclusion of VLAN Name.

**Format**

```
lldp tlv vlan-name <{off|on}>
```

**Mode**

Interface Config

### 4.12.56 name

Set or remove a descriptive name for the current interface (physical ports only).

**Format**

```
name <descriptive name>
```

**Mode**

Interface Config

**<descriptive name>**

Enter a descriptive name for the current interface (physical ports only). Max. length is 20 characters.

Note: If it contains blanks or exclamation marks (!), enclose it in quotation marks ("). The description itself must not contain any quotation marks (' or "), question marks (?) or backslashes (\).

**U no name**

Delete the descriptive name for the current interface (physical ports only).

**Format**

```
no name
```

**Mode**

Interface Config

## 4.13 SNTP - Simple Network Time Protocol

These commands show and configure the SNTP parameters.

### 4.13.1 show sntp

This command shows all SNTP settings.

#### **Format**

```
show sntp
```

#### **Mode**

```
Privileged EXEC and User EXEC
```

#### **SNTP Server Anycast Address**

Show SNTP Server Anycast Address (a.b.c.d).

#### **SNTP Server Anycast Transmit Interval**

Show SNTP Anycast Transmit Interval (in seconds).

#### **SNTP Server Anycast VLAN**

Show SNTP Server Anycast VLAN.

#### **SNTP Server Disable if Timesource is local**

Show SNTP Server Disable if Timesource is local (Yes/No).

#### **SNTP Client Accepts Broadcasts**

Show SNTP Client Accepts Broadcasts (Yes/No).

#### **SNTP Client Disable after Synchronization**

Show SNTP Client Disable after Synchronization (Yes/No).

#### **SNTP Client Request Interval**

Show SNTP Client Request Interval (in seconds).

### **SNTP Client Local Time Offset**

Show SNTP Client Local Time Offset (in minutes).

### **SNTP Client Primary Server IP Address**

Show SNTP Client Primary Server IP Address (a.b.c.d).

### **SNTP Client Secondary Server IP Address**

Show SNTP Client Secondary Server IP Address (a.b.c.d).

### **SNTP Client Threshold to Server Time**

Show SNTP Client Threshold to Server Time (in milliseconds).

### **SNTP Operation Global**

Show SNTP Operation Global (Disabled or Enabled).

### **SNTP Operation Server**

Show SNTP Operation Server (Disabled or Enabled).

### **SNTP Operation Client**

Show SNTP Operation Client (Disabled or Enabled).

### **SNTP Status**

Show SNTP Status

### **SNTP Time**

Show SNTP Time (yyyy-mm-dd hh:mm:ss).

### **SNTP System Time**

Show SNTP system Time (yyyy-mm-dd hh:mm:ss).

## 4.13.2 show sntp anycast

This command shows all SNTP anycast configuration settings.

### **Format**

```
show sntp anycast [address|transmit-interval|vlan]
```

### **Mode**

Privileged EXEC and User EXEC

**address**

Show the SNTP server's anycast destination IP Address.

**transmit-interval**

Show the SNTP Server's interval for sending Anycast messages (unit: seconds).

**vlan**

Show the SNTP server's Anycast VLAN ID (used for sending Anycast messages).

### 4.13.3 show sntp client

This command shows all SNTP anycast configuration settings.

**Format**

```
show sntp client [accept-broadcast |
                  disable-after-sync |
                  offset |
                  request-interval |
                  server<primary|secondary> |
                  threshold]
```

**Mode**

Privileged EXEC and User EXEC

**accept-broadcast**

Show if the SNTP Client accepts SNTP broadcasts.

**disable-after-sync**

Show if the SNTP client will be disabled once it is synchronized to the time server.

**offset**

Show the local time's offset (in minutes) with respect to UTC (positive values for locations east of Greenwich).

### **request-interval**

Show the SNTP Client's request interval (unit: seconds).

### **server**

Show the SNTP Client's server IP addresses.

### **server primary**

Show the SNTP Client's primary server IP addresses.

### **server secondary**

Show the SNTP Client's redundant server IP addresses.

### **server threshold**

Show the SNTP Client's threshold in milliseconds.

## 4.13.4 show sntp operation

This command shows if the SNTP function is enabled or disabled.

### **Format**

```
show sntp operation
```

### **Mode**

Privileged EXEC and User EXEC

## 4.13.5 show sntp server

This command shows the SNTP Server's configuration parameters.

### **Format**

```
show sntp server [disable-if-local]
```

### **Mode**

Privileged EXEC and User EXEC

### **disable-if-local**

Show if the server will be disabled if the time is running from the local clock and not synchronized to an external time source.

## 4.13.6 show sntp status

This command shows the SNTP state, synchronization and error messages.

### **Format**

```
show sntp status
```

### **Mode**

Privileged EXEC and User EXEC

### 4.13.7 show sntp time

This command shows time and date.

**Format**

```
show sntp time [sntp|system]
```

**Mode**

Privileged EXEC and User EXEC

**sntp**

Show the current SNTP date and UTC time.

**system**

Show the local system's current date and time.

### 4.13.8 no sntp

This command disables sntp.

**Format**

```
no sntp
```

**Mode**

Global Config



### 4.13.9 sntp anycast address

Set the SNTP server's anycast destination IP Address, default: 0.0.0.0 (none).

**Format**

```
sntp anycast address <IPAddress>
```

**Mode**

```
Global Config
```

U no sntp anycast address

Set the SNTP server's anycast destination IP Address to 0.0.0.0.

**Format**

```
no sntp anycast address
```

**Mode**

```
Global Config
```

### 4.13.10 sntp anycast transmit-interval

The transmit interval in seconds, default: 120.

**Format**

```
sntp anycast transmit-interval <1-3600>
```

**Mode**

```
Global Config
```

### 4.13.11 sntp anycast vlan

Set the SNTP server's Anycast VLAN ID used for sending Anycast messages, default: 1.

**Format**

```
sntp anycast vlan <1-4042>
```

**Mode**

```
Global Config
```

### 4.13.12 sntp client accept-broadcast

Enable/Disable that the SNTP Client accepts SNTP broadcasts.

**Format**

```
sntp client accept-broadcast <on | off>
```

**Mode**

```
Global Config
```

#### U no sntp accept-broadcast

Disable the SNTP Client accepts SNTP broadcasts.

**Format**

```
no sntp client accept-broadcast
```

**Mode**

```
Global Config
```

### 4.13.13 sntp client disable-after-sync

If this option is activated, the SNTP client disables itself once it is synchronised to a server.

**Format**

```
sntp client disable-after-sync <on | off>
```

**Mode**

Global Config

**off**

Do not disable SNTP client when it is synchronised to a time server.

**on**

Disable SNTP client as soon as it is synchronised to a time server.

### 4.13.14 sntp client offset

The offset between UTC and local time in minutes, default: 60.

**Format**

```
sntp client offset <-1000 to 1000>
```

**Mode**

Global Config

### 4.13.15 sntp client request-interval

The synchronization interval in seconds, default: 30.

**Format**

```
sntp client request-interval <1-3600>
```

**Mode**

```
Global Config
```

### 4.13.16 no sntp client server

Disable the SNTP client servers.

**Format**

```
no sntp client server
```

**Mode**

```
Global Config
```

### 4.13.17 sntp client server primary

Set the SNTP Client's primary server IP Address, default: 0.0.0.0 (none).

**Format**

```
sntp client server primary <IP-Address>
```

**Mode**

```
Global Config
```

- U no sntp client server primary  
Disable the primary SNTP client server.

**Format**

```
no sntp client server primary
```

**Mode**

```
Global Config
```

### 4.13.18 sntp client server secondary

Set the SNTP Client's secondary server IP Address, default: 0.0.0.0 (none).

**Format**

```
sntp client server secondary <IP-Address>
```

**Mode**

```
Global Config
```

- U no sntp client server secondary  
Disable the secondary SNTP client server.

**Format**

```
no sntp client server secondary
```

**Mode**

```
Global Config
```

### 4.13.19 sntp client threshold

With this option you can reduce the frequency of time alterations. Enter this threshold as a positive integer value in milliseconds. The switch obtains the server timer as soon as the deviation to the server time is above this threshold.

**Format**

```
sntp client threshold <milliseconds>
```

**Mode**

```
Global Config
```

**Milliseconds**

Enter the allowed deviation to the server time as a positive integer value in milliseconds.

U no sntp client threshold  
Disable the sntp client threshold.

**Format**

```
no sntp client threshold
```

**Mode**

```
Global Config
```

## 4.13.20sntp operation

Enable/Disable the SNTP function.

### Format

```
sntp operation <on | off> |  
                    client { on | off } |  
                    server { on | off }
```

### Mode

Global Config

### client

Enable or disable SNTP Client.

### server

Enable or disable SNTP Server.

U no sntp operation  
Disable the SNTP Client and Server.

### Format

```
no sntp operation
```

### Mode

Global Config

### 4.13.21 sntp server disable-if-local

With this option enabled, the switch disables the SNTP Server Function if it is not synchronized to a time server itself.

**Format**

```
sntp server disable-if-local <on | off>
```

**Mode**

Global Config

**off**

Enable the SNTP Server even if it is not synchronized to a time server itself.

**on**

Disable the SNTP Server if it is not synchronized to a time server itself.

### 4.13.22 sntp time system

Set the current sntp time.

**Format**

```
sntp time system <YYYY-MM-DD HH:MM:SS>
```

**Mode**

Global Config



## 4.14 PTP - Precision Time Protocol

These commands show and configure the PTP (IEEE 1588) parameters. The operation parameter is available for all devices. All other parameters are additionally available for MS20/MS30, MACH 1040, MACH 104 and PowerMICE.

### 4.14.1 show ptp

This command shows all PTP settings.

**Format**

```
show ptp
```

**Mode**

```
Privileged EXEC and User EXEC
```

## 4.14.2 show ptp configuration

This command shows the configured PTP (IEEE 1588) values depending on the currently configured clock mode.

### Format

```
show ptp configuration
```

### Mode

Privileged EXEC and User EXEC

### PTP (Global) Clock Mode

Show which PTP clock mode is currently configured.

### PTP (Global) Sync. Upper Bound

Show the upper bound for the PTP clock synchronization status (unit: nanoseconds).

### PTP (Global) Sync. Lower Bound

Show the lower bound for the PTP clock synchronization status (unit: nanoseconds).

## 4.14.3 show ptp operation

Show the global PTP (IEEE 1588) operation setting (the administrative setting). This command shows if PTP is enabled/disabled on this device.

### Format

```
show ptp operation
```

### Mode

Privileged EXEC and User EXEC

### 4.14.4 show ptp port

This command shows the PTP (IEEE 1588) port configuration settings depending on the currently configured clock mode.

**Format**

```
show port [<slot/port>|all]
```

**Mode**

Privileged EXEC and User EXEC

**<slot/port>**

Show the port-related PTP (IEEE 1588) settings for the given port.

**all**

Show the port-related PTP (IEEE 1588) settings for all ports.

## 4.14.5 show ptp status

This command shows the device's global PTP (IEEE 1588) status (the operating states).

### **Format**

```
show ptp status
```

### **Mode**

Privileged EXEC and User EXEC

### **PTP Status, Is Synchronized**

Show if the device is synchronized (true or false).

### **PTP Status, Offset From Master**

Show the device's offset from the master (unit: nanoseconds).

### **PTP Status, Max. Offset Absolute**

Show the device's maximum offset absolute (unit: nanoseconds).

### **PTP Status, Delay To Master**

Show the device's delay to the master (unit: nanoseconds).

### **PTP Status, Grandmaster UUID**

Show grandmaster Universally Unique Identifier  
(32 hexadecimal numbers).

### **PTP Status, Parent UUID**

Show parent Universally Unique Identifier  
(32 hexadecimal numbers).

### **PTP Status, Clock Stratum**

Show the device's clock stratum.

### **PTP Status, Clock Identifier**

Show the device's clock identifier.

## 4.14.6 ptp clock-mode

Configure the Precision Time Protocol (PTP, IEEE 1588) clock mode. If the clock mode is changed, PTP will be initialized. The default is "disable"

### Format

```
ptp clock-mode {v1-simple-mode
                |v2-simple-mode
                |v1-boundary-clock
                |v2-boundary-clock-onestep
                |v2-boundary-clock-twostep
                |v2-transparent-clock}
```

### Mode

Global Config

#### **v1-simple-mode**

Set the clock mode to 'v1 Simple Mode'. This is a client only mode without hardware support. The device only accepts PTPv1 sync messages and sets the time directly. No BMC algorithm will run.

#### **v2-simple-mode**

Set the clock mode to 'v2 Simple Mode'. This is a client only mode without hardware support. The device only accepts PTPv2 sync (or follow\_up) messages and sets the time directly. No BMC algorithm will run.

#### **v1-boundary-clock**

Set the clock mode to 'v1 Boundary Clock'. This specifies the mode as described in the IEEE1588 standard.

#### **v2-boundary-clock-onestep**

Set the clock mode to 'v2 Boundary Clock one-step'. This specifies the boundary-clock mode as described in the IEEE1588-2008 (PTPv2) standard. The precise timestamp is inserted directly into the sync-packet (one-step Mode).

#### **v2-boundary-clock-twostep**

Set the clock mode to 'v2 Boundary Clock two-step'. This specifies the boundary-clock mode as described in the IEEE1588-2008 (PTPv2) standard. The precise timestamp is transmitted via a follow-up packet (two-step Mode).

**v2-transparent-clock**

Set the clock mode to 'v2 Transparent Clock'. This specifies the transparent-clock mode (one-step) as described in the IEEE1588-2008 (PTPv2) standard.

### 4.14.7 ptp operation

Enable or disable the Precision Time Protocol (IEEE 1588).  
The default is "disable"

**Format**

```
ptp operation {disable|enable}
```

**Mode**

Global Config

**disable**

Disable the Precision Time Protocol (IEEE 1588).

**enable**

Enable the Precision Time Protocol (IEEE 1588).

### 4.14.8 ptp sync-lower-bound

Configure the lower bound for the PTP clock synchronization (unit: nanoseconds, min.: 0, max.: 999999999 ( $10^9-1$ ), default: 30).

Note: the lower bound always has to be smaller than the upper bound.

**Format**

```
ptp sync-lower-bound <0-999999999>
```

**Mode**

```
Global Config
```

### 4.14.9 ptp sync-upper-bound

Configure the upper bound for the PTP clock synchronization (unit: nanoseconds, min.: 31, max.: 1000000000 ( $10^9$ ), default: 5000).

Note: the upper bound always has to be larger than the lower bound.

**Format**

```
ptp sync-upper-bound <31-1000000000>
```

**Mode**

```
Global Config
```

### 4.14.10ptp v1 preferred-master

Configure the PTPv1 (IEEE1588-2002) specific settings. Specify if the local switch shall be regarded as a preferred master clock (i. e., if it will remain master in the presence of disconnection or connection of other clocks).

**Format**

```
ptp v1 preferred-master {true|false}
```

**Mode**

Global Config

**true**

The local switch shall be regarded as a preferred master clock.

**false**

The local switch shall not be regarded as a preferred master clock.

### 4.14.11ptp v1 re-initialize

Configure the PTPv1 (IEEE1588-2002) specific settings. Re-initialize the clocks in the local subdomain with the currently configured settings. Changes in the subdomain name or the sync interval will only take effect after this command.

**Format**

```
ptp v1 re-initialize
```

**Mode**

Global Config



## 4.14.12ptp v1 subdomain-name

Configure the PTPv1 (IEEE1588-2002) specific settings.

Enter a Precision Time Protocol subdomain name. The default is "\_DFLT".

Note: changes are only applied after the 're-initialize' command or after a re-boot if the configuration was saved.

### Format

```
ptp v1 subdomain-name <subdomain name>
```

### Mode

Global Config

### <subdomain name>

Enter a PTP subdomain name (up to 16 characters). Valid characters range from hex value 0x21 (!) up to and including hex value 0x7e (~). Enter special characters (\, !, ', ", ?) by preceding them with the escape character (\), e. g., as \\, \!, \', \", \?. The subdomain name must not be empty. The default is "\_DFLT".

### 4.14.13ptp v1 sync-interval

Configure the PTPv1 (IEEE1588-2002) specific settings.

Configure the Precision Time Protocol sync interval. The sync interval is the interval (in seconds) between successive sync messages issued by a master clock.

Valid values are: sec-1, sec-2, sec-8, sec-16, and sec-64. Default is sec-2.

Note: changes are only applied after the 're-initialize' command or after a reboot if the configuration was saved.

#### Format

```
ptp v1 sync-interval {sec-1|sec-2|sec-8|sec-16|
                    sec-64}
```

#### Mode

Global Config

#### sec-1

Set the PTP sync interval to sec-1 (1 sec).

#### sec-2

Set the PTP sync interval to sec-2 (2 sec).

#### sec-8

Set the PTP sync interval to sec-8 (8 sec).

#### sec-16

Set the PTP sync interval to sec-16 (16 sec).

#### sec-64

Set the PTP sync interval to sec-64 (64 sec).

### 4.14.14ptp v2bc priority1

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the priority1 value (0..255) for the BMC as described in IEEE1588-2008.

**Format**

```
ptp v2bc priority1 <0-255>
```

**Mode**

```
Global Config
```

### 4.14.15ptp v2bc priority2

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the priority2 value (0..255) for the BMC as described in IEEE1588-2008.

**Format**

```
ptp v2bc priority2 <0-255>
```

**Mode**

```
Global Config
```

### 4.14.16ptp v2bc domain

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the domain number (0..255) as described in IEEE1588-2008.

**Format**

```
ptp v2bc domain <0-255>
```

**Mode**

```
Global Config
```

### 4.14.17ptp v2bc utc-offset

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the current UTC offset in seconds.

**Format**

```
ptp v2bc utc-offset <seconds>
```

**Mode**

```
Global Config
```

### 4.14.18ptp v2bc utc-offset-valid

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Configure the UTC offset valid flag.

**Format**

```
ptp v2bc utc-offset-valid {true|false}
```

**Mode**

```
Global Config
```

### 4.14.19 ptp v2bc vlan

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Use this command to configure the VLAN in which PTP packets are send. With a value of none all packets are send untagged.

**Format**

```
ptp v2bc vlan {none | <0-4042>}
```

**Mode**

```
Interface Config
```

### 4.14.20 ptp v2bc vlan-priority

Configure the PTPv2 Boundary Clock (IEEE1588-2008) specific settings. Use this command to configure the VLAN priority.

**Format**

```
ptp v2bc vlan-priority <0-7>
```

**Mode**

```
Interface Config
```

### 4.14.21 ptp v1 burst

Enable or disable the the burst feature for synchronization runs during a synchronization interval. Default is disable.

**Format**

```
ptp v1 burst {enable|disable}
```

**Mode**

```
Interface Config
```

**enable**

During a synchronization interval, there are 2 to 8 synchronization runs. This permits faster synchronization when the network load is high.

**disable**

During a synchronization interval, there is only one synchronization run.

## 4.14.22ptp v1 operation

Enable or disable the sending and receiving / processing of PTP synchronization messages. Default is enable.

**Format**

```
ptp v1 operation {enable|disable}
```

**Mode**

```
Interface Config
```

**enable**

Port sends and receives/ processes PTP synchronization messages.

**disable**

Port blocks PTP synchronization messages.

### 4.14.23 ptp v2bc operation

Enable or disable the sending and receiving / processing of PTP synchronization messages.

**Format**

```
ptp v2bc operation {disable|enable}
```

**Mode**

```
Interface Config
```

**enable**

Port sends and receives/ processes PTP synchronization messages.

**disable**

Port blocks PTP synchronization messages.

### 4.14.24 ptp v2bc announce-interval

Configure the Announce Interval in seconds {1|2|4|8|16}.

**Format**

```
ptp v2bc announce-interval {1|2|4|8|16}
```

**Mode**

```
Interface Config
```

### 4.14.25ptp v2bc announce-timeout

Configure the Announce Receipt Timeout (2..10).

**Format**

```
ptp v2bc announce-timeout <2-10>
```

**Mode**

Interface Config

### 4.14.26ptp v2bc sync-interval

Configure the Sync Interval in seconds {0.5|1|2}.

**Format**

```
ptp v2bc sync-interval {0.5|1|2}
```

**Mode**

Interface Config

### 4.14.27ptp v2bc delay-mechanism

Configure the delay mechanism {e2e|p2p|disabled} of the transparent-clock.

**Format**

```
ptp v2bc delay-mechanism {e2e|p2p|disabled}
```

**Mode**

Interface Config



### 4.14.28 ptp v2bc pdelay-interval

Configure the Peer Delay Interval in seconds {1|2|4|8|16|32}. This interval is used if delay-mechanism is set to p2p.

**Format**

```
ptp v2bc pdelay-interval {1|2|4|8|16|32}
```

**Mode**

```
Interface Config
```

### 4.14.29 ptp v2bc network-protocol

Configure the network-protocol {ieee802\_3|udp\_ipv4} of the transparent-clock.

**Format**

```
ptp v2bc network-protocol {ieee802_3 | udp_ipv4}
```

**Mode**

```
Interface Config
```

### 4.14.30 ptp v2bc v1-compatibility-mode

Set the PTPv1 Hardware compatibility mode {auto|on|off}.

**Format**

```
ptp v2bc v1-compatibility-mode {auto|on|off}
```

**Mode**

```
Interface Config
```

### 4.14.31 ptp v2bc asymmetry

Specifies the asymmetry in nanoseconds of the link connected to this port {+-1000000000}.

**Format**

```
ptp v2bc asymmetry <value in ns>
```

**Mode**

```
Interface Config
```

### 4.14.32 ptp v2tc asymmetry

Specifies the asymmetry in nanoseconds of the link connected to this port {+-1000000000}.

**Format**

```
ptp v2tc asymmetry <value in ns>
```

**Mode**

```
Interface Config
```

### 4.14.33 ptp v2tc delay-mechanism

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the delay mechanism {e2e | p2p | disabled} of the transparent-clock.

**Format**

```
ptp v2tc delay-mechanism {e2e|p2p}
```

**Mode**

```
Global Config
```

### 4.14.34ptp v2tc management

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the management of the transparent-clock (disable for fast packet rates).

**Format**

```
ptp v2tc management {enable|disable}
```

**Mode**

```
Global Config
```

### 4.14.35ptp v2tc multi-domain-mode

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the transparent-clock for one (primary-domain) or all domain numbers.

**Format**

```
ptp v2tc multi-domain-mode {enable|disable}
```

**Mode**

```
Global Config
```

### 4.14.36ptp v2tc network-protocol

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the network-protocol {ieee802\_3|udp\_ipv4} of the transparent-clock.

**Format**

```
ptp v2tc network-protocol {ieee802_3|udp_ipv4}
```

**Mode**

Global Config

### 4.14.37ptp v2tc operation

Enable or disable the sending and receiving/ processing of PTP synchronization messages.

**Format**

```
ptp v2tc operation {disable|enable}
```

**Mode**

Interface Config

**enable**

Port sends and receives/ processes PTP synchronization messages.

**disable**

Port blocks PTP synchronization messages.

### 4.14.38ptp v2tc pdelay-interval

Configure the Peer Delay Interval in seconds {1|2|4|8|16|32}. This interval is used if delay-mechanism is set to p2p.

**Format**

```
ptp v2tc pdelay-interval {1|2|4|8|16|32}
```

**Mode**

```
Interface Config
```

### 4.14.39ptp v2tc primary-domain

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Configure the primary-domain {for syntonization} of the transparent-clock.

**Format**

```
ptp v2tc primary-domain <0-255>
```

**Mode**

```
Global Config
```

### 4.14.40ptp v2tc syntonization

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Enable or disable the syntonization of the transparent-clock.

**Format**

```
ptp v2tc syntonization {enable|disable}
```

**Mode**

```
Global Config
```

### 4.14.41 ptp v2tc vlan

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to configure the VLAN in which PTP packets are send. With a value of none all packets are send untagged.

**Format**

```
ptp v2tc vlan {none | <0-4042>}
```

**Mode**

```
Global Config
```

### 4.14.42 ptp v2tc vlan-priority

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to configure the VLAN priority of tagged ptp packets.

**Format**

```
ptp v2tc vlan-priority <0-7>
```

**Mode**

```
Global Config
```

### 4.14.43ptp v2tc sync-local-clock

Configure the PTPv2 Transparent Clock (IEEE1588-2008) specific settings. Use the command to enable or disable synchronisation of the local clock (only valid if syntonization is enabled).

**Format**

```
ptp v2tc sync-local-clock {enable | disable}
```

**Mode**

```
Global Config
```





## 4.15 PoE - Power over Ethernet

These commands show and configure the Power over Ethernet (IEEE 802.3af) parameters.

### 4.15.1 show inlinepower

This command shows global Inline Power settings PoE.

**Format**

```
show inlinepower
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.15.2 show inlinepower port

This command shows the configuration settings and states per port.

**Format**

```
show inlinepower port [<slot/port> | all]
```

**Mode**

```
Privileged EXEC and User EXEC
```

### 4.15.3 inlinepower (Global Config)

Configure the global Inline Power parameters.

#### Format

```
inlinepower {admin-mode {disable|enable} |  
trap {disable|enable} | threshold <1-99> |  
fast-startup {enable|disable} }
```

#### Mode

Global Config

#### admin-mode

Configure the global Inline Power administrative setting (enable or disable, default: enable).

#### trap

Configure the Inline Power notification (trap) setting (enable or disable, default: disable).

#### threshold

Configure the Inline Power notification (trap) threshold (unit: percent of maximum rated power, valid range: 1-99, default: 90).

#### fast-startup

Configure the Inline Power to be enabled at the beginning of the start phase (enable or disable, default: disable).

## 4.15.4 inlinepower (Interface Config)

Configure the port-related Inline Power parameters.

Note: The interface name you enter in the `name`-command.

### Format

```
inlinepower {admin-mode {disable|enable} |  
priority {critical|high|low} }
```

### Mode

Interface Config

### admin-mode

Configure the port-related Inline Power administrative setting (enable or disable, default: enable).

### priority

Configure the Inline Power priority for this port. In case of power scarcity, inline power on ports configured with the lowest priority is dropped first. Possible values are: critical, high or low, default: low. The highest priority is critical.

This parameter is available for MACH 1000, MACH 4000 and devices which support Power over Ethernet Plus (MACH104-16TX-PoEP devices and MACH 102 devices with media module M1-8TP-RJ45 PoE).

## 4.15.5 clear inlinepower

Reset the Inline Power parameters to default settings.

### Format

```
clear inlinepower
```

### Mode

Privileged EXEC



## 4.16 PoE+ - Power over Ethernet Plus

Additionally to the PoE (Power over Ethernet) commands, these commands show and configure the Power over Ethernet Plus (IEEE 802.3at) parameters.

PoE+ is available for:

- MACH104-16TX-PoEP devices
- MACH 102 devices with media module M1-8TP-RJ45 PoEP

### 4.16.1 show inlinepower slot

This command shows the PoE+ configuration settings and states per slot.

#### **Format**

```
show inlinepower slot [<slot> | all]
```

#### **Mode**

Privileged EXEC and User EXEC

#### **Slot**

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

#### **Nominal Power**

Shows the configured nominal power budget which the device provides for the PoE+ ports of the PoE+ module.

#### **Maximum Power**

Shows the nominal power which the device provides for the PoE+ ports of the PoE+ module (valid range: 0 - 248 W).

**Reserved Power**

Shows the maximum power which the device provides for all PoE+ devices together which are connected to the PoE+ module, based on their classification.

**Delivered Power**

Shows the current demand for power on all PoE+ ports of the module (valid range: 0 - 248 W).

**Send Traps**

Shows, if the function is enabled/disabled. If send traps is enabled, the device will send a trap if the power threshold exceeds or falls below the power limit or if the PoE+ power supply is switched on/off on one or more ports.

**Power Threshold**

Power threshold in per cent of the nominal power. If the power is exceeding/falling below this threshold, the device will send a trap.

## 4.16.2 inlinepower budget slot

Configure the available power budget per slot in Watts.

**Format**

```
inlinepower budget slot <slot> <0..1000>
```

**Mode**

```
Global Config
```

**Slot**

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

### 4.16.3 inlinepower threshold slot

Configure the usage power threshold expressed in per cents for comparing the measured power for this slot and initiating an alarm if the threshold is exceeded.

**Format**

```
inlinepower threshold slot <slot> <0..99>
```

**Mode**

```
Global Config
```

**Slot**

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1

### 4.16.4 inlinepower trap slot

Configure the alarm that is send if the configured threshold for this slot is exceeded.

**Format**

```
inlinepower trap slot <slot> {enable | disable}
```

**Mode**

```
Global Config
```

**Slot**

For MACH102 devices with M1-8TP-RJ45 PoEP media modules:

Slot = Slot number of the PoE+ module (valid range: 1 - 2)

For MACH104-16TX-PoEP devices: Slot = 1





## 4.17 Port monitor

These commands show and configure the port monitor parameters.

The port monitor feature monitors certain port (or global) states or changes and performs a certain action, when the specified condition occurs.

Using this commands, you can disable a port and send a trap (see "port admin shutdown").

Disabling a port by condition will not modify the configuration and therefore not keep the port in disabled state after reload/reboot.

To enable the action if a port state occurs

- D enable the port monitor globally,
- D enable the port monitor on the port,
- D configure condition(s) that is (are) performed in port state on a port and
- D an action that is performed on that port, when the condition complies.

The condition can be link flapping or CRC/Fragments error, an action can be sending a trap or disabling that port (and send a trap).

If a port was disabled by the Port-Monitor the port can be enabled again with a port monitor reset command (see "port-monitor reset").

## 4.17.1 show port-monitor

Use this command to display the global Port Monitor settings.

### **Format**

```
show port-monitor
```

### **Mode**

```
Global Config
```

### **Port Monitor**

Display if Port Monitor function is enabled or disabled.

### **Condition crc-fragment interval (seconds)**

Display the condition of the CRC fragment interval in seconds.

### **Condition crc-fragment count**

Display the condition of the CRC fragment count.

### **Condition link flap interval (seconds)**

Display the condition of the link flap interval in seconds.

### **Condition link flap count**

Display the condition of the link flap count.

## 4.17.2 show port-monitor <slot/port>

Use this command to display the Port Monitor details for the port.

### **Format**

```
show port-monitor <slot/port>
```

### **Mode**

Global Config

### **Port Monitor**

Display if Port Monitor is enabled or disabled.

### **Link Flap**

Display if Link Flap is enabled or disabled.

### **Crc-Fragment**

Display if CRC Fragment is enabled or disabled.

### **Active Condition**

Display the active condition for the port.

Possible values: Link-Flap, None.

### **Action**

Display the action (disable port or send trap) to be triggered on the port. Possible values: Disable-Port, Trap-Only.

### **Port Oper State**

Display the link state of the port. Possible values: Up, Down.

### 4.17.3 show port-monitor brief

Use this command to display the Port Monitor brief summary.

**Format**

```
show port-monitor brief
```

**Mode**

Global Config

**Intf**

Display the number of the interface (slot/port).

**Admin Mode**

Display if Port Monitor is enabled or disabled.

**Link Flap**

Display if Link Flap is enabled or disabled.

**Crc Fragment**

Display if CRC Fragment is enabled or disabled.

**Active Condition**

Display the active condition for the port.

Possible values: Link-Flap, None.

**Action**

Display the action (disable port or send trap) to be triggered on the port. Possible values: Disable-Port, Trap-Only.

**Port Oper State**

Display the link state of the port. Possible values: Up, Down.

#### 4.17.4 show port-monitor crc-fragment

Use this command to display the CRC fragment counter.

**Format**

```
show port-monitor crc-fragment <slot/port>
```

**Mode**

```
Global Config
```

**<slot/port>**

Display the Port Monitor interface details.

**Crc\_fragments in last interval**

Display the CRC fragments in last interval.

**Crc\_fragments total**

Display the CRC fragments total.

#### 4.17.5 show port-monitor link-flap

Use this command to display the Link Flap counter for the port.

**Format**

```
show port-monitor link-flap <slot/port>
```

**Mode**

```
Global Config
```

**<slot/port>**

Display the Port Monitor interface details.

**Link flaps in last interval**

Display the Link flaps in last interval.

**Link flaps total**

Display the Link flaps total.

### 4.17.6 port-monitor (Global Config)

Use this command to enable or disable the Port Monitor globally.

**Note:** This command does not reset the port disable states.

**Default**

Disable

**Format**

```
port-monitor {enable | disable}
```

**Mode**

Global Config

### 4.17.7 port-monitor (Interface Config)

Use this command to enable or disable the Port Monitor on the port.

**Note:** This command does not reset the port disable states.

**Default**

Disable

**Format**

```
port-monitor {enable | disable}
```

**Mode**

Interface Config

### 4.17.8 port-monitor condition link-flap (Global Config)

Use this command to configure the Link Flap settings (Link Flap counter and interval for Link Flap detection).

**Default**

Disable

**Format**

```
port-monitor condition link-flap
                               {count <1-100>| interval <1-180>}
```

**Mode**

Global Config

**count**

Configure the Link Flap counter.

Default: 5. Value range: 1 - 100.

**interval**

Configure the measure interval in seconds for Link Flap detection.

Default: 10 seconds. Value range: 1 - 180 seconds.

### 4.17.9 port-monitor condition link-flap (Interface Config)

Use this command to enable or disable Link Flap condition on a port to trigger an action.

**Default**

Disable

**Format**

```
port-monitor condition link-flap {enable | disable}
```

**Mode**

Interface Config

## 4.17.10 port-monitor condition crc-fragment (Global Config)

Use this command to configure the crc-fragment settings (crc-fragment counter and interval for crc-fragment detection).

### Default

Disable

### Format

```
port-monitor condition crc-fragment  
                    {count <1-1000000> | interval <5-180>}
```

### Mode

Global Config

### count

Configure the crc-fragment counter.  
Default: 1,000. Value range: 1 - 1,000,000.

### interval

Configure the measure interval in seconds for crc-fragment detection.  
Default: 10 seconds. Value range: 5 - 180 seconds.



### 4.17.11 port-monitor condition crc-fragment (Interface Config)

Use this command to enable or disable crc-fragment settings on a port to trigger an action.

**Default**

Disable

**Format**

```
port-monitor condition crc-fragment  
{enable | disable}
```

**Mode**

Interface Config

### 4.17.12 port-monitor action

Use this command to configure the Port Monitor action (disable a port or send a trap).

**Note:** Disable the Port Monitor action will reset the port from port-state.

**Default**

Enable

**Format**

```
port-monitor action {port-disable | trap-only}
```

**Mode**

Interface Config

**port-disable**

Disable the port when the configured Port Monitor condition triggers.

**trap-only**

Send a trap when the configured Port Monitor condition triggers.



## 5 CLI Commands: Switching

This section provides detailed explanation of the Switching commands. The commands are divided into two functional groups:

- D Show commands display spanning tree settings, statistics, and other information.
- D Configuration Commands configure features and options of the switch. For every configuration command there is a show command that displays the configuration setting.



## 5.1 Spanning Tree Commands

### 5.1.1 show spanning-tree

This command displays spanning tree settings for the common and internal spanning tree, when the optional parameter “brief” is not included in the command. The following details are displayed.

**Format**

```
show spanning-tree [brief]
```

**Mode**

Privileged EXEC and User EXEC

**Spanning Tree Adminmode**

Enabled or Disabled

**Bridge Priority**

Configured value.

**Bridge Identifier**

The bridge identifier for the CST (CST = Classical Spanning Tree IEEE 802.1d). It is made up using the bridge priority and the base MAC address of the bridge.

**Time Since Topology Change**

in seconds

**Topology Change Count**

Number of times changed.

**Topology Change**

Boolean value of the Topology Change parameter for the switch indicating if a topology change is in progress on any port assigned to the common and internal spanning tree.

**Designated Root**

The bridge identifier of the root bridge. It is made up from the bridge priority and the base MAC address of the bridge.

**Root Path Cost**

Value of the Root Path Cost parameter for the common and internal spanning tree.

**Root Port Identifier**

Identifier of the port to access the Designated Root for the CST.

**Root Port Max Age**

Derived value

**Root Port Bridge Forward Delay**

Derived value

**Hello Time**

Configured value

**Bridge Hold Time**

Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)

**CST Regional Root**

Bridge Identifier of the CST Regional Root. It is made up using the bridge priority and the base MAC address of the bridge.

**Regional Root Path Cost**

Path Cost to the CST Regional Root.

**Associated FIDs**

List of forwarding database identifiers currently associated with this instance.

**Associated VLANs**

List of VLAN IDs currently associated with this instance.

U show spanning-tree brief

When the “brief” optional parameter is included, this command displays a brief overview of the spanning tree settings for the bridge. In this case, the following details are displayed.

**Bridge Priority**

Configured value.

**Bridge Identifier**

The bridge identifier for the selected MST instance. It is made up using the bridge priority and the base MAC address of the bridge.

**Bridge Max Age**

Configured value.

**Bridge Hello Time**

Configured value.

**Bridge Forward Delay**

Configured value.

**Bridge Hold Time**

Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)

**Rstp Mrp Mode**

Rapid spanning tree mrp (Media Redundancy Protocol) mode (Enabled/Disabled)

**Rstp Mrp configuration error**

Configuration error in Rapid spanning tree mrp (Media Redundancy Protocol) (No/Yes)

## 5.1.2 show spanning-tree interface

This command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. The following details are displayed on execution of the command.

**Format**

```
show spanning-tree interface <slot/port>
```

**Mode**

Privileged EXEC and User EXEC

**Port mode**

Enabled or disabled.

**Port Up Time Since Counters Last Cleared**

Time since port was reset, displayed in days, hours, minutes, and seconds.

**STP BPDUs Transmitted**

Spanning Tree Protocol Bridge Protocol Data Units sent

**STP BPDUs Received**

Spanning Tree Protocol Bridge Protocol Data Units received.

**RST BPDUs Transmitted**

Rapid Spanning Tree Protocol Bridge Protocol Data Units sent

**RST BPDUs Received**

Rapid Spanning Tree Protocol Bridge Protocol Data Units received.

**MSTP BPDUs Transmitted**

Multiple Spanning Tree Protocol Bridge Protocol Data Units sent

**MSTP BPDUs Received**

Multiple Spanning Tree Protocol Bridge Protocol Data Units received.

### 5.1.3 show spanning-tree mst detailed

This command displays settings and parameters for the specified multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance ID. The following details are displayed.

**Format**

```
show spanning-tree mst detailed <mstid>
```

**Mode**

Privileged EXEC and User EXEC

**mstid**

Enter a multiple spanning tree instance identifier.  
Valid values: 0 - 4094.



**MST Instance ID**

Valid value: 0

**MST Bridge Priority**

Valid values: 0-61440 in increments of 4096.

**Time Since Topology Change**

in seconds

**Topology Change Count**

Number of times the topology has changed for this multiple spanning tree instance.

**Topology Change in Progress**

Value of the Topology Change parameter for the multiple spanning tree instance.

**Designated Root**

Identifier of the Regional Root for this multiple spanning tree instance.

**Root Path Cost**

Path Cost to the Designated Root for this multiple spanning tree instance

**Root Port Identifier**

Port to access the Designated Root for this multiple spanning tree instance

**Associated FIDs**

List of forwarding database identifiers associated with this instance.

**Associated VLANs**

List of VLAN IDs associated with this instance.

### 5.1.4 show spanning-tree mst port detailed

This command displays the detailed settings and parameters for a specific switch port within a particular multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <slot/port> is the desired switch port.

**Format**

```
show spanning-tree mst port detailed <mstid> <slot/  
port>
```

**Mode**

Privileged EXEC and User EXEC

**MST Instance ID**

Valid value: 0

**Port Identifier**

Port priority as a two digit hex number followed by the port number as a two digit hex number.

**Port Priority**

Decimal number.

**Port Forwarding State**

Current spanning tree state of this port

**Port Role**

The port's current RSTP port role.

**Port Path Cost**

Configured value of the Internal Port Path Cost parameter

**Designated Root**

The Identifier of the designated root for this port.

**Designated Port Cost**

Path Cost offered to the LAN by the Designated Port

**Designated Bridge**

Bridge Identifier of the bridge with the Designated Port.

**Designated Port Identifier**

Port on the Designated Bridge that offers the lowest cost to the LAN

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The <slot/port> is the desired switch port. In this case, the following are displayed.

**Port Identifier**

The port identifier for this port within the CST.

**Port Priority**

The priority of the port within the CST.

**Port Forwarding State**

The forwarding state of the port within the CST.

**Port Role**

The role of the specified interface within the CST.

**Port Path Cost**

The configured path cost for the specified interface.

**Designated Root**

Identifier of the designated root for this port within the CST.

**Designated Port Cost**

Path Cost offered to the LAN by the Designated Port.

**Designated Bridge**

The bridge containing the designated port

**Designated Port Identifier**

Port on the Designated Bridge that offers the lowest cost to the LAN

**Topology Change Acknowledgement**

Value of flag in next Configuration Bridge Protocol Data Unit (BPDU) transmission indicating if a topology change is in progress for this port.

**Hello Time**

The hello time in use for this port.

**Edge Port**

The configured value indicating if this port is an edge port.

**Edge Port Status**

The derived value of the edge port status. True if operating as an edge port; false otherwise.

**Point To Point MAC Status**

Derived value indicating if this port is part of a point to point link.

**CST Regional Root**

The regional root identifier in use for this port.

**CST Port Cost**

The configured path cost for this port.

### 5.1.5 show spanning-tree mst port summary

This command displays the settings of one or all ports within the specified multiple spanning tree instance. The parameter <mstid> indicates a particular MST instance. The parameter {<slot/port> | all} indicates the desired switch port or all ports.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then the status summary is displayed for one or all ports within the common and internal spanning tree.

**Format**

```
show spanning-tree mst port summary <mstid> {<slot/  
port> | all}
```

**Mode**

Privileged EXEC and User EXEC

**MST Instance ID**

The MST instance associated with this port. Valid value: 0.

**Interface**

Valid slot and port number separated by forward slashes.

**STP Mode**

Current STP mode of this port in the specified spanning tree instance.

**Type**

Currently not used.

**Port Forwarding State**

The forwarding state of the port in the specified spanning tree instance

**Port Role**

The role of the specified port within the spanning tree.

### 5.1.6 show spanning-tree mst summary

This command displays settings and parameters for the specified multiple spanning tree instance. The following details are displayed.

**Format**

```
show spanning-tree mst summary
```

**Mode**

Privileged EXEC and User EXEC

**MST Instance ID**

Valid value: 0

**Associated FIDs**

List of forwarding database identifiers associated with this instance.

**Associated VLANs**

List of VLAN IDs associated with this instance.

### 5.1.7 show spanning-tree summary

This command displays spanning tree settings and parameters for the switch. The following details are displayed on execution of the command.

**Format**

```
show spanning-tree summary
```

**Mode**

Privileged EXEC and User EXEC

**Spanning Tree Adminmode**

Enabled or disabled.

**Spanning Tree Version**

Version of 802.1 currently supported (IEEE 802.1Q-2005, IEEE 802.1D-2004) based upon the Force Protocol Version parameter

**Configuration Name**

Configured name.

**Configuration Revision Level**

Configured value.

**Configuration Digest Key**

Calculated value.

**Configuration Format Selector**

Configured value.

**MST Instances**

List of all multiple spanning tree instances configured on the switch

### 5.1.8 show spanning-tree vlan

This command displays the association between a VLAN and a multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID (1-4042).

**Format**

```
show spanning-tree vlan <vlanid>
```

**Mode**

Privileged EXEC and User EXEC

**vlanid**

Enter a VLAN identifier (1 - 4042).

**VLAN Identifier**

The VLANs associated with the selected MST instance.

**Associated Instance**

Identifier for the associated multiple spanning tree instance or "CST" if associated with the common and internal spanning tree



### 5.1.9 spanning-tree

This command sets the spanning-tree operational mode to enabled.

**Default**

disabled

**Format**

spanning-tree

**Mode**

Global Config

**U no spanning-tree**

This command sets the spanning-tree operational mode to disabled.

While disabled, the spanning-tree configuration is retained and can be changed, but is not activated.

**Format**

no spanning-tree

**Mode**

Global Config

### 5.1.10 spanning-tree auto-edgeport

This command specifies that this port is an Edge Port within the common and internal spanning tree. This will allow this port to transition to Forwarding State without delay.

**Format**

```
spanning-tree auto-edgeport
```

**Mode**

```
Interface Config
```

**U** no spanning-tree auto-edgeport

This command specifies that this port is not an Edge Port within the common and internal spanning tree.

**Format**

```
no spanning-tree auto-edgeport
```

**Mode**

```
Interface Config
```

### 5.1.11 spanning-tree bpduguard

This command sets the BPDU (Bridge Protocol Data Units) Guard on the switch to enabled.

**Default**

disabled

**Format**

spanning-tree bpduguard

**Mode**

Global Config

**U no spanning-tree bpduguard**

This command sets the BPDU (Bridge Protocol Data Units) Guard to disabled.

**Format**

no spanning-tree bpduguard

**Mode**

Global Config

### 5.1.12 spanning-tree configuration name

This command sets the Configuration Identifier Name for use in identifying the configuration that this switch is currently using. The <name> is a string of at most 32 characters.

**Default**

The base MAC address displayed using hexadecimal notation as specified in IEEE 802 standard.

**Format**

```
spanning-tree configuration name <name>
```

**Mode**

```
Global Config
```

**U no spanning-tree configuration name**

This command resets the Configuration Identifier Name to its default.

**Format**

```
no spanning-tree configuration name
```

**Mode**

```
Global Config
```

### 5.1.13 spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using. The Configuration Identifier Revision Level is a number in the range of 0 to 65535.

**Default**

0

**Format**

```
spanning-tree configuration revision <0-65535>
```

**Mode**

Global Config

**U no spanning-tree configuration revision**

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using to the default value, i.e. 0.

**Format**

```
no spanning-tree configuration revision
```

**Mode**

Global Config

### 5.1.14 spanning-tree edgeport

This command specifies that this port is an Edge Port within the common and internal spanning tree. This will allow this port to transition to Forwarding State without delay.

**Format**

```
spanning-tree edgeport
```

**Mode**

```
Interface Config
```

**U** no spanning-tree edgeport

This command specifies that this port is not an Edge Port within the common and internal spanning tree.

**Format**

```
no spanning-tree edgeport
```

**Mode**

```
Interface Config
```

### 5.1.15 spanning-tree forceversion

This command sets the Force Protocol Version parameter to a new value. The Force Protocol Version can be one of the following:

- D 802.1d - ST BPDUs are transmitted (802.1Q-2005 functionality supported)
- D 802.1s - ST BPDUs are transmitted (802.1Q-2005 functionality supported)
- D 802.1w - RST BPDUs are transmitted (802.1Q-2005 functionality supported)

**Default**

802.1w

**Format**

```
spanning-tree forceversion  
                        <802.1d | 802.1s | 802.1w>
```

**Mode**

Global Config

**U no spanning-tree forceversion**

This command sets the Force Protocol Version parameter to the default value, i.e. 802.1w.

**Format**

```
no spanning-tree forceversion
```

**Mode**

Global Config

### 5.1.16 spanning-tree forward-time

This command sets the Bridge Forward Delay parameter to a new value for the common and internal spanning tree. The forward-time value is in seconds within a range of 4 to 30, with the value being greater than or equal to  $(\text{Bridge Max Age} / 2) + 1$ .

**Default**

15

**Format**

```
spanning-tree forward-time <4-30>
```

**Mode**

Global Config

**U no spanning-tree forward-time**

This command sets the Bridge Forward Delay parameter for the common and internal spanning tree to the default value, i.e. 15.

**Format**

```
no spanning-tree forward-time
```

**Mode**

Global Config



### 5.1.17 spanning-tree guard loop

This command enables loop guard and disables root guard guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard loop

**Mode**

Interface Config

**U no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

### 5.1.18 spanning-tree guard none

This command disables root guard and disables loop guard guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard none

**Mode**

Interface Config

**U no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

### 5.1.19 spanning-tree guard root

This command enables root guard and disables loop guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard root

**Mode**

Interface Config

**U no spanning-tree guard**

This command disables the guard for this port.

**Format**

no spanning-tree guard

**Mode**

Interface Config

## 5.1.20 spanning-tree hello-time

This command sets the Hello Time parameter to a new value for the common and internal spanning tree. The hellotime <value> is in whole seconds within a range of 1 to 2 with the value being less than or equal to "(Bridge Max Age / 2) - 1".

**Default**

2

**Format**

```
spanning-tree hello-time <1-2>
```

**Mode**

Interface Config

Global Config

**U no spanning-tree hello-time**

This command sets the Hello Time parameter for the common and internal spanning tree to the default value, i.e. 2.

**Format**

```
no spanning-tree hello-time
```

**Mode**

Interface Config

Global Config

### 5.1.21 spanning-tree hold-count

This command sets the bridge hold count parameter.

**Default**

disabled

**Format**

spanning-tree hold-count <1-40>

**Mode**

Global Config

**<1-40>**

Enter the bridge parameter for hold count as an integer in the range 1 - 40.

U no spanning-tree hold-count

This command sets bridge hold count to disabled.

**Format**

no spanning-tree hold-count

**Mode**

Global Config

## 5.1.22 spanning-tree max-age

This command sets the Bridge Max Age parameter to a new value for the common and internal spanning tree. The max-age value is in seconds within a range of 6 to 40, with the value being less than or equal to "2 times (Bridge Forward Delay - 1)".

**Default**

20

**Format**

spanning-tree max-age <6-40>

**Mode**

Global Config

**U no spanning-tree max-age**

This command sets the Bridge Max Age parameter for the common and internal spanning tree to the default value, i.e. 20.

**Format**

no spanning-tree max-age

**Mode**

Global Config

### 5.1.23 spanning-tree max-hops

This command sets the Bridge Max Hops parameter to a new value for the common and internal spanning tree. The max-hops value is an integer within a range of 1 to 127.

**Format**

```
spanning-tree max-hops <1-127>
```

**Mode**

```
Global Config
```

**U no spanning-tree max-hops**

This command sets the Bridge Max Hops parameter for the common and internal spanning tree to the default value, i.e. 20.

**Format**

```
no spanning-tree max-age
```

**Mode**

```
Global Config
```

## 5.1.24 spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree. If the <mstid> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0 (defined as the default CIST ID) is passed as the <mstid>, then the configurations are performed for the common and internal spanning tree instance.

This command accepts the value 0 for the mstid, meaning the common and internal spanning tree.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter. The pathcost can be specified as a number in the range of 1 to 200000000 or auto. If "auto" is specified, the pathcost value will be set based on Link Speed.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter. The port-priority value is a number in the range of 0 to 240 in increments of 16.

### Default

```
cost : auto; external-cost : auto;
port-priority : 128
```

### Format

```
spanning-tree mst <mstid>
    { {cost <1-200000000> | auto } |
      {external-cost <1-200000000> | auto } |
      port-priority <0-240> }
```

### Mode

```
Interface Config
```

### U no spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree to the respective default values. If the <mstid> parameter corresponds to an existing multiple spanning tree instance, then the configurations are done for that multiple spanning tree instance. If however 0



(defined as the default CIST ID) is passed as the <mstid>, then the configurations are performed for the common and internal spanning tree instance.

This command accepts the value 0 for the mstid, meaning the common and internal spanning tree.

If the 'cost' token is specified, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter, to the default value, i.e. a pathcost value based on the Link Speed.

If the 'port-priority' token is specified, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the <mstid> parameter, to the default value, i.e. 128.

**Format**

```
no spanning-tree mst <mstid> <cost | port-priority>
```

**Mode**

```
Interface Config
```

### 5.1.25 spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The priority value is a number within a range of 0 to 61440 in increments of 4096.

This command accepts the value 0 for the mstid.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command sets the Bridge Priority parameter to a new value for the common and internal spanning tree. The bridge priority value again is a number within a range of 0 to 61440. The twelve least significant bits will be masked according to the 802.1s specification. This will cause the priority to be rounded down to the next lower valid priority.

**Default**

32768

**Format**

```
spanning-tree mst priority <mstid> <0-61440>
```

**Mode**

Global Config

**U no spanning-tree mst priority**

This command sets the bridge priority for a specific multiple spanning tree instance to the default value, i.e. 32768. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance.

This command accepts the value 0 for the mstid.

If 0 (defined as the default CIST ID) is passed as the <mstid>, then this command sets the Bridge Priority parameter for the common and internal spanning tree to the default value, i.e. 32768.

**Format**

```
spanning-tree mst priority <mstid>
```

**Mode**

Global Config

### 5.1.26 spanning-tree mst vlan

This command adds an association between a multiple spanning tree instance and a VLAN. The VLAN will no longer be associated with the common and internal spanning tree. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID (1-4042). This command accepts the value 0 for the mstid.

**Format**

```
spanning-tree mst vlan <mstid> <vlanid>
```

**Mode**

```
Global Config
```

**U** no spanning-tree mst vlan

This command removes an association between a multiple spanning tree instance and a VLAN. The VLAN will again be associated with the common and internal spanning tree. The instance <mstid> is a number that corresponds to the desired existing multiple spanning tree instance. The <vlanid> corresponds to an existing VLAN ID. This command accepts the value 0 for the mstid.

**Format**

```
no spanning-tree mst vlan <mstid> <vlanid>
```

**Mode**

```
Global Config
```

### 5.1.27 spanning-tree mst instance

This command creates a MST instance.

**Format**

```
spanning-tree mst instance <1-4094>
```

**Mode**

Global Config

**<1-4094>**

Enter a multiple spanning tree instance identifier.

### U no spanning-tree mst instance

This command removes a MST instance.

**Format**

```
no spanning-tree mst instance <1-4094>
```

**Mode**

Global Config

**<1-4094>**

Enter a multiple spanning tree instance identifier.

### 5.1.28 spanning-tree port mode

This command sets the Administrative Switch Port State for this port to enabled.

**Default**

disabled

**Format**

spanning-tree port mode

**Mode**

Interface Config

**U no spanning-tree port mode**

This command sets the Administrative Switch Port State for this port to disabled.

**Format**

no spanning-tree port mode

**Mode**

Interface Config

## 5.1.29 spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to enabled.

**Default**

disabled

**Format**

```
spanning-tree port mode all
```

**Mode**

Global Config

### U no spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to disabled.

**Format**

```
no spanning-tree port mode all
```

**Mode**

Global Config

### 5.1.30 spanning-tree stp-mrp-mode

This command sets the spanning tree mrp (Media Redundancy Protocol) mode to enabled.

**Default**

disabled

**Format**

```
spanning-tree stp-mrp-mode
```

**Mode**

Global Config

**U no spanning-tree stp-mrp-mode**

This command sets the spanning tree mrp (Medium Redundancy Protocol) mode to disabled.

**Format**

```
no spanning-tree stp-mrp-mode
```

**Mode**

Global Config

### 5.1.31 spanning-tree tcnguard

This command enables tcn guard on an interface.

**Default**

disabled

**Format**

spanning-tree guard tcnguard

**Mode**

Interface Config

U no spanning-tree tcnguard

This command disables tcn guard for this port.

**Format**

no spanning-tree tcnguard

**Mode**

Interface Config



## 5.2 MRP

The concept of the MRP-Ring enables the construction of high-availability, ring-shaped network structures.

The two ends of a backbone in a line-type configuration can be closed to form a redundant ring - the MRP-Ring - by using the RM function (Redundancy Manager) of the Switch.

It is possible to mix the devices that support this function in any combination within the MRP ring.

If a line section becomes inoperable, the ring structure of up to 50 switches typically transforms back to a line-type configuration within 150 ms (maximum 500 ms).

### 5.2.1 show mrp

This command displays the settings and states of the MRP-Ring. The following details are displayed on execution of the command.

#### **Format**

```
show mrp [current-domain]
```

#### **Mode**

Privileged EXEC and User EXEC

#### **current-domain**

Specify the optional keyword "current-domain" to show the current MRP domain's settings. If you omit the keyword "current-domain", the show command will display the settings of all existing MRP domains. Note: currently, it is only possible to configure one MRP domain, so the keyword keyword "current-domain" can be omitted (it exists for future compatibility reasons).

## 5.2.2 show mrp current-domain

This command displays the settings and states of the MRP-Ring's current domain. The following details are displayed on execution of the command. If you omit the optional keywords (e. g., advanced-mode), all settings will be displayed.

### Format

```
show mrp current-domain [advanced-mode |  
  domain-id | info | manager-priority | mode |  
  name | recovery-delay | operation |  
  port [primary | secondary] | summary | vlan]
```

### Mode

Privileged EXEC and User EXEC

### advanced mode

Show the switch's advanced mode setting for the given MRP domain.

### domain-id

Show the given MRP domain's ID.

### info

Show status information for the given MRP domain.

Note: the information displayed depends on the switch's mode (Client or Manager) because only a subset of them are useful for each mode.

### manager-priority

Show the switch's manager priority for the given MRP domain.

### mode

Show the switch's mode for the given MRP domain.

### name

Show the given MRP domain's name.

### recovery-delay

Show the given MRP domain's recovery delay.

### operation

Show the switch's administrative setting for the given MRP domain (enabled or disabled).

### port

Show the ports for the given MRP domain

**port primary**

Show the primary port for the given MRP domain.

**port secondary**

Show the secondary port for the given MRP domain.

**summary**

Show a summary for the given MRP domain.

**vlan**

Show the VLAN ID for the given MRP domain.

### 5.2.3 mrp current-domain

Specify that you want to configure the current MRP domain's settings.

#### Default

none

#### Format

```
mrp current-domain {advanced-mode {disable|enable}  
| manager-priority <0-65535>  
| mode {client|manager} | name <domain-name>  
| recovery-delay {500ms|200ms}  
| operation {disable|enable}  
| port {primary|secondary} <slot/port>  
| vlan <0-4042>}
```

#### Mode

Global Config

#### advanced-mode

Enable or disable the switch's advanced mode for the given MRP domain.

#### manager-priority

Configure the given MRP domain's manager priority (0-65535).

#### mode

Configure the switch's MRP mode for the given domain (client or manager).

`client`: Switch is client for the given MRP domain.

`manager`: Switch is manager for the given MRP domain.

#### name

Set a name for the given MRP domain.

#### recovery-delay

Configure the MRP recovery delay for the given domain.

`500ms`: Recovery delay is 500 ms for the given MRP domain.

`200ms`: Recovery delay is 200 ms for the given MRP domain.

#### operation

Enable or disable the switch for the given MRP domain.

**port**

Specify the switch's ports for the given MRP domain (in slot/port notation).

`primary`: Specify the switch's primary port for the given MRP domain.

`secondary`: Specify the switch's secondary port for the given MRP domain.

**vlan**

Enter the VLAN for the given MRP domain (0 - 4042, default: 0).

## 5.2.4 mrp delete-domain

Delete current MRP domain.

**Format**

```
mrp delete-domain current-domain
```

**Mode**

```
Global Config
```

## 5.2.5 mrp new-domain

Create a new MRP domain. The configuration will consist of default parameters and its operation will be disabled.

### Default

n/a not set

### Format

```
mrp new-domain (<domain-id> | default-domain)
```

### Mode

Global Config

### domain-id

Enter a new MRP domain id. Format: 16 bytes in decimal notation, example: 1.2.3.4.5.6.7.8.9.10.11.12.13.14.15.16

The MRP domain id 0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0 is invalid.

### default-domain

Create a default MRP domain (ID: 255.255.255.255.255.255.255.255.255.255.255.255.255.255.255.255).

## 5.2.6 arc

Use this command to configure ARC (Automatic Ring Configuration). ARC supports MRP.

The ARC protocol is a simple protocol that checks a ring configuration and, if suitable, configures all clients of this ring automatically.

The check cycle includes an analysis of the ARC devices for an already active ring configuration and wrong ring configuration values. The ARC devices can detect loop situations and other ARC Managers in the ring. Errors are reported to the ARC Manager. With this information the ARC Manager can decide whether a configuration of the ring clients is possible or not.

### Format

```
arc { manager {enable | disable} |
      client {enable | disable | checkOnly} |
      check |
      configure}
```

### Mode

Global Config

### client

Configure the ARC client.

- **enable**: Enable the ARC client for configuring and checking.
- **disable**: Disable the ARC client for configuring and checking.
- **checkOnly**: The device can only be checked but not configured by ARC.

### manager

Configure the ARC manager.

- **enable**: Enable the ARC manager for configuring and checking.
- **disable**: Disable the ARC manager for configuring and checking.

### check

Check the topology. All important values will be taken from the current ring configuration on the devices.

### configure

Configure the topology. All important values will be taken from the current ring configuration of the ARC manager.

## 5.2.7 show arc

This command displays the current ARC configuration and the result of the last action.

**Format**

```
show arc
```

**Mode**

```
Global Config
```

**Client Settings:**

Display the Client Settings for the current ARC configuration.

**Admin Status**

Display if the ARC client is enabled or disabled.

**MAC address of the ARC Manager**

Display the MAC address of the ARC Client.

**IP address of the ARC Manager**

Display the IP address of the ARC Client.

**Port 1**

Display the number of Ring Port 1 for the client (slot/port).

**Port 2**

Display the number of Ring Port 2 for the client (slot/port).



**Manager Settings:**

Display the Manager Settings for the current ARC configuration.

**Admin Status**

Display the ARC manager is enabled or disabled

**Protocol**

Display the Protocol. Possible values: mrp, ....

**Port 1**

Display the number of Ring Port 1 for the manager (slot/port).

**Port 2**

Display the number of Ring Port 2 for the manager (slot/port).

**VLAN ID**

Display the VLAN ID. Possible values: 0 - ....

**Last Action Result**

Display the Result of the Last Action.

Possible values: Ring is open, Already Configured, Loop Source, Multiple RM, Configuration failed, Port not in full duplex mode, ARC not supported by the ring devices.

**Last Check result:**

Display the Result of the last check.

- Nr: Display the number of the check result.
- Mac Address: Display the concerned MAC address.
- IP Address: Display the concerned IP address.
- Type: Display the type of the result. Possible values: Error, Warning.

Possible check results (examples):

Error - Ring is open

Warning - Already Configured - HIPER Ring - Port1:  
1.1 - Port2: 1.2

Warning - Already Configured - MRP - Port1: 1.9 -  
Port2: 1.10 - VLAN ID: 0

Warning - Already Configured - Fast HIPER Ring -  
Port1: 1.3 - Port2: 1.4

Error - Loop Source - Hop count: 1 - Port1: 1.1 -  
Port2: 1.4 - Port3: 1.15

Error - Multiple RM - MRP

Error - Configuration failed - MRP

Warning - Port not in full duplex mode - Port1: 1.1  
Half - Port2: 1.2 Full

Warning - ARC not supported by the ring devices

## 5.3 HIPER-Ring

The concept of the HIPER-Ring enables the construction of high-availability, ring-shaped network structures. Within such a ring topology, network components supporting the HIPER-Ring are connected with each other via their ring ports. Exactly one redundancy manager assumes control of the ring. These commands are for configuring the Hirschmann High Performance Redundancy Ring.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

### 5.3.1 show hiper-ring

This command displays the settings and states of the HIPER-Ring. The following details are displayed on execution of the command.

**Format**

```
show hiper-ring
  {info | mode | port [primary | secondary] |
  redundancy-state | rm-state | recovery-delay}
```

**Mode**

Privileged EXEC and User EXEC

**info**

Display the information about the HIPER-Ring configuration (cabling).

**mode**

Display the HIPER-Ring mode settings.

**port**

Display the HIPER-Ring's primary and secondary port properties.

**port primary**

Display the HIPER Ring's primary port properties.

**port secondary**

Display the HIPER Ring's secondary port properties.

**redundancy-state**

Display the actual state of the HIPER-Ring redundancy.

**rm-state**

Display the state of the HIPER Ring redundancy manager.

**recovery-delay**

Display the value of the recovery delay.

### 5.3.2 hiper-ring

Configure the HIPER-Ring.

Press Enter for a list of valid commands and their recommended order.

**Format**

```
hiper-ring
```

**Mode**

```
Global Config
```

U no hiper-ring

Clear the HIPER Ring configuration (delete it).

**Format**

```
no hiper-ring
```

**Mode**

```
Global Config
```

### 5.3.3 hiper-ring mode

This command sets the HIPER-Ring mode. Possible values are:

- D `ring-manager` Set the switch's HIPER Ring mode to Ring Manager.
- D `rm` Abbreviation of Ring Manager.
- D `ring-switch` Set the switch's HIPER Ring mode to Ring Switch.
- D `rs` Abbreviation of Ring Switch.

**Default**

`none`

**Format**

`hiper-ring mode <{ring-manager|ring-switch|rm|rs}>`

**Mode**

Global Config

### 5.3.4 hiper-ring port primary

Enter the switch's primary HIPER Ring port.

**Default**

`n/a (not set)`

**Format**

`hiper-ring port primary <primary ring port>`

**Mode**

Global Config

**primary ring port**

Enter the switch's primary HIPER Ring port (`<slot/port>`).

### 5.3.5 hiper-ring port secondary

Enter the switch's secondary HIPER Ring port.

**Default**

n/a not set

**Format**

hiper-ring port secondary <secondary ring port>

**Mode**

Global Config

**secondary ring port**

Enter the switch's secondary HIPER Ring port (<slot/port>).

### 5.3.6 hiper-ring recovery-delay

Defines the maximum recovery delay of ring recovery in the HIPER Ring (500 or 300 ms).

**Default**

n/a not set

**Format**

hiper-ring recovery-delay (<500/300>)

**Mode**

Global Config





## 5.4 Fast-HIPER-Ring

The concept of the Fast-HIPER-Ring enables the construction of high-availability, ring-shaped network structures. Within such a ring topology, network components supporting the Fast-HIPER-Ring are connected with each other via their ring ports. Exactly one redundancy manager assumes control of the ring.

These commands are for configuring the Hirschmann Fast High Performance Redundancy Ring.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

### 5.4.1 show fast-hiper-ring (MACH 1000, RSR20/RSR30)

This command displays the settings and states of the HIPER-Ring. The following details are displayed on execution of the command.

**Format**

```
show fast-hiper-ring
```

**Mode**

Privileged EXEC and User EXEC

**Ring ID**

Display the Ring ID.

**Mode of Switch (administrative setting)**

Display the HIPER-Ring mode administrative settings.

**Mode of Switch (real operating state)**

Display the HIPER-Ring operation mode.

**Ring Name**

Display the Fast-HIPER-Ring's name.

**Number of nodes in the ring**

Display the number of nodes in the ring.

**Port Number, Primary**

Display the HIPER-Ring's primary port number and its properties.

**Port Number, Secondary**

Display the HIPER-Ring's secondary port number and its properties.

**Operation**

Display the admin state of the HIPER-Ring configuration.

**General Operating States**

Display general information concerning the fast-hiper-ring state.

## 5.4.2 show fast-hiper-ring current-id (MACH 1000, RSR20/RSR30)

Specify that you want to show the current Fast HIPER-Ring ID's settings.

### Format

```
show fast-hiper-ring current-id
  {id | info | mode | operation | port |
  port [primary |secondary] | summary |
  ring-name | nodes | vlan}
```

### Mode

Privileged EXEC and User EXEC

### id

Display the given Fast HIPER-Ring's ID.

### info

Display status information for the given Fast HIPER-Ring ID.

### mode

Display the switch's mode for the given Fast HIPER-Ring ID.

### operation

Display the switch's operative setting for the given Fast HIPER-Ring ID.

Note: in case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

### port

Display the ports for the given Fast HIPER-Ring ID.

### port primary

Display the primary port for the given Fast HIPER-Ring ID.

### port secondary

Display the secondary port for the given Fast HIPER-Ring ID.

### summary

Display a summary for the given Fast HIPER-Ring ID.

### ring-name

Display the ring name for the given Fast HIPER-Ring ID.

**nodes**

Display the number of nodes in the ring for the given Fast HIPER-Ring ID.

**vlan**

Display the VLAN ID for the given Fast HIPER-Ring ID.

### 5.4.3 fast-hiper-ring

Configure the Fast-HIPER-Ring.

**Format**

```
fast-hiper-ring {current-id  
  {mode {ring-manager|ring-switch|rm|rs} |  
  operation {disable|enable} |  
  port {primary|secondary} <slot/port> |  
  ring-name <ring-name> |  
  nodes <1-n> |  
  vlan <0-4042>} |  
delete-id current-id |  
new-id {<id>|default-id}}
```

**Mode**

Global Config

**current-id**

Specify that you want to configure the current Fast-HIPER-Ring ID's settings.

**mode**

Configure the switch's Fast HIPER-Ring mode for the given ID (ring-manager or ring-switch).

rm: Abbreviation for 'ring-manager'.

rs: Abbreviation for 'ring-switch'.

**mode ring-manager**

Switch is ring-manager for the given Fast HIPER-Ring ID.

**mode ring-switch**

Switch is ring-switch for the given Fast HIPER-Ring ID.

**mode rm**

Abbreviation for 'ring-manager'.

**mode rs**

Abbreviation for 'ring-switch'.

**operation**

Enable or disable the switch for the given Fast-HIPER-Ring ID.

**port**

Specify the switch's ports for the given Fast-HIPER-Ring ID.

**ring-name**

Set a ring name for the given Fast HIPER-Ring ID.

**nodes**

Specify the number of nodes in the ring for the given Fast HIPER-Ring ID.

**vlan**

Specify the VLAN for the given Fast HIPER-Ring ID.

**delete-id**

Delete the given Fast HIPER-Ring ID.

**new-id**

Create a new Fast HIPER-Ring ID. The configuration will consist of default parameters and its operation will be disabled.

**<id>**

Enter a new Fast HIPER-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

**default-id**

Create a default Fast HIPER-Ring ID (1).



## 5.5 Redundant Coupling

The control intelligence built into the switch allows the redundant coupling of HiPER-Rings and network segments. Two network segments can be connected via two separate paths with one of the following switches:

- D RS2-16M
- D RS20/RS30/RS40
- D RSR20/RSR30
- D MICE (Rel. 3.0 or higher)
- D MS20/MS30
- D PowerMICE
- D MACH 1000
- D MACH 3000 (Rel. 3.3 or higher)
- D MACH 4000

The switch in the redundant line and the switch in the main line inform each other about their operating states by using control frames via the ethernet or via the control line.

**Note:** For redundancy security reasons, the Rapid Spanning Tree protocol and redundant network/ring coupling may not be enabled simultaneously.

**Note:** The network that connects the master and the slave must always be a HiPER-Ring. The coupling switch in single mode also must have a HiPER-Ring Configured.

Further information concerning this function you will find in the User Manual "Redundancy Configuration".

These commands allow you to configure the redundant coupling of network segments.

### 5.5.1 show ring-coupling

This command displays the settings and states of the network coupling / ring coupling.

To set up a new Ring Coupling configuration when no configuration is currently present (e. g., after a clear command), always set the local port first. Please refer to: ring-coupling port local <slot/port>.

The following details are displayed on execution of the command.

#### Format

```
show ring-coupling <config | info |  
net-coupling | operation | partner-ip |  
port [ all | control | local | partner] |  
redundancy-mode>
```

#### Mode

Privileged EXEC and User EXEC

#### config

Display the Ring Coupling's configuration

- single
- dual-master-inband
- dual-master-outband
- dual-slave-inband
- dual-slave-outband.

#### info

Display information about the Ring Coupling's states:

- configuration failure,
- Extended diagnosis,
- redundancy guaranteed.

#### net-coupling

Display the Ring Coupling's ring/network coupling setting (network/ring-only).

#### operation

Display the Ring Coupling's operation setting

- on
- off



**partner IP**

Display the switch's Ring Coupling partner IP address (only valid for remote configurations).

**port**

Display the switch's Ring Coupling ports

- all
- local
- partner (only takes effect in dual configurations)
- control (only takes effect in outband configurations).

**redundancy-mode**

Display the Ring Coupling's redundancy mode

- normal
- extended.

**Ring/Network Coupling Mode**

Display the Ring/Network Coupling mode

- ring-only if you wish to couple a HIPER-Ring.
- network if you wish to couple a line-type configuration.

## 5.5.2 ring-coupling

Configure the redundant coupling of HIPER-Rings / network segments. This command, if called without arguments, lists the available subcommands, their recommended order and tips how to set up a new configuration.

**Format**

```
ring-coupling
```

**Mode**

```
Global Config
```

**U** no ring-coupling

Clear the ring-coupling configuration (delete it).

**Format**

```
no ring-coupling
```

**Mode**

```
Global Config
```

### 5.5.3 ring-coupling config

This command sets the Ring Coupling configuration.

Possible values are:

- D `single` Configure the Ring Coupling's basic setting to single (both coupling ports are local to the switch, switch performs master and slave functions).
- D `dual-master-inband` Configure the Ring Coupling's basic setting to dual-master-inband (2nd coupling port is on a remote switch, local switch is master, communication over network).
- D `dual-master-outband` Configure the Ring Coupling's basic setting to dual-master-outband (2nd coupling port is on a remote switch, local switch is master, communication over dedicated control port).
- D `dual-slave-inband` Configure the Ring Coupling's basic setting to dual-slave-inband (2nd coupling port is on a remote switch, local switch is slave, communication over network).
- D `dual-slave-outband` Configure the Ring Coupling's basic setting to dual-slave-outband (2nd coupling port is on a remote switch, local switch is slave, communication over dedicated control port).
- D `dmi` Abbreviation for `dual-master-inband`.
- D `dmo` Abbreviation for `dual-master-outband`.
- D `dsi` Abbreviation for `dual-slave-inband`.
- D `dso` Abbreviation for `dual-slave-outband`.

#### Default

`none`

#### Format

```
ring-coupling config <{ single |
dual-master-inband | dual-master-outband |
dual-slave-inband | dual-slave-outband |
dmi | dmo | dsi | dso }>
```

#### Mode

`Global Config`

### 5.5.4 ring-coupling net-coupling

Coupling mode refers to the type of coupled network.

Possible values are:

- D `network` ,if you wish to couple a line-type configuration.
- D `ring-only` ,if you wish to couple a HIPER-Ring.

**Default**

`none`

**Format**

`ring-coupling net-coupling <{network|ring-only}>`

**Mode**

Global Config

### 5.5.5 ring-coupling operation

Configure the Ring Coupling's operation setting. Possible values are:

- D `on` Enable the current Ring Coupling configuration.
- D `off` Disable the current Ring Coupling configuration.

**Default**

`off`

**Format**

`ring-coupling operation <{off|on}>`

**Mode**

Global Config

### 5.5.6 ring-coupling port

Configure the Ring Coupling's ports. Possible values are:

- D `control` Enter the Ring Coupling's control coupling port in outband configurations.
- D `local` Enter the Ring Coupling's local coupling port.
- D `partner` Enter the Ring Coupling's partner coupling port in single mode configuration.

#### Default

`none`

#### Format

```
ring-coupling port <{control|local|partner}> <slot/
port>
```

#### Mode

Global Config

### 5.5.7 ring-coupling redundancy-mode

Configure the Ring Coupling's redundancy mode. Possible values are:

- D `extended` Slave responds to a failure in the remote ring or network.
- D `normal` Slave does not respond to a failure in the remote ring or network.

#### Default

`extended`

#### Format

```
ring-coupling redundancy-mode <{extended|normal}>
```

#### Mode

Global Config



## 5.6 Port Security

With the Port Security function you can specify for each port from which terminal devices data can be received and sent to other ports. This function helps to protect the network from unauthorized access.

### 5.6.1 show port-sec mode

Display the MAC/IP Based Port Security global setting for all ports.

**Format**

```
show port-sec mode
```

**Mode**

Privileged EXEC and User EXEC

### 5.6.2 show port-sec port

Display the MAC/IP Based Port Security port-related settings (allowed MAC address, current MAC address, allowed IP address, current action and current port state).

**Format**

```
show port-sec port <{all|<slot/port>}>
```

**Mode**

Privileged EXEC and User EXEC

### 5.6.3 port-sec mode

Configure the global MAC/IP Based Port Security mode:

- D `ip-based` Port security is based on a given, allowed source IP address.
- D `mac-based` Port security is based on a given, allowed source MAC address.

#### Format

```
port-sec mode <{ip-based|mac-based}>
```

#### Mode

Global Config

### 5.6.4 port-sec action

Configure the action to be taken if port security is violated at this port.

- D `none` No action is taken if port security is violated at this port.
- D `port-disable` The port is disabled for traffic if port security is violated.
- D `trap-only` A trap is sent if port security is violated at this port (this port remains open for traffic).

Configure the allowed IP source address for this port.

Configure the allowed MAC source address for this port.

#### Format

```
port-sec {action {none|port-disable|trap-only}
          |allowed-ip <IP1> [IP2 [IP3 [IP4 [IP5
                        [IP6 [IP7 [IP8 [IP9 [IP10]]]]]]]]]
          |allowed-mac <MAC1> [MAC2 [MAC3 [MAC4
                        [MAC5 [MAC6 [MAC7 [MAC8 [MAC9
                        [MAC10]]]]]]]] ] }
```

#### Mode

Interface Config



U no port-sec

No action is taken if port security is violated at this port.

**Format**

no port-sec

**Mode**

Interface Config

### 5.6.5 port-sec allowed-ip

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 10).

**Format**

port-sec allowed-ip <IP Address 1> <IP Address 2>  
... <IP Address 10>

**Mode**

Interface Config

### 5.6.6 port-sec allowed-ip add

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 50).

**Format**

port-sec allowed-ip add <IP Address 1>  
<IP Address 2> ... <IP Address 50>

**Mode**

Interface Config

### 5.6.7 port-sec allowed-ip remove

Enter the allowed IP source address for this port, format: nnn.nnn.nnn.nnn (nnn: decimal number 0..255) (up to 50).

**Format**

```
port-sec allowed-ip remove <IP Address 1>
                               <IP Address 2> ... <IP Address 50>
```

**Mode**

Interface Config

### 5.6.8 port-sec allowed-mac

Enter the allowed MAC source address for this port, format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or format: nn:nn:nn:nn:nn:nn/m (n: hexadecimal digit) (m: decimal digit (1..48)) (up to 10).

**Format**

```
port-sec allowed-mac <MAC Address 1>
                    <MAC Address 2> ... <MAC Address 10>
```

**Mode**

Interface Config

### 5.6.9 port-sec allowed-mac add

Enter the allowed MAC source address for this port,  
format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or  
format: nn:nn:nn:nn:nn:nn/m  
n: hexadecimal digit, m: decimal digit (1..48)  
(up to 50).

**Format**

```
port-sec allowed-mac add <MAC Address 1>  
                        <MAC Address 2> ... <MAC Address 50>
```

**Mode**

```
Interface Config
```

### 5.6.10 port-sec allowed-mac remove

Enter the allowed MAC source address for this port,  
format: nn:nn:nn:nn:nn:nn (n: hexadecimal digit) or  
format: nn:nn:nn:nn:nn:nn/m  
n: hexadecimal digit, m: decimal digit (1..48)  
(up to 50).

**Format**

```
port-sec allowed-mac remove <MAC Address 1>  
                            <MAC Address 2> ... <MAC Address 50>
```

**Mode**

```
Interface Config
```

## 5.6.11 clear port-sec

Clear the MAC/IP Based Port Security by setting each port's security action (applied when port security is violated) to None. Additionally, the global mode is set to MAC Based.

Note: This does not clear the 802.1X Port Security.

**Format**

```
clear port-sec
```

**Mode**

```
User EXEC and Global Config
```

## 5.7 DHCP Relay Commands

These commands configure the DHCP Relay parameters. The commands are divided by functionality into these different groups:

- D Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- D Show commands are used to display switch settings, statistics and other information.
- D Commands that start with the keyword 'no' (so-called 'no commands') are used to clear some or all of the settings to factory defaults.

### 5.7.1 show dhcp-relay

Display the settings of the BOOTP/DHCP relay.

#### Format

```
show dhcp-relay [opt82 | port {<slot/port>|all} |  
server-address]
```

#### Mode

Privileged EXEC and User EXEC

## 5.7.2 dhcp-relay

Set different options for BOOTP/DHCP relay and option 82 inclusion.

### Format

```
dhcp-relay
  {opt82
    {operation {disable|enable}|
      man-id <Manual Remote ID>|
      remote-id-type {client-id|ip|mac|other}}|
    server-address <Server-ID (1..4)> <Server IP
                                     Address>}
```

### Mode

Global Config

#### **dhcp-relay opt82 operation {disable|enable}**

Enable/Disable option 82 globally. Default: enable.

#### **dhcp-relay opt82 man-id <Manual Remote ID>**

Configure the DHCP Relay's Option 82 Manual Value for the Remote ID Type (only effective, if Remote ID is set to "other"). Default: no ID.

#### **dhcp-relay opt82 remote-id-type {client-id|ip|mac|other}**

Configure the DHCP Relay's Option 82 Remote ID Type.  
Default: mac

#### **dhcp-relay server-address <Server ID (1..4)> <Server IP Address>**

Set the server IP address for one of the 4 possible server IDs.  
Default: 0.0.0.0

#### **U no dhcp-relay**

Clear the DHCP Relay configuration (set all server addresses to 0.0.0.0).

### Format

```
no dhcp-relay
```

### Mode

Global Config

### 5.7.3 dhcp-relay

Set different port specific options for option 82 inclusion.

#### Format

```
dhcp-relay {operation {disable|enable} |  
hirschmann-device {disable|enable} |  
hirschmann-agent {disable|enable}}
```

#### Mode

Interface Config

#### **dhcp-relay operation {disable|enable}**

Enable or disable the DHCP Relay's Option 82 on this port. Default: enable.

#### **dhcp-relay hirschmann-device {disable|enable}**

Enable this parameter if a Hirschmann DHCP client is connected to this port.

- It disables the forwarding of DHCP multicast requests that are received on this port.
- It will send its own DHCP multicast requests to be relayed by the DHCP relay; this will reduce the load in your network.

Disable this parameter if a Non-Hirschmann DHCP client is connected to this port (these devices send normal broadcast DHCP requests; this enables the relaying of DHCP broadcast requests that are received on this port).

#### **dhcp-relay hirschmann-agent {disable|enable}**

Enable or disable the forwarding of DHCP requests that are received on this port. Enable this parameter if a Hirschmann DHCP client is connected to this port. Default: disable.

Disable this parameter if a Non-Hirschmann DHCP client is connected to this port (these devices send normal broadcast DHCP requests; this enables the relaying of DHCP broadcast requests that are received on this port)

Enable this parameter if a Hirschmann DHCP client is connected to this port (it will send its own DHCP multicast requests to be relayed by the DHCP relay; this will reduce the load in your network).





## 5.8 DHCP Server Commands

These commands configure the DHCP server parameters. The commands are divided by functionality into these different groups:

- D Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- D Show commands are used to display switch settings, statistics and other information.
- D Commands that start with the keyword 'no' (so-called 'no commands') clear some or all of the settings to factory defaults.

### 5.8.1 DHCP server configuration example

The example shown below has the following task: The IP address is only to be served, if a request is coming via interface 1/1 with specified Mac address.

```
<Hirschmann PowerMICE> >enable
<Hirschmann PowerMICE> #configure
<Hirschmann PowerMICE> <Config>#dhcp-server operation
enable
<Hirschmann PowerMICE> <Config>#dhcp-server pool add 1
static 192.168.0.10
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 mode interface 1/1
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 mode mac 00:80:63:12:34:56
<Hirschmann PowerMICE> <Config>#dhcp-server pool modify
1 option gateway 192.168.0.1
<Hirschmann PowerMICE> <Config>#dhcp-server pool enable
1
<Hirschmann PowerMICE> <Config>#interface 1/1
<Hirschmann PowerMICE> <interface 1/1>#dhcp-server oper-
ation enable
```

This configuration leads to the following result:

```
<Hirschmann PowerMICE> #show dhcp-server pool 1

ID..... 1
Status..... Enabled
Start Address..... 192.168.0.10
End Address..... 192.168.0.10
Leasetime..... 86400
Hirschmann Device..... Disabled
Mode..... Interface(1/1)
MAC..... 00:80:63:12:34:56
Options:
Configpath.....
Gateway..... 192.168.0.1
Subnet Mask..... 255.255.255.0
WINS..... 0.0.0.0
DNS..... 0.0.0.0
Hostname.....
```

### 5.8.2 show dhcp-server

Display DHCP Server global and interface information.

**Format**

```
show dhcp-server
```

**Mode**

Privileged EXEC and User EXEC

### 5.8.3 show dhcp-server operation

Display DHCP Server global information.

**Format**

```
show dhcp-server operation
```

**Mode**

Privileged EXEC and User EXEC

### 5.8.4 show dhcp-server port

Display the DCHP port-related settings for all ports or specific port only.

**Format**

```
show dhcp-server port {all | <slot/port>}
```

**Mode**

Privileged EXEC and User EXEC

**show dhcp-server port all**

Display the DCHP port-related settings for all ports.

**show dhcp-server port <slot/port>**

Display the DCHP port-related settings for the specified port only.

### 5.8.5 show dhcp-server pool

Display DHCP server pool information for all pool or detailed information for a specific pool.

**Format**

```
show dhcp-server pool {all | <id>}
```

**Mode**

Privileged EXEC and User EXEC

**show dhcp-server pool all**

Display the DCHP server pool information for all IDs.

**show dhcp-server pool <id>**

Display the DCHP server pool information for the specified ID only.

### 5.8.6 dhcp-server operation

Enable or disable the DHCP server globally. Default: disable.

**Format**

```
dhcp-server operation {disable|enable}
```

**Mode**

Interface Config

**dhcp-server operation disable**

Disable the DHCP server. This is the default.

**dhcp-server operation enable**

Enable the DHCP server.

### 5.8.7 dhcp-server pool add <id>

Add a pool with a single IP address (static) or with an IP range (dynamic)

**Format**

```
dhcp-server pool {add <id> {static <ipaddr>  
|dynamic <start ipaddr> <end ipaddr>}}
```

**Mode**

Global Config

**dhcp-server pool add <id> {static <ipaddr>}**

Add a pool with a single IP address (static).

**dhcp-server pool add <id> {dynamic <start ipaddr> <end ipaddr>}**

Add a pool with an IP range (dynamic).

### 5.8.8 dhcp-server pool modify <id> mode

Add or delete one or more pool modes.

#### Format

```
dhcp-server pool modify <id> mode
    {interface {all | <slot/port>} 1)
    |mac {none | <macaddr>} 1)
    |clientid {none | <clientid>} 1)
    |relay {none | <ipaddr>}
    |remoteid {none | <remoteid>} 1)
    |circuitid {none | <circuitid >} 1)
    |vlan {none | <vlan id >} }
```

#### Mode

Global Config

**dhcp-server pool modify <id> mode interface all 1)**

Set pool to all interfaces.

**dhcp-server pool modify <id> mode interface <slot/port> 1)**

Set pool to a specific interface.

**dhcp-server pool modify <id> mode mac none 1)**

Use none to remove the mode.

**dhcp-server pool modify <id> mode mac <macaddr> 1)**

Enter macaddr in xx:xx:xx:xx:xx:xx format.

**dhcp-server pool modify <id> mode clientid none 1)**

Use none to remove the mode.

**dhcp-server pool modify <id> mode clientid <clientid> 1)**

Enter clientid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode relay none**

Use none to remove the mode.

**dhcp-server pool modify <id> mode relay <ipaddr>**

Enter IP address of the relay.

**dhcp-server pool modify <id> mode remoteid none** <sup>1)</sup>

Use none to remove the mode.

**dhcp-server pool modify <id> mode remoteid <remoteid>** <sup>1)</sup>

Enter remoteid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode circuitid none** <sup>1)</sup>

Use none to remove the mode.

**dhcp-server pool modify <id> mode circuitid <circuitid>** <sup>1)</sup>

Enter circuitid in xx:xx:....:xx format.

**dhcp-server pool modify <id> mode vlan <vlan id>** <sup>1)</sup>

Enter valid VLAN ID.

<sup>1)</sup> Available for pools with single IP address only.

### 5.8.9 dhcp-server pool modify <id> option

Modify pool options.

#### Format

```
dhcp-server pool modify <id> option
                               {configpath <url>
                               |gateway <ipaddr>
                               |netmask <netmask>
                               |wins <ipaddr>
                               |dns <ipaddr>
                               |hostname <name>}
```

#### Mode

Global Config

#### **dhcp-server pool modify <id> option configpath <url>**

Enter the configpath URL in 'tftp://<servername-or-ip>/<file>' format.

#### **dhcp-server pool modify <id> option gateway <ipaddr>**

Default gateway. Enter the gateway IP address.

#### **dhcp-server pool modify <id> option netmask <netmask>**

Option netmask. Enter the netmask.

#### **dhcp-server pool modify <id> option wins <ipaddr>**

Option wins. Enter WINS IP address.

#### **dhcp-server pool modify <id> option dns <ipaddr>**

Option DNS. Enter the DNS IP address.

#### **dhcp-server pool modify <id> option hostname <name>**

Option hostname. Enter the host name.



### 5.8.10 dhcp-server pool modify leasetime

Modify pool leasetime. Enter the leasetime in seconds.

**Format**

```
dhcp-server pool modify leasetime <seconds>
```

**Mode**

```
Global Config
```

### 5.8.11 dhcp-server pool modify <id> hirschmann-device

Set this pool to Hirschmann devices only or to all devices.

**Format**

```
dhcp-server pool modify <id> hirschmann-device  
{enable|disable}
```

**Mode**

```
Global Config
```

**dhcp-server pool modify <id> hirschmann-device disable**

Use pool for all devices.

**dhcp-server pool modify <id> hirschmann-device enable**

Use pool for Hirschmann devices only.

### 5.8.12 dhcp-server pool enable

Enable a specific pool.

**Format**

```
dhcp-server pool enable <id>
```

**Mode**

Global Config

### 5.8.13 dhcp-server pool disable

Disable a specific pool.

**Format**

```
dhcp-server pool disable <id>
```

**Mode**

Global Config

### 5.8.14 dhcp-server pool delete

Delete a specific pool.

**Format**

```
dhcp-server pool delete <id>
```

**Mode**

Global Config

## 5.9 Sub-Ring Commands

These commands configure the sub-ring parameters.

The commands are divided by functionality into these different groups:

- D Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- D Show commands are used to display switch settings, statistics and other information.

### 5.9.1 show sub-ring

Display sub-ring information for all sub-rings or detailed information for a specific sub-ring.

#### Format

```
show sub-ring {all-ids | <id>}
               {id | info | mode | operation | protocol | port |
               summary | ring-name | vlan | mrp-domainID |
               partner-mac}
```

#### Mode

Privileged EXEC and User EXEC

#### show sub-ring

Display the sub-ring information.

#### show sub-ring all-ids

Display the sub-ring information for all existing Sub-Ring IDs.

#### show sub-ring <id>

Display the sub-ring information for the specified ID.

#### id

Display the given Sub-Ring's ID.

**info**

Display status information for the given Sub-Ring ID.

**mode**

Display the switch's mode for the given Sub-Ring ID.

**operation**

Display the switch's operative setting for the given Sub-Ring ID.

Note: in case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

**protocol**

Display the switch's protocol setting for the given Sub-Ring ID.

Note: in case of configuration problems, this value may differ from the administrative setting (may become 'Disabled').

**port**

Display the ports for the given Sub-Ring ID.

**summary**

Display a summary for the given Sub-Ring ID.

**ring-name**

Display ring name for the given Sub-Ring ID.

**vlan**

Display the VLAN ID for the given Sub-Ring ID.

**mrp-domainID**

Display the MRP domain ID for the given Sub-Ring ID.

**partner-mac**

Display the partner MAC for the given Sub-Ring ID.

## 5.9.2 sub-ring <id> mode

Configure the switch's Sub-Ring mode for the given ID (manager or redundant-manager).

### Format

```
sub-ring <id> mode {manager |  
                    redundant-manager |  
                    single-manager}
```

### Mode

Global Config

### <id>

Specify the Sub-Ring ID whose settings you want to configure.

### manager

Switch is manager for the given Sub-Ring ID.

### redundant-manager

Switch is redundant-manager for the given Sub-Ring ID.

### single-manager

Switch is single-manager for the given Sub-Ring ID.

### 5.9.3 sub-ring <id> operation

Enable or disable the switch for the given Sub-Ring ID.

**Format**

```
sub-ring <id> operation {enable|disable}
```

**Mode**

Global Config

**<id>**

Specify the Sub-Ring ID whose settings you want to configure.

**enable**

Enable the switch for the given Sub-Ring ID.

**disable**

Disable the switch for the given Sub-Ring ID.

### 5.9.4 sub-ring <id> protocol

Set MRP or FHR as sub-ring protocol for the given Sub-Ring ID.

**Format**

```
sub-ring <id> protocol standard_mrp
```

**Mode**

Global Config

**<id>**

Specify the Sub-Ring ID whose settings you want to configure.

**standard\_mrp**

Set MRP as sub-ring protocol for the given Sub-Ring ID.

### 5.9.5 sub-ring <id> port

Specify the switch's ports for the given Sub-Ring ID.

**Format**

```
sub-ring <id> port <slot/port>
```

**Mode**

Global Config

**<id>**

Specify the Sub-Ring ID whose settings you want to configure.

**<slot/port>**

Specify the port (in slot/port) notation.

### 5.9.6 sub-ring <id> ring-name

Set a ring name for the given Sub-Ring ID.

**Format**

```
sub-ring <id> ring-name <ring-name>
```

**Mode**

Global Config

**<id>**

Specify the Sub-Ring ID whose settings you want to configure.

**<ring-name>**

Enter a name for the given Sub-Ring ID. The name may be up to 254 characters long and contain only printable characters. If you do not give a name, the current name will be set to an empty string ("").

### 5.9.7 sub-ring <id> vlan

Specify the VLAN for the given Sub-Ring ID.

**Format**

```
sub-ring <id> vlan <0-4042>
```

**Mode**

Global Config

**<id>**

Specify the Sub-Ring ID whose settings you want to configure.

**<0-4042>**

Enter the VLAN for the given Sub-Ring ID  
(min.: 0, max.: 4042, default: 0).



### 5.9.8 sub-ring <id> mrp-domainID

Set an MRP domain ID for the given Sub-Ring ID.

#### Format

```
sub-ring <id> mrp-domainID {<id> |  
                                default-domainID}
```

#### Mode

Global Config

#### <id>

sub-ring <id>: Specify the Sub-Ring ID whose settings you want to configure.

#### <id>

Enter an MRP domainID for the given Sub-Ring ID.  
The ID has to be 16 bytes long and contain only printable characters.

#### default-domainID

Enter the default MRP domainID for the given Sub-Ring ID.  
The MRP domainID will be set to 255.255.255.255.255.255  
255.255.255.255.255.255.255.255

### 5.9.9 sub-ring delete-ring

Delete all existing Sub-Rings IDs or a specific Sub-Ring ID.

**Format**

```
sub-ring delete-ring {all-ids | <id>}
```

**Mode**

Global Config

**all-ids**

Delete all existing Sub-Ring IDs.

**<id>**

Delete the given Sub-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

### 5.9.10 sub-ring new-ring

Create a new Sub-Ring ID. The configuration will consist of default parameters and its operation will be disabled.

**Format**

```
sub-ring new-ring <id>
```

**Mode**

Global Config

**<id>**

Enter a new Sub-Ring ID. Format: a number in the range 1-2147483647 ( $2^{31} - 1$ ). An ID of 0 is invalid.

## 6 CLI Commands: Security

This chapter provides a detailed explanation of the Security commands. The following Security CLI commands are available in the software Switching Package. Use the security commands to configure security settings for login users and port users.

The commands are divided into these different groups:

- D Show commands are used to display device settings, statistics and other information.
- D Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.



## 6.1 Security Commands

### 6.1.1 authentication login

This command creates an authentication login list. The `<listname>` is up to 15 alphanumeric characters and is not case sensitive. Up to 10 authentication login lists can be configured on the switch. When a list is created, the authentication method “local” is set as the first method.

When the optional parameters “Option1”, “Option2” and/or “Option3” are used, an ordered list of methods are set in the authentication login list. If the authentication login list does not exist, a new authentication login list is first created and then the authentication methods are set in the authentication login list. The maximum number of authentication login methods is three. The possible method values are `local`, `radius` and `reject`.

The value of `local` indicates that the user’s locally stored ID and password are used for authentication. The value of `radius` indicates that the user’s ID and password will be authenticated using the RADIUS server. The value of `reject` indicates the user is never authenticated.

To authenticate a user, the authentication methods in the user’s login will be attempted in order until an authentication attempt succeeds or fails.

**Note:** The default login list included with the default configuration can not be changed.

**Note:** When assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable.

#### Format

```
authentication login <listname> [method1 [method2  
[method3]]]
```

#### Mode

```
Global Config
```

**U** no authentication login

This command deletes the specified authentication login list.

You will be unable to delete if any of the following conditions are true:

- D The login list name is invalid or does not match an existing authentication login list
- D The specified authentication login list is assigned to any user or to the non configured user for any component
- D The login list is the default login list included with the default configuration and was not created using 'authentication login'.  
The default login list cannot be deleted.

**Format**

```
no authentication login <listname>
```

**Mode**

```
Global Config
```

### 6.1.2 authorization network radius

Use this command to enable the switch to accept VLAN assignment by the RADIUS server.

**Format**

```
authorization network radius
```

**Mode**

```
Privileged EXEC
```

U no authorization network radius

Use this command to disable the switch to accept VLAN assignment by the RADIUS server.

**Format**

```
no authorization network radius
```

**Mode**

```
Global Config
```

### 6.1.3 clear dot1x statistics

This command resets the 802.1X statistics for the specified port or for all ports.

**Format**

```
clear dot1x statistics {<slot/port> | all}
```

**Mode**

```
Privileged EXEC
```

### 6.1.4 clear radius statistics

This command is used to clear all RADIUS statistics.

**Format**

```
clear radius statistics
```

**Mode**

```
Privileged EXEC
```

### 6.1.5 dot1x defaultlogin

This command assigns the authentication login list to use for non-configured users for 802.1X port security. This setting is over-ridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

**Format**

```
dot1x defaultlogin <listname>
```

**Mode**

```
Global Config
```



### 6.1.6 dot1x dynamic-vlan enable

Use this command to enable the switch to create VLANs dynamically when a RADIUS-assigned VLAN does not exist in the switch.

**Default**

disabled

**Format**

dot1x dynamic-vlan enable

**Mode**

Global Config

#### U no dot1x dynamic-vlan enable

Use this command to disable the switch to create VLANs dynamically when a RADIUS-assigned VLAN does not exist in the switch.

**Default**

disabled

**Format**

no dot1x dynamic-vlan enable

**Mode**

Global Config

### 6.1.7 dot1x guest-vlan

This command configures VLAN as guest vlan on an interface. The command specifies an active VLAN as an IEEE 802.1x guest VLAN. The range is 1 to the maximum VLAN ID supported by the platform.

**Format**

```
dot1x guest-vlan <vlan-id>
```

**Mode**

```
Interface Config
```

**<vlan-id>**

Enter an existing VLAN ID.

#### U no dot1x guest-vlan

This command is used to disable Guest VLAN for the port.

**Format**

```
no dot1x guest-vlan
```

**Mode**

```
Global Config
```

### 6.1.8 dot1x initialize

This command begins the initialization sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

**Format**

```
dot1x initialize <slot/port>
```

**Mode**

Privileged EXEC

### 6.1.9 dot1x login

This command assigns the specified authentication login list to the specified user for 802.1X port security. The <user> parameter must be a configured user and the <list-name> parameter must be a configured authentication login list.

**Format**

```
dot1x login <user> <listname>
```

**Mode**

Global Config

### 6.1.10 dot1x mac-auth-bypass

This command enables the MAC-authorized-bypass on that interface.

**Default**

disabled

**Format**

dot1x mac-auth-bypass

**Mode**

Interface Config

### U no dot1x mac-auth-bypass

This command disables the MAC-authorized-bypass on that interface.

**Default**

disabled

**Format**

no dot1x mac-auth-bypass

**Mode**

Interface Config

### 6.1.11 dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant. The <count> value must be in the range 1 - 10.

**Default**

2

**Format**

```
dot1x max-req <count>
```

**Mode**

Interface Config

#### U no dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant.

**Format**

```
no dot1x max-req
```

**Mode**

Interface Config

### 6.1.12 dot1x max-users

Use this command to set the maximum number of clients supported on an interface when MAC-based 802.1X authentication is enabled on the port. The count value is in the range 1-16 and the default value is 16.

**Default**

16

**Format**

```
dot1x max-users <count>
```

**Mode**

Interface Config

#### U no dot1x max-users

The 'no' form of this command resets the maximum number of clients allowed to its default value of 16.

**Format**

```
no dot1x max-users
```

**Mode**

Interface Config

### 6.1.13 dot1x port-control

This command sets the authentication mode to be used on the specified port. The control mode may be one of the following.

- D `force-unauthorized`: The authenticator PAE unconditionally sets the controlled port to unauthorized. Thus the port is always blocked.
- D `force-authorized`: The authenticator PAE unconditionally sets the controlled port to authorized. Thus the port is always opened.
- D `auto`: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server. The port mode is controlled by the protocol.
- D `mac-based`: Enable MAC-based 802.1X authentication on the port.

#### Default

```
force-authorized
```

#### Format

```
dot1x port-control {force-unauthorized | force-authorized | auto | mac-based}
```

#### Mode

```
Interface Config
```

#### U `no dot1x port-control`

This command sets the port-control mode for the specified port to the default mode (`force-authorized`).

#### Format

```
no dot1x port-control
```

#### Mode

```
Interface Config
```

### 6.1.14 dot1x port-control all

This command sets the authentication mode to be used on all ports. The control mode may be one of the following.

- D `force-unauthorized`: The authenticator PAE unconditionally sets the controlled port to unauthorized. Thus the ports are always blocked.
- D `force-authorized`: The authenticator PAE unconditionally sets the controlled port to authorized. Thus the ports are always open.
- D `auto`: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server. The port mode is controlled by the protocol.
- D `mac-based`: Enable the MAC-based 802.1X authentication on the port.

#### Default

```
force-authorized
```

#### Format

```
dot1x port-control all {force-unauthorized | force-authorized | auto | mac-based}
```

#### Mode

```
Global Config
```

#### U no dot1x port-control all

This command sets the port-control mode for all the ports to the default mode (`force-authorized`).

#### Format

```
no dot1x port-control all
```

#### Mode

```
Global Config
```



### 6.1.15 dot1x re-authenticate

This command begins the re-authentication sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

**Format**

```
dot1x re-authenticate <slot/port>
```

**Mode**

```
Privileged EXEC
```

### 6.1.16 dot1x re-authentication

This command enables re-authentication of the supplicant for the specified port.

**Default**

```
disabled
```

**Format**

```
dot1x re-authentication
```

**Mode**

```
Interface Config
```

**U no dot1x re-authentication**

This command disables re-authentication of the supplicant for the specified port.

**Format**

```
no dot1x re-authentication
```

**Mode**

```
Interface Config
```

### 6.1.17 dot1x safe-vlan

Use this command to enable the safe-vlan assignment on the switch. This command is available for the RS20/RS30/RS40, RSB20, MS20/MS30, RSR20/RSR30, MACH100, MACH 1000, PowerMICE, MACH 4000, OCTOPUS devices.

**Default**

```
disabled
```

**Format**

```
dot1x safe-vlan
```

**Mode**

```
Global Config
```

#### U no dot1x safe-vlan

Use this command to disable the safe-vlan assignment on the switch.

**Default**

```
disabled
```

**Format**

```
no dot1x safe-vlan
```

**Mode**

```
Global Config
```

## 6.1.18 dot1x system-auth-control

This command is used to enable the dot1x authentication support on the switch. By default, the authentication support is disabled. While disabled, the dot1x configuration is retained and can be changed, but is not activated.

### Default

disabled

### Format

```
dot1x system-auth-control
```

### Mode

Global Config

U no dot1x system-auth-control

This command is used to disable the dot1x authentication support on the switch.

### Format

```
no dot1x system-auth-control
```

### Mode

Global Config

## 6.1.19 dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port. Depending on the token used and the value (in seconds) passed, various timeout configurable parameters are set. The following tokens are supported.

- D reauth-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when re-authentication of the supplicant takes place. The reauth-period must be a value in the range 1 - 65535.
- D quiet-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The quiet-period must be a value in the range 0 - 65535.
- D tx-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The quiet-period must be a value in the range 1 - 65535.
- D supp-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the supplicant. The supp-timeout must be a value in the range 1 - 65535.
- D server-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the authentication server. The supp-timeout must be a value in the range 1 - 65535.

### Defaults

```
reauth-period: 3600 seconds
quiet-period: 60 seconds
tx-period: 30 seconds
supp-timeout: 30 seconds
server-timeout: 30 seconds
```

### Format

```
dot1x timeout {{reauth-period <seconds>} | {quiet-
period <seconds>} | {tx-period <seconds>} | {supp-
timeout <seconds>} | {server-timeout <seconds>}}
```

### Mode

```
Interface Config
```

**U** no dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port to the default values. Depending on the token used, the corresponding default values are set.

**Format**

```
no dot1x timeout {reauth-period | quiet-period |  
tx-period | supp-timeout | server-timeout}
```

**Mode**

Interface Config

## 6.1.20 dot1x timeout guest-vlan-period

Use this command to configure the timeout value for the guest-vlan-period. The time, in seconds, for which the authenticator waits to see if any EAPOL packets are received on a port before authorizing the port and placing the port in the guest vlan (if configured). The guest vlan timer is only relevant when guest vlan has been configured on that specific port.

Default guest-vlan-period: 90 seconds.

### Default

90

### Format

```
dot1x timeout guest-vlan-period <seconds>
```

### Mode

Interface Config

### <seconds>

Enter an integer in the range of 1-300.

## U no dot1x timeout guest-vlan-period

The 'no' form of this command resets the timeout value for the guest-vlan-period to its default value (90 seconds).

### Format

```
no dot1x timeout guest-vlan-period
```

### Mode

Interface Config

## 6.1.21 dot1x unauthenticated-vlan

Use this command to configure the unauthenticated VLAN associated with the specified interface. The unauthenticated VLAN ID can be a valid VLAN ID from 0 to maximum supported VLAN ID. The unauthenticated VLAN must be statically configured in the VLAN database to be operational. By default, the unauthenticated VLAN is 0, i.e. invalid and not operational.

### Default

0

### Format

```
dot1x unauthenticated-vlan <vlan-id>
```

### Mode

Interface Config

### <vlan-id>

Enter an existing VLAN ID.

## U no dot1x unauthenticated-vlan

The 'no' form of this command resets the value for the unauthenticated VLAN to its default value.

### Format

```
no dot1x unauthenticated-vlan
```

### Mode

Interface Config

## 6.1.22 dot1x user

This command adds the specified user to the list of users with access to the specified port or all ports. The <user> parameter must be a configured user.

### Format

```
dot1x user <user> {<slot/port> | all}
```

### Mode

Global Config

## U no dot1x user

This command removes the user from the list of users with access to the specified port or all ports.

### Format

```
no dot1x user <user> {<slot/port> | all}
```

### Mode

Global Config



### 6.1.23 radius accounting mode

This command is used to enable the RADIUS accounting function.

**Default**

disabled

**Format**

radius accounting mode

**Mode**

Global Config

**U no radius accounting mode**

This command is used to set the RADIUS accounting function to the default value - i.e. the RADIUS accounting function is disabled.

**Format**

no radius accounting mode

**Mode**

Global Config

## 6.1.24 radius server host

This command is used to configure the RADIUS authentication and accounting server.

If the 'auth' token is used, the command configures the IP address to use to connect to a RADIUS authentication server. Up to 3 servers can be configured per RADIUS client. If the maximum number of configured servers is reached, the command will fail until one of the servers is removed by executing the no form of the command. If the optional <port> parameter is used, the command will configure the UDP port number to use to connect to the configured RADIUS server. In order to configure the UDP port number, the IP address must match that of a previously configured RADIUS authentication server. The port number must lie between 1 - 65535, with 1812 being the default value.

If the 'acct' token is used, the command configures the IP address to use for the RADIUS accounting server. Only a single accounting server can be configured. If an accounting server is currently configured, it must be removed from the configuration using the no form of the command before this command succeeds. If the optional <port> parameter is used, the command will configure the UDP port to use to connect to the RADIUS accounting server. The IP address specified must match that of a previously configured accounting server. If a port is already configured for the accounting server then the new port will replace the previously configured value. The port must be a value in the range 1 - 65535, with 1813 being the default value.

### Format

```
radius server host {auth | acct} <ipaddr> [<port>]
```

### Mode

```
Global Config
```

#### U no radius server host

This command is used to remove the configured RADIUS authentication server or the RADIUS accounting server. If the 'auth' token is used, the previously configured RADIUS authentication server is removed from the configuration. Similarly, if the 'acct' token is used, the previously configured RADIUS accounting server is removed from the configuration. The <ipaddr> parameter must match the IP address of the previously configured RADIUS authentication / accounting server.

**Format**

```
no radius server host {auth | acct} <ipaddress>
```

**Mode**

```
Global Config
```

### 6.1.25 radius server key

This command is used to configure the shared secret between the RADIUS client and the RADIUS accounting / authentication server. Depending on whether the 'auth' or 'acct' token is used, the shared secret will be configured for the RADIUS authentication or RADIUS accounting server. The IP address provided must match a previously configured server. When this command is executed, the secret will be prompted. The secret must be an alphanumeric value not exceeding 20 characters.

**Format**

```
radius server key {auth | acct} <ipaddr>
```

**Mode**

```
Global Config
```

### 6.1.26 radius server msgauth

This command enables the message authenticator attribute for a specified server.

**Default**

```
radius server msgauth <ipaddr>
```

**Mode**

```
Global Config
```

## 6.1.27 radius server primary

This command is used to configure the primary RADIUS authentication server for this RADIUS client. The primary server is the one that is used by default for handling RADIUS requests. The remaining configured servers are only used if the primary server cannot be reached. A maximum of three servers can be configured on each client. Only one of these servers can be configured as the primary. If a primary server is already configured prior to this command being executed, the server specified by the IP address used in this command will become the new primary server. The IP address must match that of a previously configured RADIUS authentication server.

### Format

```
radius server primary <ipaddr>
```

### Mode

```
Global Config
```

## 6.1.28 radius server retransmit

This command sets the maximum number of times a request packet is retransmitted when no response is received from the RADIUS server. The retries value is an integer in the range of 1 to 15.

### Default

4

### Format

```
radius server retransmit <retries>
```

### Mode

Global Config

### U no radius server retransmit

This command sets the maximum number of times a request packet is re-transmitted, when no response is received from the RADIUS server, to the default value, i.e. 10.

### Format

```
no radius server retransmit
```

### Mode

Global Config

## 6.1.29 radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received. The timeout value is an integer in the range of 1 to 30.

### Default

6

### Format

```
radius server timeout <seconds>
```

### Mode

Global Config

### U no radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received, to the default value, i.e. 6.

### Format

```
no radius server timeout
```

### Mode

Global Config

### 6.1.30 show radius accounting

This command is used to display the configured RADIUS accounting mode, accounting server and the statistics for the configured accounting server.

#### Format

```
show radius accounting [statistics <ipaddr>]
```

#### Mode

Privileged EXEC and User EXEC

If the optional token 'statistics <ipaddr>' is not included, then only the accounting mode and the RADIUS accounting server details are displayed.

#### Mode

Enabled or disabled

#### IP Address

The configured IP address of the RADIUS accounting server

#### Port

The port in use by the RADIUS accounting server

#### Secret Configured

Yes or No

If the optional token 'statistics <ipaddr>' is included, the statistics for the configured RADIUS accounting server are displayed. The IP address parameter must match that of a previously configured RADIUS accounting server. The following information regarding the statistics of the RADIUS accounting server is displayed.

#### Accounting Server IP Address

IP Address of the configured RADIUS accounting server

#### Round Trip Time

The time interval, in hundredths of a second, between the most recent Accounting-Response and the Accounting-Request that matched it from the RADIUS accounting server.

#### Requests

The number of RADIUS Accounting-Request packets sent to this accounting server. This number does not include retransmissions.

**Retransmission**

The number of RADIUS Accounting-Request packets retransmitted to this RADIUS accounting server.

**Responses**

The number of RADIUS packets received on the accounting port from this server.

**Malformed Responses**

The number of malformed RADIUS Accounting-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators and unknown types are not included as malformed accounting responses.

**Bad Authenticators**

The number of RADIUS Accounting-Response packets containing invalid authenticators received from this accounting server.

**Pending Requests**

The number of RADIUS Accounting-Request packets sent to this server that have not yet timed out or received a response.

**Timeouts**

The number of accounting timeouts to this server.

**Unknown Types**

The number of RADIUS packets of unknown types, which were received from this server on the accounting port.

**Packets Dropped**

The number of RADIUS packets received from this server on the accounting port and dropped for some other reason.



### 6.1.31 show authentication

This command displays the ordered authentication methods for all authentication login lists.

**Format**

```
show authentication
```

**Mode**

```
Privileged EXEC and User EXEC
```

**Authentication Login List**

This displays the authentication login listname.

**Method 1**

This displays the first method in the specified authentication login list, if any.

**Method 2**

This displays the second method in the specified authentication login list, if any.

**Method 3**

This displays the third method in the specified authentication login list, if any.

### 6.1.32 show authentication users

This command displays information about the users assigned to the specified authentication login list. If the login is assigned to non-configured users, the user “default” will appear in the user column.

**Format**

```
show authentication users <listname>
```

**Mode**

Privileged EXEC and User EXEC

**User**

This field displays the user assigned to the specified authentication login list.

**Component**

This field displays the component (User or 802.1X) for which the authentication login list is assigned.

### 6.1.33 show dot1x

This command is used to show a summary of the global dot1x configuration, summary information of the dot1x configuration for a specified port or all ports, the detailed dot1x configuration for a specified port and the dot1x statistics for a specified port - depending on the tokens used.

#### Format

```
show dot1x [{summary {<slot/port> | all} | {detail  
<slot/port>}} | {statistics <slot/port>}]
```

#### Mode

Privileged EXEC and User EXEC

If none of the optional parameters are used, the global dot1x configuration summary is displayed.

#### Administrative mode

Indicates whether authentication control on the switch is enabled or disabled.

#### VLAN Assignment Mode

Indicates whether the VLAN Assignment Mode is enabled or disabled.

#### Dynamic VLAN Creation Mode

Indicates whether the Dynamic VLAN Creation Mode is enabled or disabled.

#### Safe VLAN Mode

Indicates whether the Safe VLAN Mode is enabled or disabled.

If the optional parameter 'summary {<slot/port> | all}' is used, the dot1x configuration for the specified port or all ports are displayed.

#### Port

The interface whose configuration is displayed.

#### Control Mode

The configured control mode for this port. Possible values are  
force-unauthorized | force-authorized | auto |  
mac-based

## Operating Control Mode

The control mode under which this port is operating. Possible values are `authorized` | `unauthorized`

## Reauthentication Enabled

Indicates whether re-authentication is enabled on this port

## Key Transmission Enabled

Indicates if the key is transmitted to the supplicant for the specified port

If the optional parameter 'detail <slot/port>' is used, the detailed dot1x configuration for the specified port are displayed.

## Port

The interface whose configuration is displayed

## Protocol Version

The protocol version associated with this port. The only possible value is 1, corresponding to the first version of the dot1x specification.

## PAE Capabilities

The port access entity (PAE) functionality of this port. Possible values are `Authenticator` or `Supplicant`.

## Control Mode

Display the state of the Control Mode. Possible values: `auto`, `forceauthorized`, ....

## Authenticator PAE State

Current state of the authenticator PAE state machine. Possible values are `Initialize`, `Disconnected`, `Connecting`, `Authenticating`, `Authenticated`, `Aborting`, `Held`, `ForceAuthorized`, and `ForceUnauthorized`.

## Backend Authentication State

Current state of the backend authentication state machine. Possible values are `Request`, `Response`, `Success`, `Fail`, `Timeout`, `Idle`, and `Initialize`.

## Quiet Period

The timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a

supplicant. The value is expressed in seconds and will be in the range 0 and 65535.

### **Transmit Period**

The timer used by the authenticator state machine on the specified port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The value is expressed in seconds and will be in the range of 1 and 65535.

### **Guest VLAN ID**

Display the Guest VLAN ID. Default value: 0.

### **Guest VLAN Period (secs)**

Display the Guest VLAN Period. Default value: 90 seconds.

### **Supplicant Timeout**

The timer used by the authenticator state machine on this port to timeout the supplicant. . The value is expressed in seconds and will be in the range of 1 and 65535.

### **Server Timeout**

The timer used by the authenticator on this port to timeout the authentication server. The value is expressed in seconds and will be in the range of 1 and 65535.

### **Maximum Requests**

The maximum number of times the authenticator state machine on this port will retransmit an EAPOL EAP Request/Identity before timing out the supplicant. The value will be in the range of 1 and 10.

### **VLAN Id**

Display the VLAN Id.

### **VLAN Assigned Reason**

Display the state of the VLAN Assigned Reason parameter.  
Possible values: RADIUS, Not Assigned, ....

### **Reauthentication Period**

The timer used by the authenticator state machine on this port to determine when reauthentication of the supplicant takes place. The value is expressed in seconds and will be in the range of 1 and 65535.

**Reauthentication Enabled**

Indicates if reauthentication is enabled on this port. Possible values are 'True' or "False".

**Key Transmission Enabled**

Indicates if the key is transmitted to the supplicant for the specified port. Possible values are True or False.

**Control Direction**

Indicates the control direction for the specified port or ports. Possible values are both or in.

**Maximum Users**

Display the value of Maximum Users.

**Unauthenticated VLAN ID**

Display the value of Unauthenticated VLAN ID

**Session Timeout**

Display the value of Session Timeout

**Session Termination Action**

Display the value of Session Termination Action

**MAC-Authorized-Bypass**

Display the value of MAC-Authorized-Bypass

If the optional parameter 'statistics <slot/port>' is used, the dot1x statistics for the specified port are displayed.

**Port**

The interface whose statistics are displayed.

**EAPOL Frames Received**

The number of valid EAPOL frames of any type that have been received by this authenticator.

**EAPOL Frames Transmitted**

The number of EAPOL frames of any type that have been transmitted by this authenticator.

**EAPOL Start Frames Received**

The number of EAPOL start frames that have been received by this authenticator.

**EAPOL Logoff Frames Received**

The number of EAPOL logoff frames that have been received by this authenticator.

**Last EAPOL Frame Version**

The protocol version number carried in the most recently received EAPOL frame.

**Last EAPOL Frame Source**

The source MAC address carried in the most recently received EAPOL frame.

**EAP Response/Id Frames Received**

The number of EAP response/identity frames that have been received by this authenticator.

**EAP Response Frames Received**

The number of valid EAP response frames (other than resp/id frames) that have been received by this authenticator.

**EAP Request/Id Frames Transmitted**

The number of EAP request/identity frames that have been transmitted by this authenticator.

**EAP Request Frames Transmitted**

The number of EAP request frames (other than request/identity frames) that have been transmitted by this authenticator.

**Invalid EAPOL Frames Received**

The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

**EAP Length Error Frames Received**

The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

### 6.1.34 show dot1x users

This command displays 802.1X port security user information for locally configured users.

**Format**

```
show dot1x users <slot/port>
```

**Mode**

Privileged EXEC and User EXEC

**User**

Users configured locally to have access to the specified port.



### 6.1.35 show dot1x clients

This command displays 802.1X port security client information for locally configured clients.

**Format**

```
show dot1x clients <slot/port>
```

**Mode**

Privileged EXEC

**Logical Interface**

Display the Logical Interface.

**Interface**

Display the Interface.

**User Name**

Display the User Name.

**Supp MAC Address**

Display the Supp MAC Address.

**Session Time**

Display the Session Time.

Value range: ....

**Vlan Id**

Display the Vlan Id.

Possible values: ....

**Vlan Assigned Reason**

Display the Vlan Assigned Reason.

Possible values: RADIUS, ....

**Session Timeout**

Display the Session Timeout.

Value range: ....

**Session Termination Action**

Display the Session Termination Action.

Possible values: Reauthenticate, ....

## 6.1.36 show radius

This command is used to display the various RADIUS configuration items for the switch as well as the configured RADIUS servers. If the optional token 'servers' is not included, the following RADIUS configuration items will be displayed.

### Format

```
show radius [servers]
```

### Mode

Privileged EXEC and User EXEC

### Primary Server IP Address

Indicates the configured server currently in use for authentication

### Number of configured servers

The configured IP address of the authentication server

### Max number of retransmits

The configured value of the maximum number of times a request packet is retransmitted

### Timeout Duration

The configured timeout value, in seconds, for request re-transmissions

### Accounting Mode

Yes or No

If the optional token 'servers' is included, the following information regarding the configured RADIUS servers is displayed.

### IP Address

IP Address of the configured RADIUS server

### Port

The port in use by this server

### Type

Primary or secondary

### Secret Configured

Yes / No

### 6.1.37 show radius statistics

This command is used to display the statistics for RADIUS or configured server . To show the configured RADIUS server statistic, the IP Address specified must match that of a previously configured RADIUS server. On execution, the following fields are displayed.

#### Format

```
show radius statistics [ipaddr]
```

#### Mode

Privileged EXEC and User EXEC

If ip address is not specified than only Invalid Server Address field is displayed. Otherwise other listed fields are displayed.

#### Invalid Server Addresses

The number of RADIUS Access-Response packets received from unknown addresses.

#### Server IP Address

#### Round Trip Time

The time interval, in hundredths of a second, between the most recent Access-Reply | Access-Challenge and the Access-Request that matched it from the RADIUS authentication server.

#### Access Requests

The number of RADIUS Access-Request packets sent to this server. This number does not include retransmissions.

#### Access Retransmission

The number of RADIUS Access-Request packets retransmitted to this RADIUS authentication server.

#### Access Accepts

The number of RADIUS Access-Accept packets, including both valid and invalid packets, which were received from this server.

**Access Rejects**

The number of RADIUS Access-Reject packets, including both valid and invalid packets, which were received from this server.

**Access Challenges**

The number of RADIUS Access-Challenge packets, including both valid and invalid packets, which were received from this server.

**Malformed Access Responses**

The number of malformed RADIUS Access-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signature attributes or unknown types are not included as malformed access responses.

**Bad Authenticators**

The number of RADIUS Access-Response packets containing invalid authenticators or signature attributes received from this server.

**Pending Requests**

The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response.

**Timeouts**

The number of authentication timeouts to this server.

**Unknown Types**

The number of RADIUS packets of unknown types, which were received from this server on the authentication port.

**Packets Dropped**

The number of RADIUS packets received from this server on the authentication port and dropped for some other reason.

### 6.1.38 show users authentication

This command displays all user and all authentication login information. It also displays the authentication login list assigned to the default user.

**Format**

```
show users authentication
```

**Mode**

```
Privileged EXEC
```

**User**

This field lists every user that has an authentication login list assigned.

**System Login**

This field displays the authentication login list assigned to the user for system login.

**802.1x Port Security**

This field displays the authentication login list assigned to the user for 802.1X port security.

### 6.1.39 users login

This command assigns the specified authentication login list to the specified user for system login. The `<user>` must be a configured `<user>` and the `<listname>` must be a configured login list.

If the user is assigned a login list that requires remote authentication, all access to the interface from all CLI, web, and telnet sessions will be blocked until the authentication is complete.

Note that the login list associated with the 'admin' user can not be changed to prevent accidental lockout from the switch.

#### Format

```
users login <user> <listname>
```

#### Mode

Global Config

#### user

Enter user name.

#### listname

Enter an alphanumeric string of not more than 15 characters.

Note: when assigning a list to the 'admin' account, include an authentication method that allows administrative access even when remote authentication is unavailable (use 'authentication login `<listname>` [method1 [method2 [method3]]]').

## 6.2 HTTP Commands

### 6.2.1 ip http secure-port

This command is used to set the sslt port where port can be 1-65535 and the default is port 443.

**Default**

443

**Format**

```
ip http secure-port <portid>
```

**Mode**

Privileged EXEC

#### U no ip http secure-port

This command is used to reset the sslt port to the default value.

**Format**

```
no ip http secure-port
```

**Mode**

Privileged EXEC

## 6.2.2 ip http secure-protocol

This command is used to set protocol levels (versions). The protocol level can be set to TLS1, SSL3 or to both TLS1 and SSL3.

### Default

SSL3 and TLS1

### Format

```
ip http secure-protocol [SSL3] [TLS1]
```

### Mode

Privileged EXEC



### 6.2.3 ip http server

This command enables access to the switch's graphical user interface (web-based interface) via a web browser. When access is enabled, the user can login to the switch from the web-based interface. When access is disabled, the user cannot login to the switch's web server.

Disabling the web-based interface takes effect immediately. All interfaces are effected.

**Note:** First enable HTTP before enabling HTTPS.  
First disable the HTTPS web server before disabling HTTP.  
See "ip https server" on page 531.

#### Default

enabled

#### Format

```
ip http server
```

#### Mode

Privileged EXEC

#### U no ip http server

This command disables access to the switch's graphical user interface (web-based interface) via a web browser. When access is disabled, the user cannot login to the switch's web server.

#### Format

```
no ip http server
```

#### Mode

Privileged EXEC

## 6.2.4 show ip http

This command displays the http settings for the switch.

### **Format**

```
show ip http
```

### **Mode**

Privileged EXEC and User EXEC

### **Secure-Server Administrative Mode**

This field indicates whether the administrative mode of secure HTTP is enabled or disabled.

### **Secure Protocol Level**

The protocol level may have the values of SSL3, TSL1, or both SSL3 and TSL1.

### **Secure Port**

This field specifies the port configured for SSLT.

### **HTTP Mode**

This field indicates whether the HTTP mode is enabled or disabled.

### 6.2.5 ip https server

This command is used to turn on the HTTPS server 3.

This command enables access to the switch's graphical user interface (web-based interface) via a web browser. When access is enabled, the user can login to the switch from the web interface. When access is disabled, the user cannot login to the switch's web server.

**Note:** First enable HTTP before enabling HTTPS.

First disable the HTTPS web server before disabling HTTP.

See "ip http server" on page 529.

#### Default

disabled

#### Format

```
ip https server
```

#### Mode

Privileged EXEC

#### U no ip https server

This command is used to turn off the HTTPS server 3.

This command disables access to the switch's graphical user interface (web-based interface) via a web browser. When access is disabled, the user cannot login to the switch's web server.

#### Format

```
no ip https server
```

#### Mode

Privileged EXEC

## 6.2.6 ip https port

This command is used to set the HTTPS listening port. The acceptable range is 1-65535. The default is 443

**Note:** After this setting, re-enable the HTTPS server. See “ip http server” on page 529.

### Default

443

### Format

```
ip https port <port_no>
```

### Mode

Privileged EXEC

## U no ip https port

This command is used to reset the https port to the default value.

### Format

```
no ip https port
```

### Mode

Privileged EXEC

### 6.2.7 ip https certgen

Use this command to generate an X509/PEM certificate in-place.

**Format**

```
ip https certgen
```

**Mode**

Privileged EXEC

### 6.2.8 show ip https

This command displays the status of the HTTPS server (status of the server and port number).

**Format**

```
show ip https
```

**Mode**

Privileged EXEC and User EXEC

**HTTPS Mode**

Displays the status of the HTTPS server (enabled, disabled).

**HTTPS Port**

Displays the port number of the HTTPS server (default: 443).



## 7 Appendix- VLAN Example

LAN switches can segment networks into logically defined virtual workgroups. This logical segmentation is commonly referred to as a virtual LAN (VLAN). This logical segmentation of devices provides better LAN administration, security, and management of broadcast activity over the network. Virtual LANs have become an integral feature of switched LAN solutions.

**The VLAN example below demonstrates a simple VLAN configuration.**

If a single port is a member of VLANs 2, 3 and 4, the port expects to see traffic tagged with either VLAN 2, 3 or 4.

The PVID (Port Virtual Identification) could be something entirely different, for example '12' and things would still work fine, just so incoming traffic was tagged.

Example:

Project A = (VLAN2, ports 1,2)

Project B = (VLAN3, ports 3,4)

Project C = (VLAN4, ports 5,6)

Project P = (VLAN 9, port 7)

VLAN	Command
create VLAN 2	vlan database vlan 2 exit config interface 1/1 vlan participation include 2 exit interface 1/2 vlan participation include 2 exit

*Table 16: Creating VLANs*

VLAN	Command
create VLAN 3	<pre> vlan database vlan 3 exit config interface 0/3 vlan participation include 3 exit interface 0/4 vlan participation include 3 exit </pre>
create VLAN 4	<pre> vlan database vlan 4 exit config interface 0/5 vlan participation include 4 exit interface 0/6 vlan participation include 4 exit </pre>
create VLAN 9	<pre> vlan database vlan 9 exit config interface 0/1 vlan participation include 9 exit interface 0/2 vlan participation include 9 exit interface 0/3 vlan participation include 9 exit interface 0/4 vlan participation include 9 exit interface 0/5 vlan participation include 9 exit interface 0/6 vlan participation include 9 exit interface 0/7 vlan participation include 9 exit </pre>

*Table 16: Creating VLANs*



## 7.1 SOLUTION 1

All traffic entering the ports is tagged traffic. Since the traffic is tagged, the PVID configuration for each port is not a concern.

- D The network card configuration for devices on Project A must be set to tag all traffic with 'VLAN 2'
- D The network card configuration for devices on Project B must be set to tag all traffic with 'VLAN 3'
- D The network card configuration for devices on Project C must be set to tag all traffic with 'VLAN 4'
- D The network card configuration for devices on Project P must be set to tag all traffic with 'VLAN 9'



## 7.2 SOLUTION 2

The network card configuration for devices on Project A, B and C should be set to NOT tag traffic.

To take care of these untagged frames configure the following:

- D vlan pvid 2 (in interface 0/1)
- D vlan pvid 2 (in interface 0/2)
- D vlan pvid 3 (in interface 0/3)
- D vlan pvid 3 (in interface 0/4)
- D vlan pvid 4 (in interface 0/5)
- D vlan pvid 4 (in interface 0/6)



# 8 Glossary

## Numerics

**802.1D.** The IEEE designator for Spanning Tree Protocol (STP). STP, a link management protocol, is part of the 802.1D standard for media access control bridges. Using the spanning tree algorithm, STP provides path redundancy while preventing endless loops in a network. An endless loop is created by multiple active paths between stations where there are alternate routes between hosts. To establish path redundancy, STP creates a logical tree that spans all of the switches in an extended network, forcing redundant paths into a standby, or blocked, state. STP allows only one active path at a time between any two network devices (this prevents the loops) but establishes the redundant links as a backup if the initial link should fail. If STP costs change, or if one network segment in the STP becomes unreachable, the spanning tree algorithm reconfigures the spanning tree topology and reestablishes the link by activating the standby path. Without spanning tree in place, it is possible that both connections may be simultaneously live, which could result in an endless loop of traffic on the LAN.

**802.1P.** The IEEE protocol designator for Local Area Network (LAN). This Layer 2 network standard improves support of time critical traffic, and limits the extent of high bandwidth multicast traffic within a bridged LAN. To do this, 802.1P defines a methodology for introducing traffic class priorities. The 802.1P standard allows priority to be defined in all 802 MAC protocols (Ethernet, Token Bus, Token Ring), as well as in FDDI. For protocols (such as Ethernet) that do not contain a priority field, 802.1P specifies a method for indicating frame priority based on the new fields defined in the 802.1Q (VLAN) standard.

**802.1Q VLAN.** The IEEE protocol designator for Virtual Local Area Network (VLAN). This standard provides VLAN identification and quality of service (QoS) levels. Four bytes are added to an Ethernet frame to allow eight priority levels (QoS) and to identify up to 4096 VLANs. See “VLAN” on page 554 for more information.

## A

**Address Resolution Protocol.** An Internet Protocol that dynamically maps Internet addresses to physical (hardware) addresses on a LAN.

**Advanced Network Device Layer/Software.** Hirschmann term for the Device Driver level.

**Aging.** When an entry for a node is added to the lookup table of a switch, it is given a timestamp. Each time a packet is received from a node, the timestamp is updated. The switch has a user-configurable timer that erases the entry after a certain length of time with no activity from that node.

### **Application Programming**

**Interface.** An API is an interface used by an programmer to interface with functions provided by an application.

**AVL tree.** Binary tree having the property that for any node in the tree, the difference in height between the left and right subtrees of that node is no more than 1.

## **B**

**BPDU.** See “Bridge Protocol Data Unit” on page 542.

**BootP.** See “Bootstrap Protocol.” on page 542.

**Bootstrap Protocol.** An Internet protocol that enables a diskless workstation to discover its own IP address, the IP address of a BootP server on the network, and a file to be loaded into memory to boot the machine. This enables the workstation to boot without requiring a hard or floppy disk drive.

**Bridge Protocol Data Unit.** BPDU is the IEEE 802.1D MAC Bridge Management protocol that is the

standard implementation of STP (Spanning Tree Protocol). It uses the STP algorithm to insure that physical loops in the network topology do not result in logical looping of network traffic. Using one bridge configured as root for reference, the BPDU switches one of two bridges forming a network loop into standby mode, so that only one side of a potential loop passes traffic. By examining frequent 802.1d configuration updates, a bridge in the standby mode can switch automatically into the forward mode if the other bridge forming the loop fails.

## **C**

**Checksum.** A simple error-detection scheme in which each transmitted message is identified with a numerical value based on the number of set bits in the message. The receiving station then applies a formula to the message and checks to make sure the accompanying numerical value is the same. If not, the receiver can assume that the message has been corrupted.

**CLI.** See “Command Line Interface” on page 542.

**Command Line Interface.** CLI is a line-item interface for configuring systems.

**Complex Programmable Logic Device.** CPLD is a programmable circuit on which a logic network can

be programmed after its construction.

**CPLD.** See “Complex Programmable Logic Device.” on page 542.

## D

**DAPI.** See “Device Application Programming Interface” on page 543.

**Device Application Programming Interface.** DAPI is the software interface that facilitates communication of both data and control information between the Application Layer and HAPI, with support from System Support.

**DHCP.** See “Dynamic Host Configuration Protocol.” on page 543.

**Differentiated Services.** Diffserv is a protocol for specifying and controlling network traffic by class so that certain types of traffic get precedence - for example, voice traffic, which requires a relatively uninterrupted flow of data, might get precedence over other kinds of traffic. Differentiated Services is the most advanced method for managing traffic in terms of what is called Class of Service (CoS). Unlike the earlier mechanisms of 802.1P tagging and Type of Service (ToS), Differentiated Services avoids simple priority tagging and depends on more complex policy or rule

statements to determine how to forward a given network packet. An analogy is made to travel services, in which a person can choose among different modes of travel - train, bus, airplane - degree of comfort, the number of stops on the route, standby status, the time of day or period of year for the trip, and so forth. For a given set of packet travel rules, a packet is given one of 64 possible forwarding behaviors - known as per hop behaviors (PHBs). A six-bit field, known as the Differentiated Services Code Point (DSCP), in the Internet Protocol (Internet Protocol) header specifies the per hop behavior for a given flow of packets. Differentiated Services and the Class of Service approach provide a way to control traffic that is both more flexible and more scalability than the Quality of Service approach.

**Diffserv.** See “Differentiated Services.” on page 543..

**Dynamic Host Configuration Protocol.** DHCP is a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses. Dynamic addressing simplifies network administration because the software tracks IP

addresses rather than requiring an administrator to manage the task. A new computer can be added to a network without the hassle of manually assigning it a unique IP address.

## E

**EEPROM.** See “Electronically Erasable Programmable Read Only Memory” on page 544.

**Electronically Erasable Programmable Read Only Memory.** EEPROM is also known as Flash memory. This is re-programmable memory.

## F

**Fast STP.** A high-performance Spanning Tree Protocol. See “STP” on page 553 for more information.

**FIFO.** First In First Out.

**Flash Memory.** See “EEPROM” on page 544.

**Flow Control.** The process of adjusting the flow of data from one network device to another to ensure that the receiving device can handle all of the incoming data. This is particularly important where the sending device is capable of sending data much faster than the receiving device can receive it. There are many flow control mechanisms. One of the most common flow control protocols for

asynchronous communication is called xon-xoff. In this case, the receiving device sends a an “xoff” message to the sending device when its buffer is full. The sending device then stops sending data. When the receiving device is ready to receive more data, it sends an “xon” signal.

**Forwarding.** When a frame is received on an input port on a switch, the address is checked against the lookup table. If the lookup table has recorded the destination address, the frame is automatically forwarded on an output port.

**Frame Check Sequence.** The extra characters added to a frame for error detection and correction. FCS is used in X.25, HDLC, Frame Relay, and other data link layer protocols.

## G

**GARP.** See “Generic Attribute Registration Protocol.” on page 545.

**GARP Information Propagation.**

GIP is the propagation of information between GARP participants for the same application in a bridge is carried out by a GIP component.

**GARP Multicast Registration Protocol.** GMRP provides a mechanism that allows Bridges and end stations to dynamically register (and subsequently, de-register)



Group membership information with the MAC Bridges attached to the same LAN segment, and for that information to be disseminated across all Bridges in the Bridged LAN that support Extended Filtering Services. The operation of GMRP relies upon the services provided by the GARP.

### **GARP VLAN Registration**

**Protocol.** GVRP allows workstations to request admission to a particular VLAN for multicast purposes.

**GE.** See “Gigabit Ethernet” on page 545.

**General Purpose Chip-select Machine.** GPCM provides interfacing for simpler, lower-performance memory resources and memory mapped-devices. The GPCM does not support bursting and is used primarily for boot-loading.

### **Generic Attribute Registration**

**Protocol.** GARP provides a generic attribute dissemination capability that is used by participants in GARP Applications (called GARP Participants) to register and de-register attribute values with other GARP Participants within a Bridged LAN. The definition of the attribute types, the values that they can carry, and the semantics that are associated with those values when registered are specific to the

operation of the GARP Application concerned.

**Gigabit Ethernet.** A high-speed Ethernet connection.

**GIP.** See “GARP Information Propagation” on page 544.

**GMRP.** See “GARP Multicast Registration Protocol” on page 544.

**GPCM.** See “General Purpose Chip-select Machine” on page 545.

**GVD.** GARP VLAN Database.

**GVRP.** See “GARP VLAN Registration Protocol.” on page 545.

## **H**

**.h file.** Header file in C code. Contains function and coding definitions.

**HAPI.** See “Hardware Abstraction Programming Interface” on page 545.

### **Hardware Abstraction**

**Programming Interface.** HAPI is the module that contains the NP specific software that interacts with the hardware.

**hop count.** The number of routers that a data packet passes through on its way to its destination.

## **I**

**ICMP.** See “Internet Control Message Protocol” on page 546.

**IGMP.** See “Internet Group Management Protocol” on page 546.

**IGMP Snooping.** A series of operations performed by intermediate systems to add logic to the network to optimize the flow of multicast traffic; these intermediate systems (such as Layer 2 switches) listen for IGMP messages and build mapping tables and associated forwarding filters, in addition to reducing the IGMP protocol traffic. See “Internet Group Management Protocol” on page 546 for more information.

### **Internet Control Message**

**Protocol.** ICMP is an extension to the Internet Protocol (IP) that supports packets containing error, control, and informational messages. The PING command, for example, uses ICMP to test an Internet connection.

### **Internet Group Management**

**Protocol.** IGMP is the standard for IP Multicasting on the Internet. IGMP is used to establish host memberships in particular multicast groups on a single network. The mechanisms of the protocol allow a host to inform its local router, using Host Membership Reports, that it wants to receive messages addressed to a specific multicast group. All hosts conforming to Level 2 of the IP Multicasting specification require IGMP.

**IP.** See “Internet Protocol” on page 546.

**IP Multicasting.** Sending out data to distributed servers on the MBone (Multicast Backbone). For large amounts of data, IP Multicast is more efficient than normal Internet transmissions because the server can broadcast a message to many recipients simultaneously. Unlike traditional Internet traffic that requires separate connections for each source-destination pair, IP Multicasting allows many recipients to share the same source. This means that just one set of packets is transmitted for all the destinations.

**Internet Protocol.** The method or protocol by which data is sent from one computer to another on the Internet. Each computer (known as a host) on the Internet has at least one IP address that uniquely identifies it among all other computers on the Internet. When you send or receive data (for example, an e-mail note or a Web page), the message gets divided into little chunks called packets. Each of these packets contains both the sender's Internet address and the receiver's address. Any packet is sent first to a gateway computer that understands a small part of the Internet. The gateway computer reads the destination address and forwards the packet to an adjacent gateway that in turn reads the destination address and so forth across the Internet until one

gateway recognizes the packet as belonging to a computer within its immediate neighborhood or domain. That gateway then forwards the packet directly to the computer whose address is specified.

Because a message is divided into a number of packets, each packet can, if necessary, be sent by a different route across the Internet. Packets can arrive in a different order than they were sent. The Internet Protocol just delivers them. It's up to another protocol, the Transmission Control Protocol (TCP) to put them back in the right order. IP is a connectionless protocol, which means that there is no continuing connection between the end points that are communicating. Each packet that travels through the Internet is treated as an independent unit of data without any relation to any other unit of data. (The reason the packets do get put in the right order is because of TCP, the connection-oriented protocol that keeps track of the packet sequence in a message.) In the Open Systems Interconnection (OSI) communication model, IP is in Layer 3, the Networking Layer. The most widely used version of IP today is IP version 4 (IPv4). However, IP version 6 (IPv6) is also beginning to be supported. IPv6 provides for much longer addresses and therefore for the possibility of many more Internet users. IPv6 includes the capabilities of IPv4 and any

server that can support IPv6 packets can also support IPv4 packets.

## J

**Joint Test Action Group.** An IEEE group that specifies test framework standards for electronic logic components.

**JTAG.** See “Joint Test Action Group” on page 547.

## L

**LAN.** See “Local Area Network” on page 548.

**LDAP.** See “Lightweight Directory Access Protocol” on page 547.

**Lightweight Directory Access Protocol.** A set of protocols for accessing information directories. LDAP is based on the standards contained within the X.500 standard, but is significantly simpler. Unlike X.500, LDAP supports TCP/IP, which is necessary for any type of Internet access. Although not yet widely implemented, LDAP should eventually make it possible for almost any application running on virtually any computer platform to obtain directory information, such as e-mail addresses and public keys. Because LDAP is an open protocol, applications need not worry about the type of server hosting the directory.

**Learning.** The bridge examines the Layer 2 source addresses of every frame on the attached networks (called listening) and then maintains a table, or cache, of which MAC addresses are attached to each of its ports.

**Link-State.** In routing protocols, the declared information about the available interfaces and available neighbors of a router or network. The protocol's topological database is formed from the collected link-state declarations.

**LLDP.** The IEEE 802.1AB standard for link layer discovery in Ethernet networks provides a method for switches, routers and access points to advertise their identification, configuration and capabilities to neighboring devices that store the data in a MIB (management information base). Link layer discovery allows a network management system to model the topology of the network by interrogating the MIB databases in the devices.

**Local Area Network.** A group of computers that are located in one area and are connected by less than 1,000 feet of cable. A typical LAN might interconnect computers and peripherals on a single floor or in a single building. LANs can be connected together, but if modems and telephones connect two or more LANs, the larger network constitutes

what is called a WAN or Wide Area Network.

## M

**MAC.** (1) Medium Access Control. In LANs, the sublayer of the data link control layer that supports medium-dependent functions and uses the services of the physical layer to provide services to the logical link control (LLC) sublayer. The MAC sublayer includes the method of determining when a device has access to the transmission medium. (2) Message Authentication Code. In computer security, a value that is a part of a message or accompanies a message and is used to determine that the contents, origin, author, or other attributes of all or part of the message are as they appear to be. (*IBM Glossary of Computing Terms*)

### **Management Information Base.**

When SNMP devices send SNMP messages to the management console (the device managing SNMP messages), it stores information in the MIB.

**MBONE.** See "Multicast Backbone" on page 549.

**MDC.** Management Data Clock.

**MDI.** Management Data Interface.

**MDIO.** Management Data Input/Output.

**MDIX.** Management Dependent Interface Crossover.

**MIB.** See “Management Information Base” on page 548.

**MOSPF.** See “Multicast OSPF” on page 549.

**MPLS.** See “Multi-Protocol Label Switching” on page 549.

**Multicast Backbone.** The MBONE is a virtual network. It is layered on top of portions of the physical Internet to support routing of IP multicast packets since that function has not yet been integrated into many production routers. The network is composed of islands that can directly support IP multicast, such as multicast LANs like Ethernet, linked by virtual point-to-point links called “tunnels”. The tunnel endpoints are typically workstation-class machines having operating system support for IP multicast and running the “mrouterd” multicast routing daemon.

**Multicasting.** To transmit a message to specific recipients across a network. A simple example of multicasting is sending an e-mail message to a mailing list. Teleconferencing and videoconferencing also use multicasting, but require more robust protocols and networks. Standards are being developed to support multicasting over a TCP/IP network such as the Internet. These standards, IP Multicast and Mbone,

will allow users to easily join multicast groups. Note that multicasting refers to sending a message to a select group whereas broadcasting refers to sending a message to everyone connected to a network. The terms multicast and narrowcast are often used interchangeably, although narrowcast usually refers to the business model whereas multicast refers to the actual technology used to transmit the data.

**Multicast OSPF.** With a MOSPF specification, an IP Multicast packet is routed based both on the packet's source and its multicast destination (commonly referred to as source/destination routing). As it is routed, the multicast packet follows a shortest path to each multicast destination. During packet forwarding, any commonality of paths is exploited; when multiple hosts belong to a single multicast group, a multicast packet will be replicated only when the paths to the separate hosts diverge. See “P” on page 551 for more information.

**Multiplexing.** A function within a layer that interleaves the information from multiple connections into one connection.

### **Multi-Protocol Label Switching.**

An initiative that integrates Layer 2 information about network links (bandwidth, latency, utilization) into Layer 3 (IP) within a particular

autonomous system—or ISP—in order to simplify and improve IP-packet exchange. MPLS gives network operators a great deal of flexibility to divert and route traffic around link failures, congestion, and bottlenecks. From a QoS standpoint, ISPs will better be able to manage different kinds of data streams based on priority and service plan. For instance, those who subscribe to a premium service plan, or those who receive a lot of streaming media or high-bandwidth content can see minimal latency and packet loss. When packets enter into a MPLS-based network, Label Edge Routers (LERs) give them a label (identifier). These labels not only contain information based on the routing table entry (i.e., destination, bandwidth, delay, and other metrics), but also refer to the IP header field (source IP address), Layer 4 socket number information, and differentiated service. Once this classification is complete and mapped, different packets are assigned to corresponding Labeled Switch Paths (LSPs), where Label Switch Routers (LSRs) place outgoing labels on the packets. With these LSPs, network operators can divert and route traffic based on data-stream type and Internet-access customer.

**MT-RJ connector.** A type of fiber-optic cable jack that is similar in shape and concept to a standard telephone jack, enabling duplex

fiber-optic cables to be plugged into compatible devices as easily as plugging in a telephone cable.

**MUX.** See “Multiplexing” on page 549.

## N

**NM.** Network Module.

**nm.** Nanometer (1 x 10<sup>9</sup>) meters.

**NP.** Network Processor.

## O

### **Open Systems Interconnection.**

OSI is a seven (7) layer architecture model for communications systems developed by the ISO for the interconnection of data communications systems. Each layer uses and builds on the services provided by those below it.

**Operating System Application Programming Interface.** OSAPI is a module within the System Support software that provides a set of interfaces to OS support functions.

**OS.** Operating System.

**OSAPI.** See “Operating System Application Programming Interface” on page 550.

**OSI.** See “Open Systems Interconnection” on page 550.

### P

**PDU.** See “Protocol Data Unit” on page 551.

**PHY.** The OSI Physical Layer: The physical layer provides for transmission of cells over a physical medium connecting two ATM devices. This physical layer is comprised of two sublayers: the Physical Medium Dependent (PMD) sublayer, and the Transmission Convergence (TC) sublayer.

**PMC.** Packet Mode Channel.

**Port Mirroring.** Also known as a roving analysis port. This is a method of monitoring network traffic that forwards a copy of each incoming and outgoing packet from one port of a network switch to another port where the packet can be studied. A network administrator uses port mirroring as a diagnostic tool or debugging feature, especially when fending off an attack. It enables the administrator to keep close track of switch performance and alter it if necessary. Port mirroring can be managed locally or remotely. An administrator configures port mirroring by assigning a port from which to copy all packets and another port where those packets will be sent. A packet bound for or heading away from the first port will be forwarded onto the second port as well. The administrator places a protocol analyzer on the port receiving the

mirrored data to monitor each segment separately. The analyzer captures and evaluates the data without affecting the client on the original port. The monitor port may be a port on the same SwitchModule with an attached RMON probe, a port on a different SwitchModule in the same hub, or the SwitchModule processor. Port mirroring can consume significant CPU resources while active. Better choices for long-term monitoring may include a passive tap like an optical probe or an Ethernet repeater.

**Protocol Data Unit.** PDU is a packet of data passed across a network. The term implies a specific layer of the OSI model and a specific protocol.

### Q

**QoS.** See “Quality of Service” on page 551.

**Quality of Service.** QoS is a networking term that specifies a guaranteed level of throughput. Throughput is the amount of data transferred from one device to another or processed in a specified amount of time - typically, throughputs are measured in bytes per second (Bps).

## R

### **Real-Time Operating System.**

RTOS is a component of the OSAPI module that abstracts operating systems with which other systems can interface.

**RFC.** Request For Comment.

**RMON.** Short for remote monitoring, a network management protocol that allows network information to be gathered at a single workstation. Whereas SNMP gathers network data from a single type of Management Information Base (MIB), RMON 1 defines nine additional MIBs that provide a much richer set of data about network usage. For RMON to work, network devices, such as hubs and switches, must be designed to support it. The newest version of RMON, RMON 2, provides data about traffic at the network layer in addition to the physical layer. This allows administrators to analyze traffic by protocol.

**RP.** Rendezvous Point. Used with IP Multicast.

**RPU.** Remote Power Unit.

**RTOS.** See “Real-Time Operating System” on page 552.

## S

**SDL.** Synchronous Data Link.

**Simple Network Management Protocol.** SNMP is the protocol governing network management and the monitoring of network devices and their functions. It is not necessarily limited to TCP/IP networks. The versions have the following differences:

*SNMPv1* (full): Security is based on community strings.

*SNMPsec* (historic): Security is based on parties. Few, if any, vendors implemented this version of the protocol, which is now largely forgotten.

*SNMPv2p* (historic): For this version, much work was done to update the SNMPv1 protocol and the SMIv1, and not just security. The result was updated protocol operations, new protocol operations and data types, and party-based security from SNMPsec.

*SNMPv2c* (experimental): This version of the protocol is called community string-based SNMPv2. It is an update of the protocol operations and data types of SNMPv2p, and uses community-based security from SNMPv1.

*SNMPv2u* (experimental): This version of the protocol uses the protocol operations and data types of SNMPv2c and security based on users.

*SNMPv2\** (experimental): This version combined the best features



of SNMPv2p and SNMPv2u. (It is also called SNMPv2star.) The documents defining this version were never published as RFCs.

*SNMPv3* (proposed): This version of the protocol is a combination of user-based security and the protocol operations and data types from SNMPv2p and support for proxies. The security is based on that found in SNMPv2u and SNMPv2\*, and updated after much review. The documents defining this protocol will soon be published as RFCs.

**SimpleX signaling.** SX is one of IEEE 802.3's designations for media. For example, 1000SX indicates 1000 gigabit Ethernet over "short haul" or "short wavelength" optical fiber.

**SMC1.** A model of Serial Management Controller from Motorola.

**SMII.** Serial Media Independent Interface.

**SNMP.** See "Simple Network Management Protocol" on page 552.

**SODIMM.** Small Outline Dual Inline Memory Module.

**SRAM.** Static Random Access Memory.

**STP.** Spanning Tree Protocol. See "802.1D" on page 541 for more information.

## T

**TBI.** Ten Bit Interface.

**Telnet.** A character-based UNIX application that enables users with a Telnet server account to log on to a UNIX computer and utilize its resources.

**TFTP.** See "Trivial File Transfer Protocol" on page 553.

### **Trivial File Transfer Protocol.**

TFTP is a simple form of the File Transfer Protocol (FTP). TFTP uses the User Datagram Protocol (UDP, a direct protocol used to communicate datagrams over a network with little error recovery) and provides no security features. It is often used by servers to boot diskless workstations, X-terminals, and routers.

**Trunking.** The process of combining a set of trunks that are traffic-engineered as a unit for the establishment of connections between switching systems in which all of the communications paths are interchangeable.

## U

**UPM.** User Programmable Machine.

**UPMA.** The first of two UPMs in Motorola's MPC855T processor.

**UPMB.** The second of two UPMs in Motorola's MPC855T processor.

**USP.** An abbreviation that represents Unit, Slot, Port.

## V

### **Virtual Local Area Network.**

Operating at the Data Link Layer (Layer 2 of the OSI model), the VLAN is a means of parsing a single network into logical user groups or organizations, as if they physically resided on a dedicated LAN segment of their own. In reality, this virtually defined community may have individual members peppered across a large, extended LAN. The VLAN identifier is part of the 802.1Q tag, which is added to an Ethernet frame by an 802.1Q-compliant switch or router. Devices recognizing 802.1Q-tagged frames maintain appropriate tables to track VLANs. The first three bits of the 802.1Q tag are used by 802.1P to establish priority for the packet.

**VLAN.** See "Virtual Local Area Network" on page 554.

**vMAN.** Virtual Metropolitan Area Network.

## W

**WAN.** See "Wide Area Network" on page 554.

**Web.** Also known as World-Wide Web (WWW) or W3. An Internet

client-server system to distribute information, based upon the hypertext transfer protocol (HTTP).

**Wide Area Network.** A WAN is a computer network that spans a relatively large geographical area. Typically, a WAN consists of two or more local-area networks (LANs).

## X

**X.500.** A directory standard that enables applications like e-mail to access information that can either be central or distributed. The benefit of a directory is the ability to minimize the impact on the user of changes to a network. The standard is broken down under subsequent standards, as follows:

*X.501* Models

*X.509* Authentication framework

*X.511* Abstract service definition

*X.518* Procedures for distributed operation

*X.519* Protocol specifications

*X.520* Selected attribute types

*X.521* Selected object types

**XModem.** One of the most popular file transfer protocols (FTPs). Xmodem is fairly effective at detecting errors. It sends blocks of data together with a checksum and then waits for acknowledgment of the block's receipt. The waiting

slows down the rate of data transmission considerably, but it ensures accurate transmission. Xmodem can be implemented either in software or in hardware. Many modems, and almost all communications software packages, support Xmodem. However, it is useful only at relatively slow data transmission speeds (less than 4,800 bps). Enhanced versions of Xmodem that work at higher transmission speeds are known as Ymodem and Zmodem.







# 9 Index

<b>A</b>			
addport	171	clear pass	281
address-conflict	275	clear port-sec	460
adminmode	172	clear radius statistics	488
arc	431	clear ring-coupling	283
areaid	25	clear sfp-white-list	292
authentication login	485	clear signal-contact	282
authorization network radius	487	clear traplog	283
auto-negotiate	173	clear vlan	284
auto-negotiate all	175	Competence Center	569
<b>B</b>		config commands	
boot skip-aca-on-boot	276, 276	config lags adminmode	184
bridge address-learning	101	config lags linktrap	185
bridge address-relearn detect operation	102	config lags name	186
bridge address-relearn detect threshold	102	config loginsession	263
bridge aging-time	103	config port admin-mode	234, 235
bridge duplex-mismatch-detect operation	104	config port linktrap	236, 237
bridge fast-link-detection	104	config port physical-mode	239
bridge framesize	56	config switchconfig broadcast	240, 241, 242
bridge vlan-learning	105	config switchconfig flowcontrol	243, 244
broadcasts		config users add	268, 269
broadcast storm recovery mode	240, 241, 242	config users delete	267, 268, 269
<b>C</b>		config users passwd	270
cable-crossing	174	config vlan add	245
cablestatus	277	config vlan delete	245
classofservice dot1pmapping	85	config vlan garp jointime	186, 187, 188, 189, 190, 191, 192
classofservice ip-dscp-mapping	86	config vlan garp leavealltime	194
classofservice trus	87	config vlan garp leavetime	193
clear arp-table-switch	278	config vlan interface acceptframe	247, 248, 252
clear commands		config vlan name	249
clear arp-table-switch	278	config vlan participation	250, 251
clear config	279	config vlan ports ingressfilter	248, 249, 253
clear pass	281	config vlan ports pvid	254, 256
clear traplog	282, 283	config vlan ports tagging	255, 257
clear vlan	284	config port autoneg	186
clear config	279	config switchconfig flowcontrol	243, 244
clear config factory	279	config users delete	267, 268, 269, 270
clear counters	279	config users passwd	267, 268, 269, 270
clear dot1x statistics	487	config vlan delete	245
clear eventlog	277	config vlan ports acceptframe	256
clear hiper-ring	280	config vlan ports ingressfilter	247, 252, 253, 254
clear igmpsnooping	280	configuration reset	279
clear inlinepower	371	config-watchdog	284
clear link-aggregation	282		
clear lldp config all	316		
clear mac-addr-table	281		

copy	285	dot1x re-authentication	497
copy nvram clibanner	290	dot1x safe-vlan	498
copy nvram startup-config	291	dot1x system-auth-control	499
copy system bootcode	292	dot1x timeout	500
copy system image	291	dot1x user	504
copy system running-config	292	duplex settings	239
copy nvram capture	288	dvlan-tunnel ethertype	92
copy nvram capture aca capture	287	<b>E</b>	
copy nvram clibanner	287	ethernet-ip	118
copy nvram errorlog	288	<b>F</b>	
copy nvram script	289	fast-hiper-ring	444
copy nvram traplog	289	flow control	243, 244
copy system running-config	289	frame acceptance mode	247, 248, 252
<b>D</b>		<b>G</b>	
debug tcpdump filter delete	82	Global Config Mode	45
debug tcpdump filter list	81	GVRP	
debug tcpdump filter show	81	join time	186, 187, 188, 189, 190, 191, 192
debug tcpdump help	79	leave time	193
debug tcpdump start cpu	79	<b>H</b>	
debug tcpdump start cpu filter	80	hiper-ring	437
debug tcpdump stop	80	hiper-ring mode	438
deleteport	176	hiper-ring port primary	438
deleteport all	176	hiper-ring port secondary	439
device configuration commands	201	hiper-ring recovery-delay	439
device-status connection-error	292	<b>I</b>	
device-status monitor	293	IEEE 802.1Q	247, 248, 252
DHCP server configuration example	466	ingress filtering	248, 249, 253
dhcp-relay	462, 463	inlinepower (Global Config)	370
dhcp-server operation	469	inlinepower (Interface Config)	371
dhcp-server pool add	469	inlinepower budget slot	374
dhcp-server pool delete	474	inlinepower threshold slot	375
dhcp-server pool disable	474	inlinepower trap slot	375
dhcp-server pool enable	474	Interface Config Mode	46
dhcp-server pool modify hirschmann-device	473	inventory	212, 213, 214, 216, 217, 218, 220, 221, 485
dhcp-server pool modify mode	470	ip http secure-port	527
dhcp-server pool modify option	472	ip http secure-protocol	528
dhcp-server pool modify leasetime	473	ip http server	529
digital-input	105	ip https certgen	533
digital-output	107	ip https port	532
disconnect	263	ip https server	531
dot1x defaultlogin	488	<b>J</b>	
dot1x dynamic-vlan enable	489	join time	186, 187, 188, 189, 190, 191, 192
dot1x guest-vlan	490	<b>L</b>	
dot1x initialize	491	LAGs	
dot1x login	491	enabling or disabling	184
dot1x mac-auth-bypass	492		
dot1x max-req	493		
dot1x max-users	494		
dot1x port-control	495		
dot1x port-control all	496		
dot1x re-authenticate	497		



# Index

---

link traps	185	logging buffered wrap	160
name	186	logging cli-command	161
summary information	224	logging console	162
leave time	193, 194	logging host	163
Line Config Mode	46	logging host reconfigure	164
Link Aggregation(802.3ad) Commands	95	logging host remove	164
link aggregations. See LAGs		logging snmp-requests get operation	164
link traps		logging snmp-requests get severity	165
interface	236, 237	logging snmp-requests set operation	165
LAG	185	logging snmp-requests set severity	166
link-aggregation	183	logging syslog	167
link-aggregation adminmode	184	logging syslog port	167
link-aggregation linktrap	185	logical slot/port	26
link-aggregation name	186	logout	294
link-aggregation staticcapability	95	logout command	294
lldp	312		
LLDP - Link Layer Discovery Protocol	301	M	
lldp admin-state	317	macaddr	25
lldp chassis tx-interval	316	macfilter	177
lldp config chassis admin-state	313	macfilter adddest	178
lldp config chassis notification-interval	314	macfilter adddest all	179
lldp config chassis re-init-delay	314	media-module remove	175
lldp config chassis tx-delay	315	mode dvlan-tunnel	93
lldp config chassis tx-hold-mult	315	monitor session	180
lldp fdb-mode	317	monitor session mode	181
lldp hm-mode	318	monitor session source/destination	182
lldp max-neighbors	318	mrp current-domain	428
lldp med	318	mrp delete-domain	429
lldp med al	319	mrp new-domain	430
lldp med confignotification	320		
lldp med confignotification all	320	N	
lldp med faststartrepeatcount	321	name	330
lldp med transmit-tlv	322	network javascriptmode	118
lldp med transmit-tlv all	323	network mgmt_vlan	83
lldp notification	324	network mgmt-access add	119
lldp tlv gmrp	327	network mgmt-access delete	120
lldp tlv igmp	327	network mgmt-access modify	121
lldp tlv link-aggregation	324	network mgmt-access operation	122
lldp tlv mac-phy-config-state	324	network mgmt-access status	122
lldp tlv max-frame-size	325	network parms	123
lldp tlv mgmt-addr	325	network priority	124
lldp tlv pnio	325	network protocol	123
lldp tlv pnio-alias	326	no dhcp-relay	462
lldp tlv pnio-mrp	326	no lldp	313
lldp tlv port-desc	326	no snmp	336
lldp tlv portsec	328	no snmp anycast address	337, 338, 343
lldp tlv port-vlan	327	no snmp client server	340
lldp tlv protocol	328	no snmp client server primary	341, 341, 342
lldp tlv ptp	328	no storm-control broadcast	240
lldp tlv sys-cap	329		
lldp tlv sys-desc	329	P	
lldp tlv sys-name	329	passwords	
lldp tlv vlan-name	330	changing user	270
logging buffered	159	resetting all	281

PDUs	186, 187, 188, 189, 190, 191, 192, 194	
ping		294
ping command	292, 293, 294, 295	
PoE - Power over Ethernet		369
Port monitor		377
port-monitor (Global Config)		382
port-monitor (Interface Config)		382
port-monitor action		385
port-monitor condition crc-fragment (Global Config)		384
port-monitor condition crc-fragment (Interface Config)		385
port-monitor condition link-flap (Global Config)		383
port-monitor condition link-flap (Interface Config)		383
ports		
administrative mode	234, 235	
frame acceptance mode	247, 248, 252	
information		223
ingress filtering	248, 249, 253	
link traps	236, 237	
physical mode		239
tagging	255, 257	
VLAN IDs	254, 256	
VLAN information		231
port-sec action		456
port-sec allowed-ip		457
port-sec allowed-ip add		457
port-sec allowed-ip remove		458
port-sec allowed-mac		458
port-sec allowed-mac add		459
port-sec allowed-mac remove		459
port-sec mode		456
Privileged Exec Mode		45
profinetio		125
Protocol Data Units. See PDUs		
PTP - Precision Time Protocol		345
ptp clock-mode		349
ptp operation		350
ptp sync-lower-bound		351
ptp sync-upper-bound		351
ptp v1 burst		357
ptp v1 operation		358
ptp v1 preferred-master		352
ptp v1 re-initialize		352
ptp v1 subdomain-name		353
ptp v1 sync-interval		354
ptp v2bc announce-interval		359
ptp v2bc announce-timeout		360
ptp v2bc asymmetry		362
ptp v2bc delay-mechanism		360
ptp v2bc domain		356
ptp v2bc network-protocol		361
ptp v2bc operation		359
ptp v2bc pdelay-interval		361
ptp v2bc priority1		355
ptp v2bc priority2		355
ptp v2bc sync-interval		360
ptp v2bc utc-offset		356
ptp v2bc utc-offset-valid		356
ptp v2bc v1-compatibility-mode		361
ptp v2bc vlan		357
ptp v2bc vlan-priority		357
ptp v2tc asymmetry		362
ptp v2tc delay-mechanism		362
ptp v2tc management		363
ptp v2tc multi-domain-mode		363
ptp v2tc network-protocol		364
ptp v2tc operation		364
ptp v2tc pdelay-interval		365
ptp v2tc primary-domain		365
ptp v2tc sync-local-clock		367
ptp v2tc syntonization		365
ptp v2tc vlan		366
ptp v2tc vlan-priority		366
<b>R</b>		
radius accounting mode		505
radius server host		506
radius server key		507
radius server msgauth		507
radius server primary		508
radius server retransmit		509
radius server timeout		510
reboot		298
reload		299
reset system command	298, 299	
ring-coupling		450
ring-coupling config		451
ring-coupling net-coupling		452
ring-coupling operation		452
ring-coupling port		453
ring-coupling redundancy-mode		453
rmon-alarm add		186
rmon-alarm delete		187
rmon-alarm disable		188
rmon-alarm enable		187
rmon-alarm modify falling-event		191
rmon-alarm modify interval		189
rmon-alarm modify mib-variable		188
rmon-alarm modify rising-event		191
rmon-alarm modify sample-type		190
rmon-alarm modify startup-alarm		190
rmon-alarm modify thresholds		189

S	
Schulungsangebot	569
script apply	168
script delete	169
script list	169
script show	170
script validate	170
selftest ramtest	211
selftest reboot-on-error	212
serial timeout	126
session-limit	100
sessions	
closing	263, 294
displaying	264
session-timeout	101
set garp timer join	192
set garp timer leave	193
set garp timer leaveall	194
set gmrp adminmode	195
set gmrp forward-all-groups	198
set gmrp interfacemode	196, 197
set igmp	199, 200
set igmp aging-time-unknown	201
set igmp automatic-mode	201
set igmp forward-all	202
set igmp forward-unknown	203
set igmp groupmembershipinterval	205
set igmp interfacemode	206
set igmp lookup-interval-unknown	207
set igmp lookup-resp-time-unknown	207
set igmp maxresponse	208
set igmp querier max-response-time	209
set igmp querier protocol-version	209
set igmp querier status	210
set igmp querier tx-interval	210
set igmp query-ports-to-filter	211
set igmp static-query-port	204
set prompt	127
show address-conflict	52
show arc	432
show arp switch	52, 59
show authentication	58, 513
show authentication users	514
show boot skip-aca-on-boot	276, 276
show bridge address-learning	53
show bridge address-relearn-detect	53
show bridge aging-time	54
show bridge duplex-mismatch-detect	54
show bridge fast-link-detection	54
show bridge framesize	55
show bridge vlan-learning	55
show classofservice dot1pmapping	88
show classofservice ip-dscp-mapping	89
show classofservice trust	90
show commands	
show inventory	212, 213, 214, 216, 217, 218, 220, 221, 485
show lags summary	224
show loginsession	264
show port	223
show stats switch detailed	60, 62, 68
show switchconfig	226, 227, 228
show users	265
show vlan detailed	228
show vlan interface	231
show vlan summary	230
show config-watchdog	56
show device-status	57
show dhcp-relay	461
show dhcp-server	467
show dhcp-server operation	467
show dhcp-server pool	468
show dhcp-server port	468
show digital-input	110, 113
show digital-input all	112
show digital-input config	111
show digital-output	114, 117
show digital-output all	116
show digital-output config	115
show dot1x	515
show dot1x clients	521
show dot1x users	520
show dvlan-tunnel	94
show ethernet-ip	127, 130
show eventlog	59
show fast-hiper-ring	442
show fast-hiper-ring current-id	443
show garp	212
show gmrp configuration	213
show hiper-ring	436
show hiper-ring info	437
show igmpsnooping	214
show inlinepower	369
show inlinepower port	369
show inlinepower slot	373
show interface	60
show interface ethernet	62
show interface switchport	70
show inventory	249
show ip http	530
show ip https	533
show link-aggregation	224
show link-aggregation brief	96
show lldp	301
show lldp chassis tx-interval	304
show lldp config	301
show lldp config chassis	302

show lldp config chassis admin-state	302	show snmptrap	133
show lldp config chassis notification-interval	303	show snmp	331
show lldp config chassis re-init-delay	303	show snmp anycast	332
show lldp config chassis tx-delay	304	show snmp client	333
show lldp config chassis tx-hold-mult	304	show snmp operation	334
show lldp config port	305	show snmp server	334
show lldp config port tlv	306	show snmp status	335
show lldp med	307	show snmp time	336
show lldp med interface	308	show spanning-tree	389
show lldp med local-device detail	309	show spanning-tree brief	390
show lldp med remote-device	309	show spanning-tree interface	391
show lldp med remote-device detail	310	show spanning-tree mst detailed	392
show lldp remote-data	310	show spanning-tree mst port detailed	394
show logging	70	show spanning-tree mst port summary	397
show login-session	264, 271	show spanning-tree mst summary	398
show mac-addr-table	71	show spanning-tree summary	399
show mac-filter-table gmrp	216	show spanning-tree vlan	400
show mac-filter-table igmpsnooping	217	show storm-control	227
show mac-filter-table multicast	218	show storm-control limiters port	228
show mac-filter-table static	219	show sub-ring	475
show mac-filter-table staticfiltering	220	show switchconfig	103
show mac-filter-table stats	221	show sysinfo	75, 91
show monitor session	222	show telnet	134
show mrp	425	show telnetcon	135
show mrp current domain	426	show temperature	78
show network	103, 128	show trapflags	136
show network mgmt-access	129	show users	265
show port	223, 243, 244	show users authentication	525
show port-monitor	378, 379	show vlan	228
show port-monitor brief	380	show vlan brief	230
show port-monitor crc-fragment	381	show vlan port	231
show port-monitor link-flap	381	show voice vlan	232
show port-sec mode	455	show voice vlan interface	233
show port-sec port	455	shutdown	234
show ptp	345	shutdown all	235
show ptp configuration	346	signal-contact	295
show ptp operation	346	signal-contact connection-error	295
show ptp port	347	slot/port	25
show ptp status	348	snmp trap link-status	236
show radius	522	snmp trap link-status all	237
show radius accounting	511	snmp-access global	137, 138
show radius statistics	523	snmp-access version v3-encryption	138
show reboot	298	snmp-server	79, 139
show reload	300	snmp-server community	140
show ring-coupling	448	snmp-server community ipaddr	142
show rmon-alarm	226	snmp-server community ipmask	143
show running-config	74	snmp-server community mode	144
show selftest	226	snmp-server community ro	145
show serial	131	snmp-server community rw	145
show signal-contact	72	snmp-server contact	141
show slot	73	snmp-server enable traps	146
show snmp-access	131	snmp-server enable traps linkmode	149
show snmpcommunity	132	snmp-server enable traps multiusers	150
		snmp-server enable traps port-sec	151

# Index

---

snmp-server enable traps stpmode	152	storm-control flowcontrol per port	244
snmp-server location	145	storm-control ingress-limit	242
snmp-server sysname	146	storm-control ingress-limiting	241
snmptrap	153	storm-control ingress-mode	241, 242
snmptrap ipaddr	154	sub-ring mode	477
snmptrap mode	155	sub-ring mrp-domainID	481
snmptrap snmpversion	156	sub-ring operation	478
SNTP - Simple Network Time Protocol	331	sub-ring port	479
sntp anycast address	337	sub-ring protocol	478
sntp anycast transmit-interval	337	sub-ring ring-name	479
sntp anycast vlan	338	sub-ring vlan	480
sntp client accept-broadcast	338	Sub-Ring Commands	475
sntp client disable-after-sync	339	sub-ring delete-ring	482
sntp client offset	339	sub-ring new-ring	482
sntp client request-interval	340	switch	
sntp client server primary	340	information, related 201 commands	226, 227, 228
sntp client server secondary	341	inventory	212, 213, 214, 216, 217, 218, 220, 221, 485
sntp client threshold	342	resetting	298, 299
sntp operation	343	statistics, related 201 commands	60, 62, 68
sntp server disable-if-local	344	System Information and Statistics Commands	83
spanning-tree	401	System Utilities	275, 485
spanning-tree auto-edgeport	402	system utilities	275–294
spanning-tree bpduguard	403	T	
spanning-tree bpdumigrationcheck	238	tagging	255, 257
spanning-tree configuration name	404	telnet	97
spanning-tree configuration revision	405	sessions, closing	263, 294
spanning-tree edgeport	406	sessions, displaying	264
spanning-tree forceversion	407	telnetcon maxsessions	157
spanning-tree forward-time	408	telnetcon timeout	158
spanning-tree guard loop	409	temperature	297
spanning-tree guard none	410	traceroute	278
spanning-tree guard root	411	transport input telnet	98
spanning-tree hello-time	412	transport output telnet	99
spanning-tree hold-count	413	trap log	
spanning-tree max-age	414	clearing	282, 283
spanning-tree max-hops	415	trunks. See LAGs	
spanning-tree mst	416	U	
spanning-tree mst instance	420	User Account Management Commands	263
spanning-tree mst priority	418	user account management commands	
spanning-tree mst vlan	419	201 commands	263
spanning-tree port mode	421	User Exec Mode	45
spanning-tree port mode all	422	users	
spanning-tree stp-mrp-mode	423	adding	268, 269
spanning-tree tcnguard	424	deleting	267, 268, 269
speed	239	displaying	265
speeds	239	passwords	270, 281
statistics		users access	268
switch, related 201 commands	60, 62, 68		
storm-control broadcast	240		
storm-control broadcast (port-related)	241		
storm-control egress-limit	242		
storm-control egress-limiting	240		
storm-control flowcontrol	243		

users defaultlogin	266
users login	267, 526
users name	269
users passwd	270
users snmpv3 accessmode	271
users snmpv3 authentication	272
users snmpv3 encryption	273

## V

vlan	245
vlan acceptframe	247, 248
vlan ingressfilter	248
VLAN Mode	45
vlan name	249
vlan participation	250
vlan participation all	251
vlan port acceptframe all	252
vlan port ingressfilter all	253
vlan port priority all	91
vlan port pvid all	254
vlan port tagging all	255
vlan priority	91
vlan pvid	256
vlan tagging	257
vlan0-transparent-mode	246
VLANs	
adding	245
changing the name of	249
deleting	245
details	228
frame acceptance mode	247, 248, 252
IDs	254, 256
ingress filtering	248, 249, 253
jointime	186, 187, 188, 189, 190, 191, 192
leave all time	194
leave time	193
participation in	250, 251
port information	231
resetting parameters	284
summary information	230
tagging	255, 257
voice vlan (Global Config Mode)	258
voice vlan (Interface Config Mode)	259
voice vlan auth	261

## W

Web connections, displaying	264
-----------------------------	-----

# Further support

## U Technical questions and training courses

For technical questions, please contact any Hirschmann dealer in your area or Hirschmann directly.

You will find the addresses of our partners on the Internet at <http://www.beldensolutions.com>

Contact our support at <https://hirschmann-support.belden.eu.com>

You can contact us

in the EMEA region at

D Tel.: +49 (0)1805 14-1538

D E-mail: [hac.support@belden.com](mailto:hac.support@belden.com)

in the America region at

D Tel.: +1 (717) 217-2270

D E-mail: [inet-support.us@belden.com](mailto:inet-support.us@belden.com)

in the Asia-Pacific region at

D Tel.: +65 68549860

D E-mail: [inet-ap@belden.com](mailto:inet-ap@belden.com)

## U Hirschmann Competence Center

The Hirschmann Competence Center is ahead of its competitors:

D Consulting incorporates comprehensive technical advice, from system evaluation through network planning to project planning.

D Training offers you an introduction to the basics, product briefing and user training with certification.

The current training courses to technology and products can be found at <http://www.hicomcenter.com>

D Support ranges from the first installation through the standby service to maintenance concepts.

With the Hirschmann Competence Center, you have decided against making any compromises. Our client-customized package leaves you free to choose the service components you want to use.

Internet:

<http://www.hicomcenter.com>



**HIRSCHMANN**

---

A **BELDEN** BRAND