

## SL126020

FLOW SENSORS • SENSORS FOR AIR

### DIMENSIONAL DRAWING

#### INSTALLATION



Mounting / Installation may only be carried out by a qualified electrician!

#### DISPOSAL



#### SAFETY WARNINGS

Before initial operation, please make sure to follow all safety instructions that may be provided in the product information!